



WAGO-I/O-SYSTEM 750 **PFC200 DC 2ETH RS CAN** **750-8204(/xxx-xxx)** **PLC - PFC200 Controller**

Version 1.1.0, valid from SW-Version 02.02.12(03)

WAGO®

© 2014 by WAGO Kontakttechnik GmbH & Co. KG
All rights reserved.

WAGO Kontakttechnik GmbH & Co. KG

Hansastraße 27
D-32423 Minden

Phone: +49 (0) 571/8 87 – 0
Fax: +49 (0) 571/8 87 – 1 69

E-Mail: info@wago.com

Web: <http://www.wago.com>

Technical Support

Phone: +49 (0) 571/8 87 – 5 55
Fax: +49 (0) 571/8 87 – 85 55

E-Mail: support@wago.com

Every conceivable measure has been taken to ensure the accuracy and completeness of this documentation. However, as errors can never be fully excluded, we always appreciate any information or suggestions for improving the documentation.

E-Mail: documentation@wago.com

We wish to point out that the software and hardware terms as well as the trademarks of companies used and/or mentioned in the present manual are generally protected by trademark or patent.

Table of Contents

1	Notes about this Documentation.....	12
1.1	Validity of this Documentation.....	12
1.2	Copyright.....	12
1.3	Symbols.....	13
1.4	Number Notation.....	15
1.5	Font Conventions.....	15
2	Important Notes	16
2.1	Legal Bases	16
2.1.1	Subject to Changes	16
2.1.2	Personnel Qualifications.....	16
2.1.3	Use of the WAGO-I/O-SYSTEM 750 in Compliance with Underlying Provisions	16
2.1.4	Technical Condition of Specified Devices.....	17
2.2	Safety Advice (Precautions).....	18
2.3	Special Use Conditions for ETHERNET Devices.....	20
3	Device Description	21
3.1	View	24
3.2	Connectors.....	26
3.2.1	Data Contacts/Internal Bus.....	26
3.2.2	Power Jumper Contacts/Field Supply	27
3.2.3	CAGE CLAMP® Connectors	28
3.2.4	Service Interface.....	29
3.2.5	Network Connections – X1, X2	30
3.2.6	RS-232/RS-485 – X3 Communication Connection	31
3.2.6.1	Operating as an RS-232 Interface.....	32
3.2.6.2	Operating as an RS-485 Interface.....	33
3.2.7	CANopen – X4 Fieldbus Connection.....	34
3.3	Display Elements	36
3.3.1	Power Supply Indicating Elements	36
3.3.2	Fieldbus/System Indicating Elements	37
3.3.3	Memory Card Indicating Elements	38
3.3.4	Network Indicating Elements.....	39
3.4	Operating Elements	40
3.4.1	Operating Mode Switch.....	40
3.4.2	Reset Button	41
3.5	Slot for Memory Card	42
3.6	Schematic Diagram	43
3.7	Technical Data	44
3.7.1	Device Data	44
3.7.2	System Data.....	44
3.7.3	Power supply	44
3.7.4	Clock.....	44
3.7.5	Programming.....	45
3.7.6	Internal data bus	45
3.7.7	ETHERNET	45
3.7.8	CANopen.....	45

3.7.9	Serial interface.....	46
3.7.10	Connection Type	47
3.7.11	Climatic Environmental Conditions.....	47
3.8	Approvals	48
3.9	Standards and Guidelines	48
4	Function Description	49
4.1	Network Configuration	49
4.1.1	Operation in Switch Mode.....	49
4.1.2	Operation with Separate Network Interfaces	49
5	Mounting.....	50
5.1	Installation Position.....	50
5.2	Overall Configuration	50
5.3	Mounting onto Carrier Rail.....	52
5.3.1	Carrier Rail Properties.....	52
5.3.2	WAGO DIN Rail.....	53
5.4	Spacing.....	53
5.5	Mounting Sequence.....	54
5.6	Inserting Devices.....	55
5.6.1	Inserting the Fieldbus Coupler/Controller.....	55
5.6.2	Inserting the I/O Module	56
6	Connect Devices	57
6.1	Connecting a Conductor to the CAGE CLAMP®.....	57
6.2	Power Supply Concept.....	58
6.2.1	Supplementary Power Supply Regulations	58
7	Commissioning.....	60
7.1	Switching On the Controller	60
7.2	Determining the IP Address of the Host PC	61
7.3	Setting an IP Address	62
7.3.1	Assigning an IP Address using DHCP	63
7.3.2	Changing an IP Address using the “CBM” Configuration Tool via the Serial Interface.....	64
7.3.3	Changing an IP Address using “WAGO Ethernet Settings”	67
7.4	Testing the Network Connection	69
7.5	Shutdown/Restart	70
7.6	Initiating Reset Functions	71
7.6.1	Warm Start Reset.....	71
7.6.2	Cold Start Reset.....	71
7.6.3	Software Reset.....	71
7.6.4	Setting a Fixed IP Address	71
7.6.5	Factory Reset.....	72
7.7	Users and Passwords	73
7.7.1	Services and Users.....	73
7.7.2	WBM Group.....	74
7.7.3	Linux User Group.....	74
7.7.4	SNMP User Group	74
7.8	Configuration	75
7.8.1	Configuration using Web-Based Management (WBM).....	76
7.8.1.1	WBM User Administration.....	77

7.8.1.2	General Information about the Page	79
7.8.1.3	“Status Information” Page	81
7.8.1.3.1	“Controller Details” Group	81
7.8.1.3.2	“Network Details (Xn)” Group(s)	81
7.8.1.4	“CODESYS Configuration” Page	82
7.8.1.4.1	“General Configuration” Group	82
7.8.1.5	“CODESYS Information” Page	83
7.8.1.5.1	“CODESYS” Group	83
7.8.1.5.2	“Project Details” Group	83
7.8.1.5.3	"Task n" Group(s)	83
7.8.1.6	“CODESYS WebVisu” Page	85
7.8.1.6.1	“Webserver Configuration” Group	85
7.8.1.7	“Configuration of Network Parameters” Page"	86
7.8.1.7.1	“Hostname” Group	86
7.8.1.7.2	“Domain Name” Group	86
7.8.1.8	“TCP/IP Configuration” Page	87
7.8.1.8.1	“Switch Configuration” Group	87
7.8.1.8.2	“IP Address (Xn)” Group(s)	87
7.8.1.8.3	“Default Gateway” Group	88
7.8.1.8.4	“DNS Server” Group	88
7.8.1.9	“Configuration of ETHERNET Parameters” Page	89
7.8.1.9.1	“Interface Xn” Groups	89
7.8.1.10	“Configuration of Time and Date” Page	90
7.8.1.10.1	“Date on Device” Group	90
7.8.1.10.2	“Time on Device” Group	90
7.8.1.10.3	“Time Zone” Group	91
7.8.1.10.4	“TZ String” Group	91
7.8.1.11	“Configuration of the Users for the Web-based Management” Page	92
7.8.1.11.1	“Change Password for Selected User” Group	92
7.8.1.12	“Create Bootable Image” Page	93
7.8.1.12.1	"Create Bootable Image from Active Partition (<Active Partition>" Group	93
7.8.1.13	“Configuration of Serial Interface RS232” Page	94
7.8.1.13.1	“Serial Interface Assigned to” Group	94
7.8.1.13.2	“Assign Owner of Serial Interface (Active after Next Controller Reboot)” Group	94
7.8.1.14	“Reboot Controller” Page	95
7.8.1.14.1	“Reboot Controller” Group	95
7.8.1.15	“Firmware Back-up” Page	96
7.8.1.16	“Firmware Restore” Page	97
7.8.1.17	“System Partition” Page	98
7.8.1.17.1	“Current Active Partition” Group	98
7.8.1.17.2	“Set Inactive Partition Active” Group	98
7.8.1.18	“Mass Storage” Page	99
7.8.1.18.1	“<Device Name>” Group(s)	99
7.8.1.18.2	“<Device Name> - FAT Format” Group(s)	99
7.8.1.19	“Software Uploads” Page	100
7.8.1.19.1	“Upload New Software” Group	100
7.8.1.19.2	“Activate New Software” Group	100
7.8.1.20	“Configuration of Network Services” Page	101

7.8.1.20.1	“Telnet” Group.....	101
7.8.1.20.2	“FTP” Group.....	101
7.8.1.20.3	“FTPS” Group.....	101
7.8.1.20.4	“HTTP” Group.....	101
7.8.1.20.5	“HTTPS” Group.....	101
7.8.1.21	“Configuration of NTP Client” Page.....	102
7.8.1.21.1	“NTP Client” Group.....	102
7.8.1.22	“Configuration of the CODESYS Services” Page.....	103
7.8.1.22.1	“CODESYS Webserver” Group.....	103
7.8.1.22.2	“Communication” Group.....	103
7.8.1.22.3	“Port Authentication” Group.....	103
7.8.1.22.4	“Port Authentication Password” Group.....	103
7.8.1.23	“SSH Client Settings” Page.....	104
7.8.1.23.1	“SSH Client” Group.....	104
7.8.1.24	“TFTP Server” Page.....	105
7.8.1.24.1	“TFTP Server” Group.....	105
7.8.1.25	“Configuration of SNMP parameter” Page.....	106
7.8.1.25.1	“General SNMP Configuration” Group.....	106
7.8.1.26	“Configuration of SNMP Parameter” Page.....	107
7.8.1.26.1	“SNMP v1/v2c Manager Configuration” Group.....	107
7.8.1.26.2	“Actually Configured Trap Receivers” Group(s).....	107
7.8.1.26.3	“Trap Receiver n” Group(s).....	108
7.8.1.26.4	“Add new Trap Receiver” Group.....	108
7.8.1.27	“Configuration of SNMP v3 Users” Page.....	109
7.8.1.27.1	“Actually Configured v3 Users” Group(s).....	109
7.8.1.27.2	“v3 User n” Group(s).....	109
7.8.1.27.3	“Add New v3 User” Group.....	110
7.8.1.28	“Diagnostic Information” Page.....	111
7.8.2	Configuration using a Terminal Program (CBM).....	112
7.8.3	Configuration using “WAGO ETHERNET Settings”.....	113
7.8.3.1	Identification Tab.....	115
7.8.3.2	Network Tab.....	116
7.8.3.3	Protocol Tab.....	118
7.8.3.4	Status Tab.....	119
8	Run-time System CODESYS 2.3.....	120
8.1	Installing the CODESYS 2.3 Programming System.....	120
8.2	First Program with CODESYS 2.3.....	120
8.2.1	Start the CODESYS Programming System.....	120
8.2.2	Creating a Project and Selecting the Target System.....	120
8.2.3	Creating the PLC Configuration.....	122
8.2.4	Editing the Program Function Block.....	128
8.2.5	Loading and Running the PLC Program in the Fieldbus Controller (ETHERNET).....	131
8.2.6	Creating a Boot Project.....	133
8.3	Syntax of Logical Addresses.....	133
8.4	Creating Tasks.....	134
8.4.1	Cyclic Tasks.....	137
8.4.2	Freewheeling Tasks.....	138
8.5	System Events.....	138
8.5.1	Creating an Event Handler.....	141

8.6	Process Images	143
8.6.1	Process Images for I/O Modules Connected to the Controller.....	145
8.6.2	Process Image for Slaves Connected to the Fieldbus.....	146
8.7	Access to Process Images of the Input and Output Data via CODESYS 2.3.....	146
8.8	Addressing Example	148
8.9	Internal Data Bus Synchronization	149
8.9.1	Case 1: CODESYS Task Interval Set Smaller than the I/O Module Cycle.....	149
8.9.2	Case 2: CODESYS Task Interval Smaller than Twice the Internal Data Bus Cycle.....	151
8.9.3	Case 3: CODESYS Task Interval Greater than Twice the Internal Data Bus Cycle	152
8.9.4	Case 4: CODESYS Task Interval Greater than 10 ms	153
8.9.5	Internal Data Bus Configuration	154
8.9.5.1	Effect of Update Mode on CODESYS Tasks.....	155
8.9.5.1.1	Asynchronous Update Mode.....	155
8.9.5.1.2	Synchronous Update Mode.....	156
8.10	Memory Settings in CODESYS.....	156
8.10.1	Program Memory.....	156
8.10.2	Data Memory and Function Block Limitation	157
8.10.3	Remanent Memory	158
8.11	CODESYS Visualization	159
8.11.1	Limits of CODESYS Visualization.....	162
8.11.2	Eliminating Errors in CODESYS Web Visualization.....	164
8.11.3	FAQs about CODESYS Web Visualization.....	165
9	MODBUS	167
9.1	General	167
9.2	Features	167
9.3	Configuration	168
9.3.1	MODBUS Settings	169
9.3.2	MODBUS TCP Settings.....	170
9.3.3	MODBUS UDP Settings	170
9.3.4	MODBUS RTU Settings	171
9.4	Data Exchange	173
9.4.1	Process Image.....	174
9.4.2	Flag Area	175
9.4.3	MODBUS Registers	176
9.4.4	MODBUS Mapping.....	176
9.4.4.1	MODBUS Mapping for Write Bit Services FC1, FC2.....	176
9.4.4.2	MODBUS Mapping for Write Bit Services FC5, FC15.....	177
9.4.4.3	MODBUS Mapping for Read Register Services FC3, FC4, FC23/178	
9.4.4.4	MODBUS Mapping for Write Register Services FC6, FC16, FC22, FC23	180
9.5	WAGO MODBUS Register	182
9.5.1	Process Image Properties.....	183
9.5.1.1	Register 0x1022 – Number of Registers in the MODBUS Input Process Image	183
9.5.1.2	Register 0x1023 – Number of Registers in the MODBUS Output Process Image	183

9.5.1.3	Register 0x1024 – Number of Bits in the MODBUS Input Process Image	183
9.5.1.4	Register 0x1025 – Number of Bits in the MODBUS Output Process Image	183
9.5.2	Network Configuration.....	184
9.5.2.1	Register 0x1028 – IP Configuration.....	184
9.5.2.2	Register 0x102A – Number of Established TCP Connections....	184
9.5.2.3	Register 0x1030 – MODBUS TCP Socket Timeout.....	184
9.5.2.4	Register 0x1031 – MAC Address for ETHERNET-Interface 1 (eth0).....	184
9.5.2.5	Register 0x1037 - MODBUS TCP Response Delay	184
9.5.3	PLC Status Register.....	185
9.5.4	MODBUS Watchdog.....	185
9.5.4.1	Register 0x1100 – Watchdog Command.....	185
9.5.4.2	Register 0x1101 – Watchdog Status.....	187
9.5.4.3	Register 0x1102 – Watchdog Timeout.....	187
9.5.4.4	Register 0x1103 – Watchdog Config	188
9.5.5	MODBUS Constants Register.....	188
9.5.6	Electronic Nameplate	189
9.5.6.1	Register 0x2010 – Revision (Firmware Index)	189
9.5.6.2	Register 0x2011 – Series Designator.....	189
9.5.6.3	Register 0x2012 – Device ID	189
9.5.6.4	Register 0x2013 – Major Firmware Version.....	189
9.5.6.5	Register 0x2014 – Minor Firmware Version.....	189
9.5.6.6	Register 0x2015 – MBS Version.....	189
9.6	Diagnostics	190
9.6.1	Diagnostics for the MODBUS Master	190
9.6.2	Diagnostics for the Runtime System	190
9.6.3	Diagnostics for the Error Server.....	190
10	CANopen Master and Slave.....	193
10.1	Object Directory.....	193
10.2	Communications Profile.....	193
10.2.1	Master Configuration.....	197
10.3	Data Exchange	198
10.3.1	Controller Communication Objects.....	198
10.3.2	Fieldbus-Specific Addressing.....	199
10.3.3	Examples for the Definition of PFC Fieldbus Variables.....	203
10.3.3.1	CODESYS Access to PFC Variables	203
10.3.3.2	Maximum Indices	203
10.3.4	CANopen Master Control Configuration	205
10.3.4.1	Selecting the Master	205
10.3.4.2	Setting the Master Parameters	206
10.3.4.3	Adding Slaves	208
10.3.4.4	Configuring the Slave PDOs	214
10.3.4.5	Configuring the Service Data Objects	217
10.3.5	CANopen Slave Control Configuration	220
10.3.5.1	CANopen Variables Configuration	221
10.3.5.2	Configuring of CANopen Parameters	222
10.4	Fieldbus Coupler Diagnostics	223
10.4.1	DiagGetBusState() and DiagGetState().....	223

10.4.2	Creating Diagnostics 7 in CODESYS 2.3	224
10.4.3	Calling Up the Diagnostics Function Block.....	226
10.4.4	Executing a Bus Diagnosis using DiagGetBusState().....	227
10.4.5	Performing Subscriber Diagnostics using DiagGetState().....	229
10.4.6	Evaluating the CANopen Diagnosis (Emergency Messages)	231
10.5	Data Exchange between Simple CAN Subscribers and PFC200 in the CANopen Network.....	233
10.6	Data Exchange between CAN Subscribers and the PFC200 in a CAN Layer2 Network	235
11	Diagnostics	236
11.1	Operating and Status Messages.....	236
11.1.1	Power Supply Indicating Elements	236
11.1.2	Fieldbus/System Indicating Elements	237
11.2	Diagnostics Messages (I/O LED).....	241
11.2.1	Flashing Sequence	241
11.2.2	Example of a Diagnostics Message Indicated by a Blink Code.....	243
11.2.3	Meaning of Blink Codes and Procedures for Troubleshooting.....	244
12	Service	250
12.1	Inserting and Removing the Memory Card.....	250
12.1.1	Inserting the Memory Card	250
12.1.2	Removing the Memory Card.....	250
13	Removal	252
13.1	Removing Devices	252
13.1.1	Removing the Fieldbus Coupler/Controller	252
13.1.2	Removing the I/O Module.....	253
14	Appendix.....	254
14.1	Structure of Process Data for the I/O Modules	254
14.1.1	Digital Input Modules.....	255
14.1.1.1	1 Channel Digital Input Module with Diagnostics	255
14.1.1.2	2 Channel Digital Input Modules	255
14.1.1.3	2 Channel Digital Input Module with Diagnostics	255
14.1.1.4	2 Channel Digital Input Module with Diagnostics and Output Process Data.....	256
14.1.1.5	4 Channel Digital Input Modules	256
14.1.1.6	8 Channel Digital Input Modules	256
14.1.1.7	8 Channel Digital Input Module PTC with Diagnostics and Output Process Data.....	257
14.1.1.8	16 Channel Digital Input Modules	257
14.1.2	Digital Output Modules.....	258
14.1.2.1	1 Channel Digital Output Module with Input Process Data	258
14.1.2.2	2 Channel Digital Output Modules.....	258
14.1.2.3	2 Channel Digital Input Modules with Diagnostics and Input Process Data.....	259
14.1.2.4	4 Channel Digital Output Modules.....	260
14.1.2.5	4 Channel Digital Output Modules with Diagnostics and Input Process Data.....	260
14.1.2.6	8 Channel Digital Output Module	260

14.1.2.7	8 Channel Digital Output Modules with Diagnostics and Input Process Data.....	261
14.1.2.8	16 Channel Digital Output Modules.....	261
14.1.2.9	8 Channel Digital Input/Output Modules.....	262
14.1.3	Analog Input Modules.....	263
14.1.3.1	1 Channel Analog Input Modules.....	263
14.1.3.2	2 Channel Analog Input Modules.....	263
14.1.3.3	4 Channel Analog Input Modules.....	264
14.1.3.4	3-Phase Power Measurement Module.....	265
14.1.3.5	8 Channel Analog Input Modules.....	265
14.1.4	Analog Output Modules.....	266
14.1.4.1	2 Channel Analog Output Modules.....	266
14.1.4.2	4 Channel Analog Output Modules.....	266
14.1.5	Specialty Modules.....	267
14.1.5.1	Counter Modules.....	267
14.1.5.2	Pulse Width Modules.....	269
14.1.5.3	Serial Interface Modules with alternative Data Format.....	269
14.1.5.4	Serial Interface Modules with Standard Data Format.....	270
14.1.5.5	Data Exchange Module.....	270
14.1.5.6	SSI Transmitter Interface Modules.....	270
14.1.5.7	Incremental Encoder Interface Modules.....	271
14.1.5.8	DC-Drive Controller.....	273
14.1.5.9	Stepper Controller.....	274
14.1.5.10	RTC Module.....	275
14.1.5.11	DALI/DSI Master Module.....	275
14.1.5.12	DALI Multi-Master Module.....	276
14.1.5.13	LON [®] FTT Module.....	278
14.1.5.14	EnOcean Radio Receiver.....	278
14.1.5.15	MP Bus Master Module.....	278
14.1.5.16	Bluetooth [®] RF-Transceiver.....	279
14.1.5.17	Vibration Velocity/Bearing Condition Monitoring VIB I/O.....	280
14.1.5.18	KNX/EIB/TP1 Module.....	280
14.1.5.19	AS-interface Master Module.....	281
14.1.6	System Modules.....	283
14.1.6.1	System Modules with Diagnostics.....	283
14.1.6.2	Binary Space Module.....	283
14.2	CODESYS Libraries.....	284
14.2.1	General Libraries.....	284
14.2.1.1	CODESYS System Libraries.....	284
14.2.1.2	SysLibCom.lib.....	285
14.2.1.3	SysLibFile.lib.....	285
14.2.1.4	SysLibFileAsync.lib.....	286
14.2.1.5	SysLibRtc.lib.....	286
14.2.1.6	BusDiag.lib.....	287
14.2.1.7	mod_com.lib.....	287
14.2.1.8	SerComm.lib.....	287
14.2.1.9	WagoConfigToolLIB.lib.....	288
14.2.1.10	WagoLibCpuUsage.lib.....	303
14.2.1.11	WagoLibDiagnosticIDs.lib.....	303
14.2.1.12	WagoLibLed.lib.....	304

14.2.1.13	WagoLibNetSnmp.lib	304
14.2.1.14	WagoLibNetSnmpManager.lib.....	304
14.2.1.15	WagoLibSSL.lib	305
14.2.1.16	WagoLibTerminalDiag.lib.....	305
14.2.2	Libraries for a CANopen and CANLayer2 Link	306
14.2.2.1	WagoCANLayer2_02.lib.....	306
14.2.2.2	WagoCANopen_02.lib	306
List of Figures		307
List of Tables.....		310

1 Notes about this Documentation

Note



Always retain this documentation!

This documentation is part of the product. Therefore, retain the documentation during the entire service life of the product. Pass on the documentation to any subsequent user. In addition, ensure that any supplement to this documentation is included, if necessary.

1.1 Validity of this Documentation

This documentation is only applicable to the controller “PFC200 DC 2ETH RS CAN” (750-8204) and the variants listed in the table below.

Table 1: Variants

Item Number/Variant	Designation
750-8204	PFC200 DC 2ETH RS CAN
750-8204/025-000	PFC200 DC 2ETH RS CAN/T

Note



Documentation Validity for Variants

Unless otherwise indicated, the information given in this documentation applies to listed variants.

This documentation is only applicable from SW-Version 02.02.12(03).

1.2 Copyright

This Manual, including all figures and illustrations, is copyright-protected. Any further use of this Manual by third parties that violate pertinent copyright provisions is prohibited. Reproduction, translation, electronic and phototechnical filing/archiving (e.g., photocopying) as well as any amendments require the written consent of WAGO Kontakttechnik GmbH & Co. KG, Minden, Germany. Non-observance will involve the right to assert damage claims.

1.3 Symbols

 **DANGER**

Personal Injury!

Indicates a high-risk, imminently hazardous situation which, if not avoided, will result in death or serious injury.

 **DANGER**

Personal Injury Caused by Electric Current!

Indicates a high-risk, imminently hazardous situation which, if not avoided, will result in death or serious injury.

 **WARNING**

Personal Injury!

Indicates a moderate-risk, potentially hazardous situation which, if not avoided, could result in death or serious injury.

 **CAUTION**

Personal Injury!

Indicates a low-risk, potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

NOTICE

Damage to Property!

Indicates a potentially hazardous situation which, if not avoided, may result in damage to property.

NOTICE

Damage to Property Caused by Electrostatic Discharge (ESD)!

Indicates a potentially hazardous situation which, if not avoided, may result in damage to property.

Note

Important Note!

Indicates a potential malfunction which, if not avoided, however, will not result in damage to property.



Information

Additional Information:

Refers to additional information which is not an integral part of this documentation (e.g., the Internet).

1.4 Number Notation

Table 2: Number Notation

Number code	Example	Note
Decimal	100	Normal notation
Hexadecimal	0x64	C notation
Binary	'100' '0110.0100'	In quotation marks, nibble separated with dots (.)

1.5 Font Conventions

Table 3: Font Conventions

Font type	Indicates
<i>italic</i>	Names of paths and data files are marked in italic-type. e.g.: <i>C:\Programme\WAGO-I/O-CHECK</i>
Menu	Menu items are marked in bold letters. e.g.: Save
>	A greater-than sign between two names means the selection of a menu item from a menu. e.g.: File > New
Input	Designation of input or optional fields are marked in bold letters, e.g.: Start of measurement range
“Value”	Input or selective values are marked in inverted commas. e.g.: Enter the value “4 mA” under Start of measurement range .
[Button]	Pushbuttons in dialog boxes are marked with bold letters in square brackets. e.g.: [Input]
[Key]	Keys are marked with bold letters in square brackets. e.g.: [F5]

2 Important Notes

This section includes an overall summary of the most important safety requirements and notes that are mentioned in each individual section. To protect your health and prevent damage to devices as well, it is imperative to read and carefully follow the safety guidelines.

2.1 Legal Bases

2.1.1 Subject to Changes

WAGO Kontakttechnik GmbH & Co. KG reserves the right to provide for any alterations or modifications that serve to increase the efficiency of technical progress. WAGO Kontakttechnik GmbH & Co. KG owns all rights arising from the granting of patents or from the legal protection of utility patents. Third-party products are always mentioned without any reference to patent rights. Thus, the existence of such rights cannot be excluded.

2.1.2 Personnel Qualifications

All sequences implemented on WAGO-I/O-SYSTEM 750 devices may only be carried out by electrical specialists with sufficient knowledge in automation. The specialists must be familiar with the current norms and guidelines for the devices and automated environments.

All changes to the coupler or controller should always be carried out by qualified personnel with sufficient skills in PLC programming.

2.1.3 Use of the WAGO-I/O-SYSTEM 750 in Compliance with Underlying Provisions

Fieldbus couplers, fieldbus controllers and I/O modules found in the modular WAGO-I/O-SYSTEM 750 receive digital and analog signals from sensors and transmit them to actuators or higher-level control systems. Using programmable controllers, the signals can also be (pre-) processed.

The devices have been developed for use in an environment that meets the IP20 protection class criteria. Protection against finger injury and solid impurities up to 12.5 mm diameter is assured; protection against water damage is not ensured. Unless otherwise specified, operation of the devices in wet and dusty environments is prohibited.

Operating the WAGO-I/O-SYSTEM 750 devices in home applications without further measures is only permitted if they meet the emission limits (emissions of interference) according to EN 61000-6-3. You will find the relevant information in the section “Device Description” > “Standards and Guidelines” in the manual for the used fieldbus coupler/controller.

Appropriate housing (per 94/9/EG) is required when operating the WAGO-I/O-SYSTEM 750 in hazardous environments. Please note that a prototype test certificate must be obtained that confirms the correct installation of the system in a housing or switch cabinet.

2.1.4 Technical Condition of Specified Devices

The devices to be supplied ex works are equipped with hardware and software configurations, which meet the individual application requirements. WAGO Kontakttechnik GmbH & Co. KG will be exempted from any liability in case of changes in hardware or software as well as to non-compliant usage of devices.

Please send your request for modified and new hardware or software configurations directly to WAGO Kontakttechnik GmbH & Co. KG.

2.2 Safety Advice (Precautions)

For installing and operating purposes of the relevant device to your system the following safety precautions shall be observed:



DANGER

Do not work on devices while energized!

All power sources to the device shall be switched off prior to performing any installation, repair or maintenance work.

DANGER

Install the device only in appropriate housings, cabinets or in electrical operation rooms!

The WAGO-I/O-SYSTEM 750 and its components are an open system. As such, install the system and its components exclusively in appropriate housings, cabinets or in electrical operation rooms. Allow access to such equipment and fixtures to authorized, qualified staff only by means of specific keys or tools.

NOTICE

Do not use in telecommunication circuits!

Only use devices equipped with ETHERNET or RJ-45 connectors in LANs. Never connect these devices with telecommunication networks.

NOTICE

Replace defective or damaged devices!

Replace defective or damaged device/module (e.g., in the event of deformed contacts), since the long-term functionality of device/module involved can no longer be ensured.

NOTICE

Protect the components against materials having seeping and insulating properties!

The components are not resistant to materials having seeping and insulating properties such as: aerosols, silicones and triglycerides (found in some hand creams). If you cannot exclude that such materials will appear in the component environment, then install the components in an enclosure being resistant to the above-mentioned materials. Clean tools and materials are imperative for handling devices/modules.

NOTICE

Clean only with permitted materials!

Clean soiled contacts using oil-free compressed air or with ethyl alcohol and leather cloths.

NOTICE

Do not use any contact spray!

Do not use any contact spray. The spray may impair contact area functionality in connection with contamination.

NOTICE

Do not reverse the polarity of connection lines!

Avoid reverse polarity of data and power supply lines, as this may damage the devices involved.

NOTICE



Avoid electrostatic discharge!

The devices are equipped with electronic components that may be destroyed by electrostatic discharge when touched. Please observe the safety precautions against electrostatic discharge per DIN EN 61340-5-1/-3. When handling the devices, please ensure that environmental factors (personnel, work space and packaging) are properly grounded.

2.3 Special Use Conditions for ETHERNET Devices

If not otherwise specified, ETHERNET devices are intended for use on local networks. Please note the following when using ETHERNET devices in your system:

- Do not connect control components and control networks to an open network such as the Internet or an office network. WAGO recommends putting control components and control networks behind a firewall.
- Limit physical and electronic access to all automation components to authorized personnel only.
- Change the default passwords before first use! This will reduce the risk of unauthorized access to your system.
- Regularly change the passwords used! This will reduce the risk of unauthorized access to your system.
- If remote access to control components and control networks is required, use a Virtual Private Network (VPN).
- Regularly perform threat analyses. You can check whether the measures taken meet your security requirements.
- Use “defense-in-depth” mechanisms in your system's security configuration to restrict the access to and control of individual products and networks.

3 Device Description

The controller 750-8204(PFC200 DC 2ETH RS CAN) is an automation device that can perform control tasks of a PLC. It is suitable for mounting on a DIN rail and stands out on account of its various interfaces.

This controller can be used for applications in mechanical and systems engineering, in the processing industry and in building technology.

You can connect all available I/O modules of the WAGO-I/O-SYSTEM 750 (750 and 753 Series) to the controller, enabling it to internally process analog and digital signals from the automation environment, or to supply these signals to other devices via one of the available interfaces.

Automation tasks can be executed in all IEC 61131-3-compatible languages with the programming system CODESYS 2.3 (WAGO-I/O-PRO).

The implementation of the CODESYS task processing is optimized with real-time extensions in order to provide maximal performance for automation tasks. For visualization, Web visualization is also available in addition to the development environment.

The controller provides a physical 256 Mbyte program memory (flash), a 256 Mbyte data memory (RAM) and a 128 kbyte remanent memory (retain, NVRAM). The memory capacities may not be able to be utilized fully on account of internal administration.

The file system on the internal memory provides 64 Mbyte for applications. Files may also be stored on a removable memory card, or on an internal RAM disk.

The controller provides a 16 Mbyte program memory, a 64 Mbyte data memory and a 128 kbyte remanent memory (retain and flag variables) in an integrated NVRAM for IEC-61131-3 programming on CODESYS applications.

Two ETHERNET interfaces and an integrated, configurable switch enable line topology wiring for:

- In line topology with a common MAC address and IP address for both interfaces.
- Two separate networks with a common MAC address and an IP address for each interface.

Both of these interfaces support:

- 10Base-T / 100Base-TX
- Full/Half duplex
- Autonegotiation
- Auto-MDI(X)

The following fieldbus circuits are implemented for exchange of process data:

- MODBUS TCP
- MODBUS UDP
- MODBUS RTU (via RS-232 or RS-485)
- CANopen Master/Slave

In the controller, all input signals from the sensors are combined. After connecting the controller, all of the I/O modules on the bus node are detected and a local process image is created from these. Analog and specialty module data is sent via words and/or bytes; digital data is sent bit by bit.

Note



No direct access from fieldbus to the process image for I/O modules!

Any data that is required from the I/O module process image must be explicitly mapped in the CODESYS program to the data in the fieldbus process image and vice versa! Direct access is not possible!

Fieldbus configuration can be performed using the CODESYS 2.3 controller configuration.

A Web-based management system (WBM) is also available as a configuration aid. This system includes various dynamic HTML pages from which, among other things, information about configuration and the status of the controller can be called up. The WBM is already stored in the device and is presented and operated using an Internet browser. You can also save your own HTML pages in the implemented file system, or call up programs directly.

In the controller's initial state, the installed firmware is based on Linux[®], with special real-time extensions of the RT-Preempt patch. In addition, the following application programs are also installed on the controller, along with a number of different auxiliary programs:

- a SNMP server/client
- a Telnet server
- a FTP, FTPS server
- a SSH server/client
- a Web server
- a NTP client
- a BootP and DHCP daemon
- a CODESYS Runtime Environment

Based on IEC-61131-3 programming, data processing takes place on site in the controller. The logical process results can be output directly to the actuators or transmitted via a connected fieldbus to the higher level controller.

Note



Memory card is not included in the scope of delivery!

Note, the controller is delivered without memory card.

To use a memory card, you must order one separately. The controller can also be operated without memory card expansion, the use of a memory card is optional.

Note



Only use recommended memory cards!

Use only the SD memory card available from WAGO (item No. 758-879/000-001) as it is suitable for industrial applications subjected to environmental extremes and was developed for use in the controller.

Compatibility with other commercially available storage media cannot be guaranteed.

3.1 View




Figure 1: View of device

Table 4: Legend for figure “Device view”

Item	Description	See section
1	Marking Options (Mini-WSB)	---
2	LED Indicators – Power Supply	“Indicating elements” > “Indicating element power supply”
3	Data contacts	“Connections” > “Data contacts/Internal data bus”
4	CAGE CLAMP® Connections for Power Supply	“Connections” > “CAGE CLAMP® connections”
5	Slot for memory card	“Memory card slot”
6	Power contacts for power supply of down-circuit I/O modules	“Connections” > “Power contacts/ Field-side supply”
7	Releasing strap	“Mounting” > “Inserting and Removing Device”
8	Service Interface (behind the flap)	“Connections” > “Service interface”
9	Mode selector switch	“Operating elements” > “Mode selector switch”
10	ETHERNET Connections	“Connections” > “Network connections ETHERNET – X1, X2”

11	Safe Locking Feature	“Mounting” > “Inserting and Removing Device”
12	Fieldbus Connection – CANopen	“Connections” > “CANopen – X4 Fieldbus Connection”
13	Serial interface	“Connections” > “Communication port RS-232/RS-485 – X3”
14	LED Indicators – System	“Indicating elements” > “Indicating elements Fieldbus/System”
15	Reset button (in hole)	“Operating elements” > “Reset button”

3.2 Connectors

3.2.1 Data Contacts/Internal Bus

NOTICE

Do not place the I/O modules on the gold spring contacts!

Do not place the I/O modules on the gold spring contacts in order to avoid soiling or scratching!

NOTICE



Ensure that the environment is well grounded!

The devices are equipped with electronic components that may be destroyed by electrostatic discharge. When handling the devices, ensure that the environment (persons, workplace and packing) is well grounded. Avoid touching conductive components, e.g. data contacts.

Communication between the controller and the I/O modules and system power supply for the I/O modules is provided via the internal data bus, which consists of 6 data contacts designed as self-cleaning gold spring contacts.




Figure 2: Data contacts

3.2.2 Power Jumper Contacts/Field Supply

⚠ CAUTION

Risk of injury due to sharp-edged blade contacts!

The blade contacts are sharp-edged. Handle the I/O module carefully to prevent injury.

The controller 750-8204 is equipped with 3 self-cleaning power contacts for transferring of the field-side power supply to down-circuit I/O modules. These contacts are designed as spring contacts.




Figure 3: Power Jumper Contacts

Table 5: Legend for Figure “Power Jumper Contacts”

Contact	Type	Function
1	Spring contact	Potential transmission (U_V) for field supply
2	Spring contact	Potential transmission (0 V) for field supply
3	Spring contact	Potential transmission (ground) for field supply

NOTICE

Do not exceed maximum current via power jumper contacts!

The maximum current to flow through the power jumper contacts is 10 A. Greater currents can damage the contacts.

When configuring your system, ensure that this current is not exceeded. If exceeded, insert an additional supply module.

3.2.3 CAGE CLAMP® Connectors




Figure 4: CAGE CLAMP® connections

Table 6: Legend for figure “CAGE CLAMP® connections”

Contact	Description	Description
1	24 V	System power supply voltage +24 V
2	+	Field-side power supply voltage U_V
3	-	Field-side power supply voltage 0 V
4	Ground	Field-side power supply voltage, ground
5	0 V	System power supply voltage 0 V
6	+	Field-side power supply voltage U_V
7	-	Field-side power supply voltage 0 V
8	Ground	Field-side power supply voltage, ground

Note



Observe supplementary power supply regulations for use in shipbuilding!

Observe supplementary power supply regulations for shipbuilding and the supply voltage in Section “Connect Devices” > ... > “Supplementary Power Supply Regulations”!

3.2.4 Service Interface

The service interface is located behind the flap.

The Service interface is used for communication with WAGO-I/O-CHECK and WAGO-I/O-PRO and for firmware download.




Figure 5: Service interface, (closed and open flap)

Table 7: Service interface

Number	Description
1	Open flap
2	Service interface

NOTICE

Device must be de-energized!

To prevent damage to the device, unplug and plug in the communication cable only when the device is de-energized!

The connection to the 4-pin header under the cover flap can be realized via the communication cables with the item numbers 750-920 and 750-923 or via the WAGO radio adapter with the item number 750-921.

3.2.5 Network Connections – X1, X2




Figure 6: Network connections – X1, X2

Table 8: Legend for Figure "Network Connections – X1, X2"

Contact	Signal	Description
1	TD +	Transmit Data +
2	TD -	Transmit Data -
3	RD +	Receive Data +
4	NC	Not assigned
5	NC	Not assigned
6	RD -	Receive Data -
7	NC	Not assigned
8	NC	Not assigned

3.2.6 RS-232/RS-485 – X3 Communication Connection




Figure 7: RS-232/RS-485 – X3 communication connection

Table 9: Key for the “RS-232/RS-485 – X3 communication connection” figure

Contact	RS-232		RS-485	
	Signal	Description	Signal	Description
1	NC	Not assigned	NC	Not assigned
2	RxD	Receive Data	NC	Not assigned
3	TxD	Transmit Data	RxD/TxD-P	Receive/transmit data +
4	NC	Not assigned	NC	Not assigned
5	FB_GND	Ground	FB_GND	Ground
6	NC	Not assigned	FB_5V	Power Supply
7	RTS	Request to send	NC	Not assigned
8	CTS	Clear to send	RxD/TxD-N	Receive/transmit data -
9	NC	Not assigned	NC	Not assigned
Enclosure	Shield	Shielding	Shield	Shielding

NOTICE

Incorrect parameterization can damage the communication partners!

The voltage levels are -12 V and +12 V for RS-232, and -5 V and +5 V for RS-485.

If the controller interfaces differ from those of the communication partners (RS-232 \leftrightarrow RS-485 or RS-485 \leftrightarrow RS-232), this may damage the interface of the communication partner.

Therefore, always ensure that the controller interface matches those of its communication partners when configuring these items!

DC/DC converters and optocouplers in the fieldbus interface electrically isolate the fieldbus system and the electronics.

3.2.6.1 Operating as an RS-232 Interface

Depending on the device type DTE (e.g., PC) or DCE (e.g., PFC, modem), the RS-232 signals have different data directions.

Table 10: Function of RS-232 signals for DTE/DCE

Contact	Signal	Data Direction	
		DTE	DCE
2	RxD	Input	Output
3	TxD	Output	Input
5	FB_GND	---	---
7	RTS	Output	Input
8	CTS	Input	Output

For a DTE-to-DCE connection, the signals are connected directly (1:1).




Figure 8: Termination with DTE-DCE connection (1:1)

For a DTE-to-DTE connection, the signal connections are crossed.




Figure 9: Termination with DTE-DTE connection (cross-over)

3.2.6.2 Operating as an RS-485 Interface

To minimize reflection at the end of the line, the RS-485 line must be terminated at both ends by a cable termination. If required, one pull-up or pull-down resistor may be used. These resistors ensure a defined level on the bus when no subscriber is active, i.e., when all subscribers are in “Tri-state”.

Note



Attention — bus termination!

The RS-485 MODBUS bus segment must be terminated at both ends!

No more than two terminations per bus segment may be used!

Terminations may not be used in stub and branch lines!

Operation without proper termination of the RS-485 MODBUS network may result in transmission errors.




Figure 10: RS-485 bus termination

3.2.7 CANopen – X4 Fieldbus Connection




Figure 11: CANopen – X4 fieldbus connection

Table 11: Legend for Figure “CANopen – X4 Fieldbus Connection”

Contact	Signal	Description
1	-	Not used
2	CAN_L	CAN Signal Low
3	GND	Ground
4	-	Not used
5	Drain Shield	Shield termination
6	-	Not used
7	CAN_H	CAN Signal High
8	-	Not used
9	CAN_V+	Not used

DC/DC converters and optocouplers in the fieldbus interface provide electrical isolation between the CANopen bus system and the electronics.

The cable shield must be applied to the CAN shield. This is terminated to ground in devices with 1 M Ω (DIN rail contact). A low-impedance connection of the shielding to ground is possible only from the outside (e.g., by a supply module). We recommend using central ground contacts for the entire CANopen bus line shielding.

To minimize reflection at the end of the line, the CANopen line must be terminated at both ends by a cable termination.

Note



Attention - bus termination!

The CANopen bus segment must be terminated at both ends!

No more than 2 terminations per bus segment may be used!

Terminations may not be used in stub and branch lines!

Operation without proper termination of the CANopen network may result in transmission errors.

Note



Observe permissible resistor power loss!

For normal operation, 1/4Watt resistors are sufficient. In the event of a short circuit (24V power supply to a bus line), the resistor is subjected to a power loss of (short-circuit output current from transceiver * power supply voltage). The resistor must be designed to withstand this power loss level.




Figure 12: CANopen standard bus termination

3.3 Display Elements

3.3.1 Power Supply Indicating Elements




Figure 13: Power supply indicating elements

Table 12: Legend for Figure “Power Supply Indicating Elements”

Description	Color	Description
A	Green/off	Status of system power supply voltage
B	Green/off	Status of field-side power supply voltage

3.3.2 Fieldbus/System Indicating Elements




Figure 14: Indicating elements for fieldbus/system

Table 13: Legend for figure “Fieldbus/System Indicating Elements”

Description	Color	Description
SYS	Red/Green/ Orange/Off	System status
RUN	Red/Green/ Orange/Off	PLC program status
I/O	Red/Green/ Orange/Off	Internal data bus status
CG	Without function	
NS	Without function	
CAN	Red/Green/ Orange/Off	CANopen status
U6	Green/Red/ Orange/Off	User LED 6, programmable using the function blocks of the “WagoLibLed.lib” library.
U5	Green/Red/ Orange/Off	User LED 5, programmable using the function blocks of the “WagoLibLed.lib” library.
U4	Red/Green/ Orange/Off	User LED 4, programmable using the function blocks of the “WagoLibLed.lib” library.
U3	Red/Green/ Orange/Off	User LED 3, programmable using the function blocks of the “WagoLibLed.lib” library.
U2	Red/Green/ Orange/Off	User LED 2, programmable using the function blocks of the “WagoLibLed.lib” library.
U1	Red/Green/ Orange/Off	User LED 1, programmable using the function blocks of the “WagoLibLed.lib” library.

3.3.3 Memory Card Indicating Elements




Figure 15: Indicating elements, memory card slot

Table 14: Legend for figure “Indicating Elements, memory card slot”

Description	Color	Description
SD	Yellow/Off	Memory card status

3.3.4 Network Indicating Elements




Figure 16: Indicating elements, RJ-45 jacks

Table 15: Legend for figure “Indicating elements, RJ-45 jacks”

Description	Color	Description
LNK	Green/Off	ETHERNET connection status
ACT	Yellow/Off	ETHERNET data exchange

3.4 Operating Elements

3.4.1 Operating Mode Switch




Figure 17: Mode selector switch

Table 16: Mode selector switch

Item	Activation	Function
RUN	Latching	Normal mode CODESYS 2 application runs.
STOP	Latching	Stop CODESYS 2 application stopped.
RESET	Spring-return	Reset warm start or Reset cold start (based on the duration of activation, see Section “Starting” > “Initiating Reset Functions”)

Other functions can also be initiated using the reset button.

3.4.2 Reset Button




Figure 18: Reset button

The Reset button can be actuated using a suitable object (e.g., pen) through a hole in the enclosure.

Depending on the position of the mode selector switch, the Reset button can be used to initiate different functions: Software reset, factory reset or fixed IP address.

Information about these functions are given in the Section “Starting” > “Initiating Reset Functions”.

3.5 Slot for Memory Card




Figure 19: Memory card slot

The memory card is locked in the enclosure by a push/push mechanism. Inserting and removing the card is described in the Section “Service” > “Inserting and Removing the Memory Card”.

The memory card is protected by a cover flap, which can also be sealed.

Note



Memory card is not included in the scope of delivery!

Note, the controller is delivered without memory card.

To use a memory card, you must order one separately. The controller can also be operated without memory card expansion, the use of a memory card is optional.

Note



Only use recommended memory cards!

Use only the SD memory card available from WAGO (item No. 758-879/000-001) as it is suitable for industrial applications subjected to environmental extremes and was developed for use in the controller.

Compatibility with other commercially available storage media cannot be guaranteed.

3.6 Schematic Diagram




Figure 20: Schematic diagram

3.7 Technical Data

3.7.1 Device Data

Table 17: Technical data, device data

Width	112 mm
Height (from upper edge of DIN 35 rail)	65 mm
Length	100 mm
Weight	250 g

3.7.2 System Data

Table 18: Technical Data – System Data

CPU	Cortex A8, 600 MHz
Operating System	Real-time Linux [®] 3.6 (with RT Preemption Patch)
Main memory (RAM)	256 MB
Internal memory (flash)	256 MB
Non-volatile memory (Retain, NVRAM)	128 KB
Memory card slot	Push-push mechanism, sealing cover lid
Type of memory card	SD and SDHC up to 32 Gbytes (All guaranteed properties are valid only in connection with the WAGO 758-879/000-001 memory card.)

3.7.3 Power supply

Table 19: Technical Data – Power Supply

Power supply	24 VDC (-25 % ... +30 %)
Max. input current (24 V)	550 mA
Total current for I/O modules (5V)	1700 mA
Isolation	500 V system/supply

3.7.4 Clock

Table 20: Technical data – Clock

Drift - system clock (25 °C)	20 ppm
Drift - RTC (25 °C)	3 ppm
Buffer time RTC	30 days

3.7.5 Programming

Table 21: Technical Data – Programming

Programming	WAGO-I/O-PRO V2.3
IEC 61131-3	IL, LD, FBD, ST, FC
Program memory (Flash)	16 MB
Data memory (RAM)	64 MB
Non-volatile memory (Retain + Flag, NVRAM)	128 KB

3.7.6 Internal data bus

Table 22: Technical Data – Internal Data Bus

Number of I/O modules (per node)	64
with bus extension	250
Input and output process image (max.)	1000 words

3.7.7 ETHERNET

Table 23: Technical Data – ETHERNET

ETHERNET	2 x RJ-45 (switched or separated mode)
Transmission medium	Twisted Pair S-UTP, 100 Ω, Cat 5, 100 m maximum cable length
Baud rate	10/100 Mbit/s; 10Base-T/100Base-TX
Protocols	DHCP, DNS, SNTP, FTP, FTPS, SNMP, HTTP, HTTPS, SSH, MODBUS (TCP, UDP)
MODBUS input and output process image, max.	1000 words, also with MODBUS access to the flag area (see Section "MODBUS" > ... > "Flag Area")

Note



No direct access from fieldbus to the process image for I/O modules!

Any data that is required from the I/O module process image must be explicitly mapped in the CODESYS program to the data in the fieldbus process image and vice versa! Direct access is not possible!

3.7.8 CANopen

Table 24: Technical Data – CANopen

CANopen input and output process image max.	2000 words
---	------------

Note



No direct access from fieldbus to the process image for I/O modules!

Any data that is required from the I/O module process image must be explicitly mapped in the CODESYS program to the data in the fieldbus process image and vice versa! Direct access is not possible!

3.7.9 Serial interface

Table 25: Technical Data – Serial Interface

Interface	1 x serial interface per TIA/EIA 232 and TIA/EIA 485 (switchable), 9-pole D-sub female connector
Protocols	MODBUS RTU

3.7.10 Connection Type

Table 26: Technical Data – Field Wiring

Wire connection	CAGE CLAMP®
Cross section	0.08 mm ² ... 2.5 mm ² , AWG 28 ... 14
Stripped lengths	8 mm ... 9 mm / 0.33 in

Table 27: Technical Data – Power Jumper Contacts

Power jumper contacts	Spring contact, self-cleaning
Voltage drop at I _{max.}	< 1 V/64 modules

Table 28: Technical Data – Data Contacts

Data contacts	Slide contact, hard gold plated, self-cleaning
---------------	--

3.7.11 Climatic Environmental Conditions

Table 29: Technical Data – Climatic Environmental Conditions

Operating temperature range	0 °C ... 55 °C
Operating temperature range for components with extended temperature range (750-xxx/025-xxx)	-20 °C ... +60 °C
Storage temperature range	-25 °C ... +85 °C
Storage temperature range for components with extended temperature range (750-xxx/025-xxx)	-40 °C ... +85 °C
Relative humidity	Max. 5 % ... 95 % without condensation
Resistance to harmful substances	Acc. to IEC 60068-2-42 and IEC 60068-2-43
Maximum pollutant concentration at relative humidity < 75 %	SO ₂ ≤ 25 ppm H ₂ S ≤ 10 ppm
Special conditions	Ensure that additional measures for components are taken, which are used in an environment involving: – dust, caustic vapors or gases – ionizing radiation


3.8 Approvals

The following approvals have been granted to the controller “PFC200 DC 2ETH RS CAN” (750-8204):

 Conformity Marking

 cUL_{US} UL508

The following ship approvals have been granted to the basic version of the controller “PFC200 DC 2ETH RS CAN” (750-8204):

 GL (Germanischer Lloyd) Cat. A, B, C, D (EMC 1)

3.9 Standards and Guidelines

The controller “PFC200 DC 2ETH RS CAN” (750-8204) fulfills the following EMC standards:

EMC CE-Immunity to interference acc. to EN 61000-6-2: 2005

EMC CE-Emission of interference acc. to EN 61000-6-3: 2007 + A1: 2011

4 Function Description

4.1 Network Configuration

ETHERNET interfaces X1 and X2 of the controller can be operated in Switch mode or as separate network interfaces.

Switch mode can be switched ON or OFF at run-time.

Switch mode is ON by default and during initial startup. Configuration mode is set to “DHCP”.

For interface X1, a fixed IP address can be set.
Setting a fixed IP address has no effect on the mode previously set.

4.1.1 Operation in Switch Mode

For operation in Switch mode, the TCP/IP settings such as the IP address or subnet mask apply for both X1 and X2.

When switching to Switch mode, the X1 settings are applied as a new common configuration for X1 and X2.

The device is then no longer accessible via the IP address previously set for X2. For CODESYS applications that use X2 for communication must take this into account.

4.1.2 Operation with Separate Network Interfaces

When operating with separate network interfaces, both ETHERNET interfaces can be configured and used separately.

Note that two interfaces still have the same MAC address. Therefore, they must not be operated in the same network segment.

When switching to operating with separate interfaces, interface X2 is initialized with the setting values last valid for it. The connections on the X1 interface persist.

When operating with separate interfaces and fixed IP address, the device can still be accessed via interface X2 via the regular IP address.

5 Mounting

5.1 Installation Position

Along with horizontal and vertical installation, all other installation positions are allowed.

Note



Use an end stop in the case of vertical mounting!

In the case of vertical assembly, an end stop has to be mounted as an additional safeguard against slipping.

WAGO order no. 249-116 End stop for DIN 35 rail, 6 mm wide

WAGO order no. 249-117 End stop for DIN 35 rail, 10 mm wide

5.2 Overall Configuration

The maximum total length of a fieldbus node without fieldbus coupler/controller is 780 mm including end module. The width of the end module is 12 mm. When assembled, the I/O modules have a maximum length of 768 mm.

Examples:

- 64 I/O modules with a 12 mm width can be connected to a fieldbus coupler/controller.
- 32 I/O modules with a 24 mm width can be connected to a fieldbus coupler/controller.

Exception:

The number of connected I/O modules also depends on the type of fieldbus coupler/controller is used. For example, the maximum number of stackable I/O modules on one PROFIBUS DP/V1 fieldbus coupler/controller is 63 with no passive I/O modules and end module.

NOTICE

Observe maximum total length of a fieldbus node!

The maximum total length of a fieldbus node without fieldbus coupler/controller and without using a 750-628 I/O Module (coupler module for internal data bus extension) may not exceed 780 mm.

Also note the limitations of individual fieldbus couplers/controllers.



Note

Increase the total length using a coupler module for internal data bus extension!

You can increase the total length of a fieldbus node by using a 750-628 I/O Module (coupler module for internal data bus extension). For such a configuration, attach a 750-627 I/O Module (end module for internal data bus extension) after the last I/O module of a module assembly. Use an RJ-45 patch cable to connect the I/O module to the coupler module for internal data bus extension of another module block.

This allows you to segment a fieldbus node into a maximum of 11 blocks with maximum of 10 I/O modules for internal data bus extension.

The maximum cable length between two blocks is five meters.

More information is available in the manuals for the 750-627 and 750-628 I/O Modules.

5.3 Mounting onto Carrier Rail

5.3.1 Carrier Rail Properties

All system components can be snapped directly onto a carrier rail in accordance with the European standard EN 50022 (DIN 35).

NOTICE

Do not use any third-party carrier rails without approval by WAGO!

WAGO Kontakttechnik GmbH & Co. KG supplies standardized carrier rails that are optimal for use with the I/O system. If other carrier rails are used, then a technical inspection and approval of the rail by WAGO Kontakttechnik GmbH & Co. KG should take place.

Carrier rails have different mechanical and electrical properties. For the optimal system setup on a carrier rail, certain guidelines must be observed:

- The material must be non-corrosive.
- Most components have a contact to the carrier rail to ground electro-magnetic disturbances. In order to avoid corrosion, this tin-plated carrier rail contact must not form a galvanic cell with the material of the carrier rail which generates a differential voltage above 0.5 V (saline solution of 0.3 % at 20°C).
- The carrier rail must optimally support the EMC measures integrated into the system and the shielding of the I/O module connections.
- A sufficiently stable carrier rail should be selected and, if necessary, several mounting points (every 20 cm) should be used in order to prevent bending and twisting (torsion).
- The geometry of the carrier rail must not be altered in order to secure the safe hold of the components. In particular, when shortening or mounting the carrier rail, it must not be crushed or bent.
- The base of the I/O components extends into the profile of the carrier rail. For carrier rails with a height of 7.5 mm, mounting points are to be riveted under the node in the carrier rail (slotted head captive screws or blind rivets).
- The medal springs on the bottom of the housing must have low-impedance contact with the DIN rail (wide contact surface is possible).

5.3.2 WAGO DIN Rail

WAGO carrier rails meet the electrical and mechanical requirements shown in the table below.

Table 30: WAGO DIN Rail

Order number	Description
210-113 /-112	35 x 7.5; 1 mm; steel yellow chromated; slotted/unslotted
210-114 /-197	35 x 15; 1.5 mm; steel yellow chromated; slotted/unslotted
210-118	35 x 15; 2.3 mm; steel yellow chromated; unslotted
210-198	35 x 15; 2.3 mm; copper; unslotted
210-196	35 x 7.5; 1 mm; aluminum; unslotted

5.4 Spacing

The spacing between adjacent components, cable conduits, casing and frame sides must be maintained for the complete fieldbus node.




Figure 21: Spacing

The spacing creates room for heat transfer, installation or wiring. The spacing to cable conduits also prevents conducted electromagnetic interferences from influencing the operation.

5.5 Mounting Sequence

Fieldbus couplers/controllers and I/O modules of the WAGO-I/O-SYSTEM 750 are snapped directly on a carrier rail in accordance with the European standard EN 50022 (DIN 35).

The reliable positioning and connection is made using a tongue and groove system. Due to the automatic locking, the individual devices are securely seated on the rail after installation.

Starting with the fieldbus coupler/controller, the I/O modules are mounted adjacent to each other according to the project design. Errors in the design of the node in terms of the potential groups (connection via the power contacts) are recognized, as the I/O modules with power contacts (blade contacts) cannot be linked to I/O modules with fewer power contacts.

CAUTION

Risk of injury due to sharp-edged blade contacts!

The blade contacts are sharp-edged. Handle the I/O module carefully to prevent injury.

NOTICE

Insert I/O modules only from the proper direction!

All I/O modules feature grooves for power jumper contacts on the right side. For some I/O modules, the grooves are closed on the top. Therefore, I/O modules featuring a power jumper contact on the left side cannot be snapped from the top. This mechanical coding helps to avoid configuration errors, which may destroy the I/O modules. Therefore, insert I/O modules only from the right and from the top.

Note



Don't forget the bus end module!

Always plug a bus end module 750-600 onto the end of the fieldbus node! You must always use a bus end module at all fieldbus nodes with WAGO-I/O-SYSTEM 750 fieldbus couplers/controllers to guarantee proper data transfer.

5.6 Inserting Devices

NOTICE

Perform work on devices only if they are de-energized!

Working on energized devices can damage them. Therefore, turn off the power supply before working on the devices.

5.6.1 Inserting the Fieldbus Coupler/Controller

1. When replacing the fieldbus coupler/controller for an already available fieldbus coupler/controller, position the new fieldbus coupler/controller so that the tongue and groove joints to the subsequent I/O module are engaged.
2. Snap the fieldbus coupler/controller onto the carrier rail.
3. Use a screwdriver blade to turn the locking disc until the nose of the locking disc engages behind the carrier rail (see the following figure). This prevents the fieldbus coupler/controller from canting on the carrier rail.

With the fieldbus coupler/controller snapped in place, the electrical connections for the data contacts and power contacts (if any) to the possible subsequent I/O module are established.




Figure 22: Release Tab of Controller

5.6.2 Inserting the I/O Module

1. Position the I/O module so that the tongue and groove joints to the fieldbus coupler/controller or to the previous or possibly subsequent I/O module are engaged.




Figure 23: Insert I/O Module (Example)

2. Press the I/O module into the assembly until the I/O module snaps into the carrier rail.




Figure 24: Snap the I/O Module into Place (Example)

With the I/O module snapped in place, the electrical connections for the data contacts and power jumper contacts (if any) to the fieldbus coupler/controller or to the previous or possibly subsequent I/O module are established.

6 Connect Devices

6.1 Connecting a Conductor to the CAGE CLAMP®

The WAGO CAGE CLAMP® connection is appropriate for solid, stranded and finely stranded conductors.

Note



Only connect one conductor to each CAGE CLAMP®!
Only one conductor may be connected to each CAGE CLAMP®.
Do not connect more than one conductor at one single connection!

If more than one conductor must be routed to one connection, these must be connected in an up-circuit wiring assembly, for example using WAGO feed-through terminals.

Exception:

If it is unavoidable to jointly connect 2 conductors, then you must use a ferrule to join the wires together. The following ferrules can be used:

Length:	8 mm
Nominal cross section _{max.} :	1 mm ² for 2 conductors with 0.5 mm ² each
WAGO product:	216-103 or products with comparable properties

1. For opening the CAGE CLAMP® insert the actuating tool into the opening above the connection.
2. Insert the conductor into the corresponding connection opening.
3. For closing the CAGE CLAMP® simply remove the tool. The conductor is now clamped firmly in place.




Figure 25: Connecting a Conductor to a CAGE CLAMP®

6.2 Power Supply Concept

6.2.1 Supplementary Power Supply Regulations

The WAGO-I/O-SYSTEM 750 can also be used in shipbuilding or offshore and onshore areas of work (e. g. working platforms, loading plants). This is demonstrated by complying with the standards of influential classification companies such as Germanischer Lloyd and Lloyds Register.

Filter modules for 24 V supply are required for the certified operation of the system.

Table 31: Filter Modules for 24 V Supply

Order No.	Name	Description
750-626	Supply Filter	Filter module for system supply and field supply (24 V, 0 V), i. e. for fieldbus coupler/controller and bus power supply (750-613)
750-624	Supply Filter	Filter module for the 24 V field supply (750-602, 750-601, 750-610)

Therefore, the following power supply concept must be absolutely complied with.




Figure 26: Power Supply Concept



Note

Use a supply module for equipotential bonding!

Use an additional 750-601/ 602/ 610 Supply Module behind the 750-626 Filter Module if you want to use the lower power jumper contact for equipotential bonding, e.g., between shielded connections and require an additional tap for this potential.

7 Commissioning

7.1 Switching On the Controller

Before switching on the controller ensure that you

- have properly installed the controller (see section “Installation”),
- have connected all required data cables (see section “Connections”) to the corresponding interfaces and have secured the connectors by their attached locking screws,
- have connected the electronics and field-side power supply (see section “Connections”),
- have mounted the end module (750-600) (see Section “Installation”),
- have performed appropriate potential equalization at your machine/system (see System Description for 750-xxx) and
- have performed shielding properly (see System Description for 750-xxx).

To switch on both the controller and the connected I/O modules, switch on your power supply unit.

Starting of the controller is indicated by a brief green flashing of all LEDs. After a few seconds the SYS LED will signal successful boot-up of the controller. The CODESYS 2.3 runtime system is started simultaneously.

Once the entire system has been successfully started, the SYS and I/O LEDs light up green.

If there is no executable IEC-61131-3 program stored on the controller, or if the RUN/STOP switch is set to STOP, the RUN LED will light up red.

7.2 Determining the IP Address of the Host PC

To ensure that the host PC can communicate with the controller via ETHERNET, both devices must be located in the same subnet.

To determine the IP address of the host PC (with the Microsoft Windows[®] operating system) using the MS DOS prompt, proceed as follows:

1. Open the MS DOS prompt window.
To do this, enter the command “cmd” in the input field under **Start > Execute... > Open:** (Windows[®] XP) or **Start > Search programs/files** (Windows[®] 7) and then click **[OK]** or press **[Enter]**.
2. In the MS DOS prompt enter the command “ipconfig” and then press **[Enter]**.
3. The IP address, subnet mask and standard gateway, including the appropriate parameters, are displayed.

7.3 Setting an IP Address

In the controller's initial state the following IP addresses are active for the ETHERNET interface (Port X1 and Port X2):

Table 32: Default IP Addresses for ETHERNET Interfaces

Ethernet interface	Default setting
X1/X2	Dynamic assignment of IP address using “Dynamic Host Configuration Protocol” (DHCP)

Adapt IP addressing for your specific system structure to ensure that the PC and the controller can communicate with one another using one of the available configuration tools (WBM, “WAGO Ethernet Settings”, CBM) (see section “Configuration”).

Example for incorporating the controller (192.168.2.17) into an existing network:

If the IP address of your host PC is 192.168.1.2, for example, then the controller must be on the same subnet. That is, with the net mask **255.255.255.0**, the first three digits of the controller must match those of your PC. This yields the following address range for the controller:

Table 33: Network Mask 255.255.255.0


Host PC	Subnet address range for the controller
192.168.1.2	192.168.1.3 ... 192.168.1.254

7.3.1 Assigning an IP Address using DHCP

The PFC200 can obtain dynamic IP addresses from a server (DHCP/BootP). In contrast to fixed IP addresses, dynamically assigned addresses are not stored permanently. Therefore, a BootP or DHCP server must be available each time the controller is restarted.

If an IP address has been assigned by means of DHCP (default setting), it can be determined through the settings and the output of the specific DHCP server.

In the example figure shown here, the corresponding output of “Open DHCP” is presented.

A screenshot of a terminal window titled "Run Stand Alone". The window displays the output of the "Open DHCP" command. The text in the terminal is as follows:

```
Open DHCP Server Version 1.56 Windows Build 1033
Starting DHCP...
DHCP Range: 192.168.2.200-192.168.2.220/255.255.255.0
Server Name:
Detecting Static Interfaces..
Lease Status URL: http://127.0.0.1:6789
Listening On: 192.168.2.20
DHCPDISCOVER for 00:30:de:ff:00:5a <PFC200-FF005A> from interface 192.168.2.20 received
Host 00:30:de:ff:00:5a <PFC200-FF005A> offered 192.168.2.200
DHCPREQUEST for 00:30:de:ff:00:5a <PFC200-FF005A> from interface 192.168.2.20 received
Host 00:30:de:ff:00:5a <PFC200-FF005A> allotted 192.168.2.200 for 10 seconds
```

Figure 27: “Open DHCP”, example figure

In conjunction with the DNS server associated with DHCP, the device can be reached using its host name.

This name consists of the prefix “PFC200-“ and the last six places of the MAC address (in the example shown here: “00:30:DE:FF:00:5A”). The MAC address of the device can be printed on the label on the side of the device.

The host name of the device in the example shown here is thus “PFC200-FF005A”.

7.3.2 Changing an IP Address using the “CBM” Configuration Tool via the Serial Interface

Using the “CBM” configuration tool accessible on the Linux[®] console, you can assign, among other things, a new IP address to the ETHERNET interfaces X1 and X2. More information about “CBM” is given in the Section “Configuration”.

Preparation:

Link a PC to the X3 serial interface using a terminal program.

1. Start the configuration tool by entering the command “cbm” on the command line and then press **[Enter]**.

```
=====
WAGO Console Based Management Tool
=====
Main Menu
-----
0. Quit
1. Information
2. CODESYS
3. Networking
4. Clock
5. Administration
6. Package Server
7. Mass Storage
8. Downloads
9. Ports and Services
10. SNMP
-----
Select an entry or Q to quit
=====
```

Figure 28: CBM starting screen

2. In the **Main menu** use the keyboard (arrow keys or numeric keypad) to move to and select **Networking** and then press **[Enter]**.

```
=====
WAGO Console Based Management Tool
=====
Main Menu
-----
0. Quit
1. Information
2. CODESYS
3. Networking
4. Clock
5. Administration
6. Package Server
7. Mass Storage
8. Downloads
9. Ports and Services
10. SNMP
-----
Select an entry or Q to quit
=====
```

Figure 29: CBM – Selecting “Networking”

3. In the **Networking** menu select **TCP/IP** and press **[Enter]**.

```
=====
WAGO Console Based Management Tool
=====
Networking
-----
0. Back to Main Menu
1. Host-/Domain Name
2. TCP/IP
3. Ethernet
-----
Select an entry or Q to quit
-----
█
```

Figure 30: CBM – Selecting “TCP/IP”

4. In the menu **TCP/IP** select **IP Address** and press **[Enter]**.

```
=====
WAGO Console Based Management Tool
=====
TCP/IP
-----
0. Back to Networking Menu
1. IP Address
2. Default Gateway
3. DNS Server
-----
Select an entry or Q to quit
-----
█
```

Figure 31: CBM – Selecting “IP address”

5. In the menu **TCP/IP Configuration** select **IP Address** and press **[Enter]**.

```

=====
WAGO Console Based Management Tool
=====
TCP/IP Configuration
-----
0. Back to TCP/IP Menu
1. Type of IP Address Configuration...Static IP
2. IP Address.....192.168.1.17
3. Subnet Mask.....255.255.255.0
-----
Select an entry or Q to quit
█

```

Figure 32: CBM – Selecting the IP address

6. In the menu **Change IP Address** enter the new IP address and confirm by clicking **[OK]**. If you want to return to the main menu without making changes, click **[Abort]**.

```

=====
WAGO Console Based Management Tool
=====
Change IP Address
-----
Enter new IP Address:
+-----+
| 192.168.1.17 |
+-----+
< OK >   <Abort>
-----
OK: confirm value, Abort: quit without changes
-----

```

Figure 33: CBM – Entering a new IP address

7.3.3 Changing an IP Address using “WAGO Ethernet Settings”

The Microsoft Windows® application “WAGO Ethernet Settings” is a software used to identify the controller and configure network settings.

Note



Observe the software version!

To configure the controller use at least Version 5.4.2.3 dated July 20, 2013 in “WAGO Ethernet Settings”!

You can use WAGO communication cables or WAGO radio adapters or even the IP network for data communication.

1. Switch off the power supply to the controller.
2. Connect the 750-920 communication cable to the Service interface on the controller and to a serial interface of your PC.
3. Switch the power supply to the controller on again.
4. Start the “WAGO Ethernet Settings” program.




Figure 34: "WAGO Ethernet Settings" – Starting screen

5. Click **[Identify]** to read in and identify the connected PFC200.
6. Select the “Network” tab:




Figure 35: “WAGO Ethernet Settings” – “Network” tab

7. To assign a fixed address, select “Static configuration” on the “Source” line under “Input”. DHCP is normally activated as the default setting.
8. In the column “Input” enter the required IP address and, if applicable, the address of the subnet mask and of the gateway.
9. Click on **[Write]** to accept the address in the PFC200. (When you click the **[Write]** button “WAGO Ethernet Settings” will automatically restart your controller. This action therefore requires about 30 seconds.)
10. You can now close “WAGO Ethernet Settings”, or make other changes directly in the Web-based Management system as required. To do this, click on **[WBM]** at the right in the window.

7.4 Testing the Network Connection

Carry out a ping network function to check whether you can reach the controller at the IP address you have assigned in the network.

1. Open the MS DOS prompt window.
To do this, enter the command “cmd” in the input field under **Start > Execute... > Open:** (Windows® XP) or **Start > Search programs/files** (Windows® 7) and then click **[OK]** or press **[Enter]**.
2. In the MS DOS window, enter the command “ping” and the IP address of the controller (for example, ping 192.168.1.17) and then press **[Enter]**.

Note



Host entries in the ARP table!

It may also be useful to delete the current host entries in the ARP table with the command “arp -d *” before executing the “ping” command (as administrator in Windows® 7). This ensures that older entries will not impair the success of the “ping” command.

3. Your PC sends out a query that is answered by the controller. This reply appears in the MS DOS prompt window. If the error message “Timeout” appears, the controller has not responded properly. You then need to check your network settings.

```
C:\WINDOWS\system32\cmd.exe
U:\>ping 192.168.1.17

Ping wird ausgeführt für 192.168.1.17 mit 32 Bytes Daten:

Antwort von 192.168.1.17: Bytes=32 Zeit=1ms TTL=64
Antwort von 192.168.1.17: Bytes=32 Zeit<1ms TTL=64
Antwort von 192.168.1.17: Bytes=32 Zeit<1ms TTL=64
Antwort von 192.168.1.17: Bytes=32 Zeit<1ms TTL=64

Ping-Statistik für 192.168.1.17:
    Pakete: Gesendet = 4, Empfangen = 4, Verloren = 0 (0% Verlust),
    Ca. Zeitangaben in Millisek.:
        Minimum = 0ms, Maximum = 1ms, Mittelwert = 0ms

U:\>_
```

Figure 36: Example of a function test

4. If the test is completed successfully, close the MS DOS window.

7.5 Shutdown/Restart

Switch off the power supply to shut down the controller.

To perform a controller restart press and hold the Reset ALL button for more than 7 seconds until all of the LEDs go out.

The controller then performs a restart.

As an alternative, you can switch off the controller and switch it back on again.

A controller restart is signaled by all LEDs briefly lighting up green.

7.6 Initiating Reset Functions

You can initiate various reset functions using the mode selector switch and the Reset button (RST).

7.6.1 Warm Start Reset

The CODESYS 2 application is reset on a warm start reset. This corresponds to the CODESYS 2 IDE command “Reset”.

To perform a warm start reset, set the mode selector switch to "Reset" and hold it there for two to seven seconds.

Execution of the reset is signaled by the red “RUN LED” briefly going out when the mode selector switch is released.

7.6.2 Cold Start Reset

On a cold start reset the CODESYS 2 application is reset and the memory containing the retain variables is cleared.

This corresponds to the CODESYS 2 IDE command “Reset (Cold)”.

To perform a cold start reset, set the mode selector switch to “Reset” and hold it there for more than seven seconds.

Execution of the reset is signaled after seven seconds by the “RUN” LED going out for an extended period. You can then release the mode selector switch.

7.6.3 Software Reset

The controller is restarted on a software reset.

To perform a software reset, set the mode selector switch to RUN or STOP and then press the Reset button (RST) for one to eight seconds.

All LEDs will light up briefly in green to signal reset completion.

7.6.4 Setting a Fixed IP Address

This procedure sets the IP address for the X1 interfaces to the fixed address “192.168.1.17”.

When the switch is enabled, the fixed address is also used for interface X2.

When the switch is disabled, the original address setting for interface X2 is not changed.

No reset is performed.

To make this setting, set the mode selector switch to STOP and press and hold the Reset button (RST) for longer than eight seconds.

Execution of the setting is signaled by the “SYS” LED flashing orange.

To cancel this setting, perform a software reset or switch off the controller and then switch it back on.

7.6.5 Factory Reset

A factory reset restores the device to its initial state on delivery. The controller is then restarted.

Note



Any subsequently installed firmware functions are overwritten!

Firmware functions installed after initial controller startup are overwritten by a factory reset, and the firmware is reset to the version marked on the device. After factory reset, some of the functions described in this manual may no longer be available.

To restore the current operating status, you will need:

- a backup of the currently programmed application,
- the currently installed firmware,
- the manual's version that is applicable to the factory settings.

If you have any questions, feel free to contact our WAGO Support.

To perform a factory reset, set the mode selector switch to “RESET” and press the Reset button (RST) for 1 ... 8 seconds. Briefly release the Reset button (RST) (< 1 second) and press it again until the “CAN” LED lights up red. If the “CAN” LED lights up red, release the mode selector switch and the Reset button. After the first 1 ... 8 seconds, the controller reboots (all LEDs light up orange) and after another 3 seconds, the “Factory reset” process begins. The process is indicated by all LEDs lighting up red in succession.

Alternatively, you can also initiate a factory reset when you switch on the controller. Hold the mode selector switch at “RESET” for at least 3 seconds when you switch on the controller and hold the Reset button (RST) down until the “CAN” LED lights up red. If the “CAN” LED lights up red, release the mode selector switch and the Reset button.

Note



Do not interrupt the reset process!

If you release the Reset button (RST) too soon (after the Reset process), the controller switches to production mode (indicated by a green “CAN” LED). If this happens, switch the controller off and then back on again.

Note



Do not switch off!

Do not interrupt, i.e., switch off the controller, during the factory reset process! In other words, do not switch off the controller while this process is in progress!

7.7 Users and Passwords

Several groups of users are provided in the controller which can be used for various services.

Standard passwords are set for all users. We strongly recommend changing these passwords on startup!

Note



Change passwords

Standard passwords are documented in these instructions and therefore do not offer adequate protection! Change the passwords to meet your particular needs.

7.7.1 Services and Users

All password-protected services and their associated users are listed in the following table.

Service	WBM		Linux [®]			SNMP user
	admin	user	root	admin	user	
Web Based Management (WBM)	X	X				
Linux [®] console			X	X	X	
Console Based Management (CBM)			X	X		
CODESYS				X		
Telnet			X	X	X	
FTP			X	X	X	
FTPS			X	X	X	
SSH			X	X	X	
SNMP						X

7.7.2 WBM Group

WBM has its own user administration system. The users in this system are isolated from the other user groups in the system for security reasons.

Detailed information about this is given in the Section “WBM User Administration”.

Table 34: WBM Users

Users	Permissions	Default Password
admin	All (administrator)	wago
user	Supported to a limited extent:	user
guest	Display only	---

7.7.3 Linux User Group

The Linux[®] users group include the actual users of the operating system, which is likewise used by most services.

The passwords for these users must be configured through a terminal connection via SSH/RS-232.

Table 35: Linux[®] Users

User	Special Feature	Home Directory	Default Password
root	Super user	/root	wago
admin	CODESYS user	/home/admin	wago
user	Normal user	/home/user	user

7.7.4 SNMP User Group

The SNMP service manages its own users. In its initial state, no users are stored in the system.

7.8 Configuration

The following methods are available for configuring the PFC200:

- Access to the Web-based management system via the PC using an Internet browser (“Configuration using Web-Based Management (WBM)”)
- Access to the “Console-Based Management” system (CBM) via the PC using a terminal program (via ETHERNET and/or RS-232 interface) (“Configuration using a Terminal Program”)
- Access via the CODESYS PLC program using the WagoConfigToolLIB.lib library (“Appendix” > “WagoConfigToolLIB.lib”)
- Access via the PC using “WAGO Ethernet Settings” (“Configuration using 'WAGO Ethernet Settings'”).

The CBM basically provides the same parameters for configuration of the PFC200 as the WBM, except for parameters which cannot be represented in a useful manner in a terminal window.

For an explanation of these parameters refer to the sections starting at “Information' Page”.

7.8.1 Configuration using Web-Based Management (WBM)

The implemented HTML pages (from here on referred to as “pages”) for Web-Based Management configure the PFC200. Proceed as follows for access the WBM using an Internet browser:

1. Connect the PFC200 to the ETHERNET network via the ETHERNET interface X1.
2. To access the pages, enter the controller's IP address in the address line of your browser followed by “/wbm”, e.g., “http://192.168.1.17/wbm”. Note that the PC and the PFC200 must be located within the same subnet (see Section “Setting an IP Address”). If you do not know the IP address and cannot determine it, switch the controller to the pre-set address “192.168.1.17” using the “Fixed IP address” function (see Section “Initiate Reset Functions” > “Set Fixed IP Address”).

If you have installed a DHCP server on your PC and would like to access WBM through DHCP, use the other interface. You can find detailed information about this in the section “Assigning an IP Address Using DHCP”.

Note



Displaying the PFC200 Start Page

If the PFC200 does not display the start page, ensure that your Internet browser settings permit bypassing the proxy server for local addresses. Also check whether your PC is located in the same subnet as the PFC200.

Note



Take usage by the CODESYS program into account

If the PFC200 is at capacity due to a CODESYS program, this may result in slower processing in the WBM. As a result, timeout errors are sometimes reported under some circumstances. It is therefore important to stop the CODESYS application prior to performing complicated configuration using WBM.

Some pages of the WBM are password protected. The first time you select an item from the navigation bar, the password query appears:




Figure 37: Entering authentication

7.8.1.1 WBM User Administration

To allow settings to be made only by a select number of users, limit access to WBM functions through User Administration.



Note

Change passwords

Standard passwords are documented in these instructions and therefore do not offer adequate protection. Change the passwords to meet your particular needs, see Section “Administration - Users' Page”.

If you do not change the passwords, a warning is displayed on every requested web page after logging in.




Figure 38: Password reminder

Table 36: User Settings in the Initial State

Users	Password
user	user
admin	wago



Note

Observe access rights

Users in WBM are authorized exclusively for access to Web pages. User administration for controller applications is configured separately.

Access to the WBM pages is as follows:

Table 37: Access Rights for WBM Pages

Navigation	WBM page	User
Information	Status Information	---
CODESYS		
– Information	CODESYS Information	---
– General Configuration	CODESYS Configuration	user, admin
– WebVisu	CODESYS WebVisu	---
Networking		
– Host/Domain Name	Configuration of Network Parameters	user, admin
– TCP/IP	TCP/IP Configuration	user, admin
– Ethernet	Configuration of Ethernet Parameters	user, admin
Clock	Configuration of Date and Time	user, admin
Administration		
– Users	Configuration of the users for the Web-based Management	admin
– Create Image	Create bootable Image	admin
– Serial Interface	Configuration of Serial Interface RS233	admin
– Reboot	Reboot Controller	admin
Package Server		
– Firmware Backup	Firmware Backup	admin
– Firmware Restore	Firmware Restore	admin
– System Partition	System Partition	admin
Mass Storage	Mass Storage	admin
Software Uploads	Software Uploads	admin
Ports and Services		
– Network Services	Configuration of Network Services	user, admin
– NTP Client	Configuration of NTP Client	user, admin
– CODESYS Services	Configuration of the CODESYS Services	user, admin
– SSH	SSH Client Settings	user, admin
– TFTP	TFTP Server	user, admin
SNMP		
– General Configuration	Configuration of SNMP parameter	admin
– v1/v2c	Configuration of SNMP parameter	admin
– v3	Configuration of SNMP v3 Users	admin
Diagnostic	Diagnostic Information	---

7.8.1.2 General Information about the Page




Figure 39: WBM browser window (example)

The device name is displayed in the header of the browser window.

The navigation tree is shown at the left edge of the browser window. You can use this navigation tree to go to the individual pages and, where provided, subpages included in these pages.

A status area with the following elements is displayed at the right edge:




Figure 40: WBM status information (example)

- **WBM status:**
Here, you can recognize whether the WBM is currently communicating with the device in the background, i.e., one or more queries have been sent and the browser is waiting on a response. Movement is then visible in the graphic. This occurs when data are read on initial call-up of the page, when

the user has sent off a change form or when data is reloaded automatically in cycles, e.g., the contents of the status area.

- Local Time:
Local time on the device
- Local Date:
Local date on the device
- PLC Switch:
Setting of the mode selector switch
- LEDs:
Here, the the status of the device LEDs is indicated. All of the LEDs are symbolized by a diagram and are labeled with their particular designation (e.g., SYS, RUN, etc.). The following colors may be used:

- gray:
LED is off

- full color (green, red, yellow, orange):
The LED is activated in the particular color

- half color:
The LED is flashing in the corresponding color. The other half of the surface is then either gray or also colored. The latter case indicates that the LED is flashing sequentially in different colors.

A tool tip containing more detailed information opens as long as the cursor is positioned over an LED. The text that is displayed also contains the message that put the LED into its current status. The time of the message is also shown.

The statuses displayed in the WBM will not always correspond at the precise time to those on the PFC200. Data has a runtime during transmission and can only be queried at a certain interval. The time period between two queries is 30 seconds.

The contents of the individual pages and sub-pages are explained in the following sections.

7.8.1.3 “Status Information” Page

The following tables explain the parameters listed on this page:

7.8.1.3.1 “Controller Details” Group

Table 38: WBM “Status Information” page – “Controller Details” group

Parameters	Explanation
Product Description	Controller identification
Order Number	Item number of the controller
License Information	Notification that the CODESYS runtime system is available
Firmware Revision	Firmware status

7.8.1.3.2 “Network Details (Xn)” Group(s)

If the switch is enabled, one group (“Network Details”) is shown for both connections.

If the switch is disabled, one group (“Network Details X1” / “Network Details X2”) is shown for each connection.

Table 39: WBM “Status Information” page – “Network Details (Xn)” group(s)

Parameters	Explanation
State	Status of the ETHERNET interface (enabled/disabled)
Mac Address	MAC address identifies and addresses the controller
IP Address	Current IP address of the controller
Subnet Mask	Current subnet mask of the controller

7.8.1.4 “CODESYS Configuration” Page

The settings for the boot project created in CODESYS are shown on the “CODESYS Configuration” page.

7.8.1.4.1 “General Configuration” Group

Table 40: WBM “CODESYS Configuration” page – “General Configuration” group

Display Fields	Explanation	
CODESYS Version	Select which CODESYS version you want to activate.	
	None	CODESYS is not active.
	2	CODESYS version 2 is active.
(Boot Device)	Select the storage medium the boot project will be stored on.	
	Memory Card	The boot project is stored on the memory card.
	Internal Flash	The boot project is stored in the internal flash memory.

Note



“Internal Flash” is not always available!

The boot project can only be stored in the internal flash memory when the operating system has been started from the internal flash.

If the operating system has been started from the memory card, the “Internal Flash” option is not available.

Click [**Submit**] to apply change. The change is effective immediately.

Note



Restart the controller after changing this setting!

Restart the controller after changing the setting to ensure that any files still open are switched over correctly.

7.8.1.5 “CODESYS Information” Page

All information about the PLC program created in CODESYS is provided on the “CODESYS Information” page.

7.8.1.5.1 “CODESYS” Group

Table 41: WBM “CODESYS – Information” page – “CODESYS” group

Display Fields	Explanation	
Version	The version of the CODESYS runtime system currently active is shown (if the runtime system is disabled, “None” is displayed and the subsequent fields of this group are disabled).	
Version Number	The version number of the CODESYS Web server is shown. This field is only visible when CODESYS is enabled.	
CODESYS State	The operating status of CODESYS is shown. This field is only visible when CODESYS is enabled.	
	STOP	PLC program is not executed.
	RUN	PLC program is executed.
Number of Tasks	The number of tasks in the CODESYS program is shown. This field is only visible when CODESYS is enabled.	

7.8.1.5.2 “Project Details” Group

Table 42: WBM “CODESYS Information” page – “Project Details” group

Display Fields	Explanation
Date	Display of project information that the programmer entered in the PLC program (in CODESYS under Project > Project Information...).
Title	
Version	
Author	
Description	
	The information only appears in an executed PLC program.
	Descriptive texts up to 1024 characters long are given under “Description.”

7.8.1.5.3 "Task n" Group(s)

One dedicated group is displayed for each task when the PLC program is executed. As a rule, only the group title is displayed with the task number, the task name and the task ID.

Click [+] to expand the group and display the following information.

Table 43: WBM “CODESYS Information” page – “Task n” group(s)

Display Field	Explanation
Cycle count	Number of task cycles since system start
Cycle time (µsec)	Currently measured task cycle time
Cycle time min (µsec)	Minimum task cycle time since system start
Cycle time max (µsec)	Maximum task cycle time since system start
Cycle time avg (µsec)	Average task cycle time since system start
Status	Task status (e.g., RUN, STOP)
Mode	Task execution mode (e.g., in cycles)
Priority	Set task priority
Interval (msec)	Set task interval

To hide this information, click [-].

7.8.1.6 “CODESYS WebVisu” Page

The settings for the Web visualization created in CODESYS are shown on the “CODESYS WebVisu” page.

7.8.1.6.1 “Webserver Configuration” Group

Table 44: WBM “CODESYS WebVisu” page – “Webserver Configuration” group

Display Fields	Explanation	
CODESYS Webserver State	The status (enabled/disabled) of the CODESYS Web server is displayed here.	
Default Webserver	Choose whether the Web-based Management or CODESYS Web visualization should be displayed when only entering the IP address of the controller.	
	Web-based Management	The Web-based Management is displayed.
	CODESYS WebVisu	The CODESYS Web visualization is displayed.

Click [**Submit**] to apply change. The change is effective immediately.

In its default setting, the WBM is called up when only entering the IP address.

To update the display after switching, enter the IP address again in the address line of the Web browser.

To display the Web visualization, the CODESYS Web server must be enabled (in WBM under “Ports and Services” -> “CODESYS Services”) and there must be a suitably configured CODESYS application.

Regardless of the default Web browser setting, the WBM can be called up at any time with “http://<IP address>/wbm” and the Web visualization with “http://<IP address>/webvisu”.

You can obtain additional information on CODESYS Web visualization in the chapter with the same name.

Note



Possible error messages when calling up the Web visualization

The “500 – Internal Server Error” message indicates that the CODESYS Web server is not enabled.

A page with the header “WebVisu not available” means that no CODESYS application has been loaded in the controller using Web visualization.

7.8.1.7 “Configuration of Network Parameters” Page

The settings for the general TCP/IP parameters are found on the “Configuration of Network Parameters” page.

7.8.1.7.1 “Hostname” Group

Table 45: WBM “Configuration of Network Parameters” page – “Hostname” group

Parameters	Explanation
Currently used	If you have selected dynamic assignment of an IP address via DHCP, the name of the host currently being used is displayed.
Configured	Enter the host name of the PC that will be used after a controller restart.

Click [**Submit**] to apply the change. The change becomes effective after the next controller reboot.

7.8.1.7.2 “Domain Name” Group

Table 46: WBM “Configuration of Network Parameters” page – “Domain Name” group

Parameters	Explanation
Domain Name	Set the domain name here.

Click [**Submit**] to apply change. The change is effective immediately.

7.8.1.8 “TCP/IP Configuration” Page

The TCP/IP settings for the ETHERNET interfaces are shown on the “TCP/IP configuration” page.

7.8.1.8.1 “Switch Configuration” Group

Table 47: WBM “TCP/IP Configuration” page – “Switch Configuration” group

Parameters	Explanation	
Interfaces	Enable or disable the switch.	
	Switched	Both interfaces are operated with one IP address.
	Separated	Each interface is operated with its own IP address.

Click [**Submit**] to apply change. The change is effective immediately.

7.8.1.8.2 “IP Address (Xn)” Group(s)

If the switch is enabled, one group (“IP Address”) is shown for both connections. If the switch is disabled, one group (“IP Address X1” / “IP Address X2”) is shown for each connection.

Table 48: WBM “TCP/IP Configuration” page – “IP Address (Xn)” group(s)

Parameters	Explanation	
Configuration Type	Select a static or dynamic IP address.	
	Static IP	Static IP addressing
	DHCP	Dynamic IP addressing
	BootP	Dynamic IP addressing
IP Address	Here, enter a static IP address. This is active if “Static IP” is activated in the Configuration Type field.	
Subnet Mask	Enter the subnet mask here. This is active if “Static IP” is activated in the Configuration Type field.	

Click [**Submit**] to apply changes. The change is effective immediately.

7.8.1.8.3 “Default Gateway” Group

Table 49: WBM “TCP/IP Configuration” page – “Default Gateway” group

Parameters	Explanation	
State This field is only visible when the switch is enabled.	Specify if you will use the standard gateway. The controller uses the standard gateway when the target address is located outside of its own network.	
	Disabled	The standard gateway is not used.
	Enabled	The standard gateway is used.
Interface This field is only visible when the switch is disabled.	Choose which connection you will use for the standard gateway. The controller uses the standard gateway when the target address is located outside of its own network.	
	None	The standard gateway is not used.
	X1	The standard gateway is used for connection X1.
	X2	The standard gateway is used for connection X2.
Gateway	Enter the address of the standard gateway here.	

Note



Set a maximum of one standard gateway!

If the standard gateway is specified via the DHCP server, a maximum of one standard gateway can be set in “Separated” mode for all combinations (“DHCP”/“Static”, “DHCP”/“DHCP”, etc.).

Click [**Submit**] to apply change. The change is effective immediately.

7.8.1.8.4 “DNS Server” Group

Table 50: WBM “TCP/IP Configuration” page – “DNS Server” group

Parameters	Explanation
DNS Server 1, 2, ...	The addresses of the defined DNS servers are displayed here. If no server has been defined, “Configured: None” is displayed.
New server IP	Add additional DNS addresses here.

Click [**Delete**] to remove the selected DNS server. The change is effective immediately.

Click [**Add**] to add the entered DNS server. The change is effective immediately.

7.8.1.9 “Configuration of ETHERNET Parameters” Page

The ETHERNET TCP/IP settings are shown on the “Configuration of ETHERNET” page.

7.8.1.9.1 “Interface Xn” Groups

One group (“Interface X1” / “Interface X2”) is displayed for each connection.

Table 51: WBM “Configuration of ETHERNET Parameters” page – “Interface Xn” groups

Parameters	Explanation	
Enabled	You can enable or disable the interface.	
Autonegotiation on	When Autonegotiation is activated, the connection modalities are negotiated automatically with the peer devices.	
Speed/Duplex	Select the transmission speed and the duplex method:	
	10 Mbit half-duplex	Information can only be sent or received.
	100 Mbit half-duplex	
	10 MBit full-duplex	Information can be sent and received simultaneously.
100 Mbit full-duplex		

Click [**Submit**] to apply changes. The change is effective immediately.

7.8.1.10 “Configuration of Time and Date” Page

The settings for date and time are shown on the “Configuration of Time and Date” page.

7.8.1.10.1 “Date on Device” Group

Table 52: WBM “Configuration of Time and Date” page – “Date on Device” group

Parameters	Explanation
Local	Set date here.

Click [**Change date**] to apply change. The change is effective immediately.

7.8.1.10.2 “Time on Device” Group

Table 53: WBM “Configuration of time and date” page – “Time on Device” group

Parameters	Explanation
Local	Set local time.
UTC	Set GMT time.
12 h format	For switching between 12-hour and 24-hour time display.

Click [**Change time**] to apply change to the time. The change is effective immediately.

Click [**Change format**] to apply change to the time format. The change is effective immediately.

7.8.1.10.3 “Time Zone” Group

Table 54: WBM “Configuration of time and date” page – “Time Zone” group

Parameters	Explanation	
Time Zone	Specify the appropriate time zone for your location. Default setting:	
	AST/ADT	“Atlantic Standard Time”, Halifax
	EST/EDT	“Eastern Standard Time”, New York, Toronto
	CST/CDT	“Central Standard Time”, Chicago, Winnipeg
	MST/MDT	“Mountain Standard Time”, Denver, Edmonton
	PST/PDT	“Pacific Standard Time”, Los Angeles, Whitehouse:
	GMT/BST	“Greenwich Mean Time”, GB, P, IRL, IS, ...
	CET/CEST	“Central European Time”, B, DK, D, F, I, CRO, NL, ...
	EET/EEST	“East European Time”, BUL, FI, GR, TR, ...
	CST	“China Standard Time”
	JST	“Japan/Korea Standard Time”

Click [**Change**] to apply time zone change. The change is effective immediately.

7.8.1.10.4 “TZ String” Group

Table 55: WBM “Configuration of time and date” page – “TZ String” group

Parameters	Explanation
TZ String	Enter your time zone if it is not available from the “Time Zone” parameter list. An overview of all time zones is available at http://home.tiscali.nl/~t876506/TZworld.html with information about editing the TZ string in Linux® at http://www.minix-vmd.org/pub/Minix-vmd/1.7.0/wwwman/man5/TZ.5.html .

Click [**Change**] to apply the change. The change is effective immediately.

7.8.1.11 “Configuration of the Users for the Web-based Management” Page

The settings for user administration are shown on this page.

7.8.1.11.1 “Change Password for Selected User” Group

Table 56: WBM “Configuration of the users for the Web-based Management” page – “Change Password for selected user” group

Parameters	Explanation
Select User	Select the user (“user” or “admin”) for new password assignment.
New Password	Enter the new password for the user selected under “Select User”. The following ASCII characters for passwords are valid: a ... z, A ... Z, 0 ... 9 and spaces. These special characters are also valid:]!"#\$%&'()*+,-./:;<=>?@[^_`{ }~--
Confirm password	Enter the new password again for confirmation.

Click [**Change Password**] to apply change. The change is effective immediately.

Note



Observe the valid characters for WBM passwords!

If WBM passwords with invalid characters are set outside the WBM system (e.g. via CBM), then accessing the WBM pages is no longer possible!

Note



Observe access rights

Authorized WBM users only have access to the Web pages. User administration for controller applications is configured separately.

7.8.1.12 “Create Bootable Image” Page

You can create a bootable image on the “Create Bootable Image” page.

7.8.1.12.1 "Create Bootable Image from Active Partition (<Active Partition>" Group

The active partition that boot-up was performed from is displayed in brackets in the heading.

Table 57: WBM “Create Bootable Image” page – “Create bootable image from active partition” group

Parameters	Explanation		
Destination	The possible destination partition that an image will be saved to is displayed. Depending on which medium has been booted, the following destination is available for selection after boot-up for the image to be generated:		
	System was booted from		Target partition for “bootable image”
	Memory Card	→	Internal Flash
	Internal Flash	→	Memory Card

Once the destination has been determined and output, it is then checked and the results of this check are displayed below the settings:

- Free space on the target device:
If the available memory is less than 5 %, a warning is displayed. You can still start the copy process despite the warning. If the available space is definitively too low, a corresponding message is displayed and copying cannot be started.
- Device being used by CODESYS:
If the device is being used by CODESYS a warning is displayed. Although it is not recommended, you can still start the copying procedure despite this warning.

Click **[Start Copy]** to start the copying procedure. If the outcome of the test is positive, copying begins immediately. If errors have been detected, a corresponding message is displayed and copying is not started. If warnings have been issued, these are displayed again and you must then confirm that you still wish to continue.

Note



Remove the memory card write protection!

Because write access to the memory card is possible during the boot process, the memory card cannot be write protected when creating the image and during operation.

7.8.1.13 “Configuration of Serial Interface RS232” Page

The settings for the serial interface are shown on the “Configuration of Serial Interface RS232” page.

7.8.1.13.1 “Serial Interface Assigned to” Group

The application that the serial interface is currently assigned to is displayed.

7.8.1.13.2 “Assign Owner of Serial Interface (Active after Next Controller Reboot)” Group

You can specify the application that the serial interface is to assigned after the next controller reboot.

Table 58: WBM “Configuration of Serial Interface RS232” page – “Assign Owner of serial Interface” group

Parameters	Explanation
Linux [®] Console	Specify that the serial interface is assigned to the Linux [®] console.
Unassigned (usage by applications, libraries, CODESYS)	Specify that the serial interface is not to be assigned to any particular application and is available, so that the CODESYS program, for example, can access it via function blocks.

NOTICE

Remove RS-485 devices before switching to “Linux Console”!

Connected RS-485 devices can be damaged when switching to “Linux Console”.
Remove these devices before switching!

Click [**Change Owner**] to apply the change. The change takes effect after the next controller reboot.

7.8.1.14 “Reboot Controller” Page

The settings for the system reboot are shown on the “Reboot Controller” page.

7.8.1.14.1 “Reboot Controller” Group

Click the [Reboot] button to reboot the system.



Note

Account for boot-up time!

The boot process takes time. You cannot access the PFC200 while this is occurring.

7.8.1.15 “Firmware Back-up” Page

The settings for a firmware backup are shown on the “Firmware Backup” page.

Select the packages to be restored in the **Packages** group. Select the corresponding entries.

Note



Only one package may be copied to the network!

If you have specified “Network” as the storage location, only one package may be selected for each storing process.

In the selection box **Destination**, select the target storage location.

Note



No backup of the memory card!

Backup from the memory card to the internal flash memory is not possible.

To activate the automatic update function mark check box **Activate “auto update feature”**.

Note



Account for backup time

Generation of backup files can take several minutes. Stop the CODESYS program before you start the backup procedure to help shorten the time required.

To begin the backup procedure, click the [**Submit**] button.

7.8.1.16 “Firmware Restore” Page

The settings for restoring the firmware are shown on the “Firmware Restore” page.

In the **Source** selection box, select the storage location.

Select the packages to be restored in the **Packages** group. Select the corresponding entries.

In the **CODESYS backup file** input field, enter the name of the backup file for the CODESYS project or click the **[Browse]** button to select the file in Explorer.

In the **Settings backup file** input field, enter the name of the backup file for the settings or click the **[Browse]** button to select the file in Explorer.

In the **System backup file** input field, enter the name of the backup file for the system data or click the **[Browse]** button to select the file in Explorer.

Note



Reset by restore

A reset is performed when the system or settings are restored by CODESYS!

To start the restore procedure, click the **[Submit]** button.

7.8.1.17 “System Partition” Page

The settings for specifying the partition that the system will be started from are shown on the “System Partition” page.

7.8.1.17.1 “Current Active Partition” Group

The partition currently in use is displayed here.

7.8.1.17.2 “Set Inactive Partition Active” Group

Click [**Activate Partition**] to start the system from a different partition at the next controller reboot.

Note



Ensure bootable partition!

A functional firmware backup must be present in the boot partition!

Note



Remove the memory card write protection!

Because write access to the memory card is possible during the boot process, the memory card cannot be write protected when operated as the active partition.

7.8.1.18 “Mass Storage” Page

A group containing information about the storage volume is displayed for each storage volume that is found, along with an additional group for formatting (when this is possible).

The group title contains the designation for the storage volume (“SD card” or “Internal Flash”) and, if this storage volume is also the active partition, the text “Active Partition”.

7.8.1.18.1 “<Device Name>” Group(s)

Table 59: WBM “Mass Storage” page – “<Device Name>” group

Parameters	Explanation
Device	The name of the storage volume in the operating system file system is displayed here.
Volume name	The name of the storage volume is displayed here.

7.8.1.18.2 “<Device Name> - FAT Format” Group(s)

Table 60: WBM “Mass Storage” page – “<Device Name>” group

Parameters	Explanation
Volume Name	Specify the name for the storage volume when formatted.

Note



Data are deleted!

Any data stored in the storage volume is deleted during formatting!

To format the specified storage volume, click **[Start Formatting]**.

7.8.1.19 “Software Uploads” Page

The settings for a device update are shown on the “Software uploads” page.

7.8.1.19.1 “Upload New Software” Group

Table 61: WBM “Software Uploads” page – “Upload New Software” group

Parameters	Explanation
(Package File)	You can select fieldbus software, program licenses and update scripts, for example, for transfer from a PC to the controller.

To select a file on the PC, click the [**Browse**] button.

To transfer the selected file to the controller, click [**Start Upload**] button.

7.8.1.19.2 “Activate New Software” Group

Table 62: WBM “Software Uploads” page – “Activate New Software” group

Parameters	Explanation
(Package File)	The file name of the software package to be transferred is displayed here, with a button on the right for activation. If no new, uploaded software package is available on the controller, the message “No upload file exists” is displayed.

To activate the uploaded software package, click the [**Activate**] button. The process starts immediately.

The file with the software package is deleted on completion of the installation procedure.

7.8.1.20 “Configuration of Network Services” Page

The settings for various services are shown on the “Configuration of Network Services” page.

7.8.1.20.1 “Telnet” Group

Table 63: WBM “Configuration of Network Services” page – “Telnet” group

Parameters	Explanation
enabled/disabled	Indicates if the Telnet service is enabled.

Click **[Disable]/[Enable]** to change the status of the service. The change is effective immediately.

7.8.1.20.2 “FTP” Group

Table 64: WBM “Configuration of Network Services” page – “FTP” group

Parameters	Explanation
enabled/disabled	Indicates if the FTP service is enabled.

Click **[Disable]/[Enable]** to change the status of the service. The change is effective immediately.

7.8.1.20.3 “FTPS” Group

Table 65: WBM “Configuration of Network Services” page – “FTPS” group

Parameters	Explanation
enabled/disabled	It is displayed if the FTPS service is enabled.

Click **[Disable]/[Enable]** to change the status of the service. The change is effective immediately.

7.8.1.20.4 “HTTP” Group

Table 66: WBM “Configuration of Network Services” page – “HTTP” group

Parameters	Explanation
enabled/disabled	It is displayed if the HTTP service is enabled.

Click **[Disable]/[Enable]** to change the status of the service. The change is effective immediately.

7.8.1.20.5 “HTTPS” Group

Table 67: WBM “Configuration of Network Services” page – “HTTPS” group

Parameters	Explanation
enabled/disabled	It is displayed if the HTTPS service is enabled.

Click **[Disable]/[Enable]** to change the status of the service. The change is effective immediately.

7.8.1.21 “Configuration of NTP Client” Page

The settings for the NTP service are shown on the “Configuration of NTP Client” page.

7.8.1.21.1 “NTP Client” Group

Table 68: WBM “Configuration of NTP Client” page – “NTP Client” group

Parameters	Explanation
Service enabled	Activate/deactivate time update.
Port	Enter the port number for the NTP access (default setting: 123)
Time Server	Enter the IP address of the time server.
Update Time (sec)	Specify the time server query cycle.

Click the [**Submit**] button to apply the changes. The change is effective immediately.

7.8.1.22 “Configuration of the CODESYS Services” Page

The settings for various CODESYS services are shown on the “Configuration of the CODESYS Services” page.

7.8.1.22.1 “CODESYS Webserver” Group

Table 69: WBM “Configuration of the CODESYS Services” page – “CODESYS Webserver” group

Parameters	Explanation
Current State	The CODESYS Web server status is displayed.

Click **[Disable]/[Enable]** to change the status of the service. The change is effective immediately.

7.8.1.22.2 “Communication” Group

Table 70: WBM “Configuration of the CODESYS Services” page – “Communication” group

Parameters	Explanation
Current State	The CODESYS status is displayed.
Port Number	The CODESYS port number is displayed.

Click **[Disable]/[Enable]** to change the status of the service. The change is effective immediately.

Click **[Change]** to change the port number. The change is effective immediately.

7.8.1.22.3 “Port Authentication” Group

Table 71: WBM “Configuration of the CODESYS Services” page – “Port Authentication” group

Parameters	Explanation
Current State	Displays if port authentication is activated. If authentication is “enabled”, a password is required to access the port.

Click **[Disable]/[Enable]** to activate/deactivate port authentication. The change is effective immediately.

7.8.1.22.4 “Port Authentication Password” Group

Table 72: WBM “Configuration of the CODESYS Services” page – “Port Authentication Password” group

Parameters	Explanation
New Password	Specify the password for port authentication.
Confirm password	Enter the new password again for confirmation.

Click **[Change]** to change the password. The change is effective immediately.

7.8.1.23 “SSH Client Settings” Page

The settings for the SSH service are shown on the “SSH Client Settings” page.

7.8.1.23.1 “SSH Client” Group

Table 73: WBM “SSH Client Settings” page – “SSH Client” group

Parameters	Explanation
Current state	You can enable/disable the SSH client.
Port Number	Specify the port number.
Allow root login	You can enable or inhibit root access.
Allow password login	Activate or deactivate the password query function here.

Click **[Disable]**/**[Enable]** to change the status of the service. The change is effective immediately.

Click the **[Submit]** button to apply the other changes. The change is effective immediately.

7.8.1.24 “TFTP Server” Page

The settings for the TFTP service are shown on the “TFTP Server” page.

7.8.1.24.1 “TFTP Server” Group

Table 74: WBM “TFTP Server” page – “TFTP Server” group

Parameters	Explanation
Current state	Activate or deactivate the TFTP server.
Download directory	Specify the path for downloading the server directory.

Click [**Disable**]/[**Enable**] to change the status of the service. The change is effective immediately.

Click the [**Submit**] button to apply the other changes. The change is effective immediately.

7.8.1.25 “Configuration of SNMP parameter” Page

The general settings for SNMP are shown on the “Configuration of SNMP parameter” page.

7.8.1.25.1 “General SNMP Configuration” Group

Table 75: WBM “Configuration of SNMP parameter” page – “General SNMP Configuration” group

Parameters	Explanation
Current state: enabled/disabled	Here, the actual state of the SNMP service is displayed.
Name of device	Enter the device name (sysName) here.
Description	Enter the device description (sysDescription) here.
Physical location	Enter the device location (sysLocation) here.
Contact	Enter the email contact address (sysContact) here.

Click [**Disable/Enable**] to change the state of the SNMP service. Click [**Change**] to apply any further changes. The changes do not become effective until after the next software or hardware reset.

7.8.1.26 “Configuration of SNMP Parameter” Page

The general settings for SNMP v1/v2c are shown on the “Configuration of SNMP parameter” page.

7.8.1.26.1 “SNMP v1/v2c Manager Configuration” Group

Table 76: WBM “Configuration of SNMP parameter” page – “SNMP v1/v2c Manager Configuration” group

Parameters	Explanation
Protocol enabled	It is displayed the SNMP protocol for v1/v2c is activated. The local community name is deleted when the protocol is deactivated.
Local Community Name	Here, specify the community name for the SNMP manager configuration. The community name can establish relationships between SNMP managers and agents who are respectively referred to as “Community” and who control identification and access between SNMP participants. The community name can be up to 32 characters long and may not include spaces. To use the SNMP protocol, a valid community name must always be specified.

Click [**Change**] to apply changes. The changes do not become effective until after the next software or hardware reset.

7.8.1.26.2 “Actually Configured Trap Receivers” Group(s)

Table 77: WBM “Configuration of SNMP parameter” page – “Actually Configured Trap Receivers” group

Parameters	Explanation
Count	The number of configured trap receivers is displayed.

7.8.1.26.3 “Trap Receiver n” Group(s)

A dedicated group with the following information is displayed for each trap receiver:

Table 78: WBM “Configuration of SNMP parameter” page – “Trap Receiver n” group

Parameters	Explanation
IP Address	The IP address of the trap receiver (management station) is displayed.
Community Name	The community name for the trap receiver configuration is displayed here. The community name can be evaluated by the trap receiver.
Version	The SNMP version, via which the traps are sent, is displayed here: v1 or v2c (traps higher than v3 are displayed in a separate form).

Click **[Delete]** to delete the trap receiver. The changes do not become effective until after the next software or hardware reset.

7.8.1.26.4 “Add new Trap Receiver” Group

Table 79: WBM “Configuration of SNMP parameter” page – “Add new Trap Receiver” group

Parameters	Explanation
IP Address	Enter the IP address of the new trap receiver (management station).
Community Name	Here, specify the community name for the new trap receiver configuration. The community name can be evaluated by the trap receiver. The community name can be up to 32 characters long and may not include spaces.
Version	Specify the SNMP version that will send the traps: v1 or v2c (traps higher than v3 are configured in a separate form).

Click **[Add]** to add a new trap receiver. The changes do not become effective until after the next software or hardware reset.

7.8.1.27 “Configuration of SNMP v3 Users” Page

The general settings for SNMP v3 are shown on the “Configuration of SNMP v3 Users” page.

7.8.1.27.1 “Actually Configured v3 Users” Group(s)

Table 80: WBM “Configuration of SNMP v3” page – “Actually Configured v3 Users” group

Parameters	Explanation
Count	The number of configured v3 users is displayed.

7.8.1.27.2 “v3 User n” Group(s)

A group with the following information is displayed for each user:

Table 81: WBM “Configuration of SNMP v3 Users” page – “v3 User n” group(s)

Parameters	Explanation
Security Authentication Name	The user name is displayed.
Authentication Type	The authentication type for the SNMP v3 packets is displayed here. Possible values: - Use no authentication (“None”) - Message Digest 5 (“MD5”) - Secure Hash Algorithm (“SHA”)
Authentication Key (min. eight char.)	The authentication key is displayed.
Privacy	The encryption algorithm for the SNMP message is displayed here. Possible values: - No encryption (“None”) - Data Encryption Standard (“DES”) - Advanced Encryption Standard (“AES”)
Privacy Key (min. eight char.)	The key for encryption of the SNMP message is displayed here. If nothing is displayed here, the “authentication key” is automatically used.
Notification Receiver IP	The IP address of a trap receiver for v3 traps is displayed here. If no v3 traps are to be sent for this user, this field remains blank.

Click **[Delete]** to delete the user. The changes do not become effective until after the next software or hardware reset.

7.8.1.27.3 “Add New v3 User” Group

Table 82: WBM “Configuration of SNMP v3 Users” page – “Add new v3 User” group

Parameters	Explanation
Security Authentication Name	Enter the user name here. This name must be unique; a pre-existing user name is not accepted when entered here. The security authentication name can have a maximum 32 characters, without any spaces.
Authentication Type	Specify the authentication type for the SNMP v3 packets. Possible values: - Use no authentication (“None”) - Message Digest 5 (“MD5”) - Secure Hash Algorithm (“SHA”)
Authentication Key (min. eight char.)	Specify the authentication key here. This authentication key must have between eight and 32 characters, without any spaces.
Privacy	Specify the encryption algorithm for the SNMP message here. Possible values: - No encryption (“None”) - Data Encryption Standard (“DES”) - Advanced Encryption Standard (“AES”)
Privacy Key (min. eight char.)	Enter the key for encryption of the SNMP message here. If nothing is specified here, the “authentication key” is automatically used. The privacy key must have between eight and 32 characters, without any spaces.
Notification Receiver IP	Specify an IP address for a trap receiver for v3 traps here. If no v3 traps are to be sent for this user, this field remains blank.

Click [**Add**] to add a new user. The changes do not become effective until after the next software or hardware reset.

7.8.1.28 “Diagnostic Information” Page

The settings for displaying diagnostics messages are shown on the “Diagnostic Information” page.

Table 83: WBM “Diagnostic Information” page

Parameters	Explanation
Read all notifications	Activate display of all messages.
Read only the last n	Activate display of only the last n messages. You also specify the number of messages to be displayed.
Automatic refresh cycle (sec)	Select the check box to enable cyclic refresh. Enter the cycle time in seconds when a cyclic refresh is performed. If cyclic refresh is enabled, the button label changes to “Stop”.


To refresh the display or to enable cyclic refresh, click the **[Refresh]** button. The button is only visible if cyclic refresh is disabled.

To stop cyclic refresh again, click the **[Stop]** button. The button is only visible if cyclic refresh is enabled.

The messages are displayed below the settings.

7.8.2 Configuration using a Terminal Program (CBM)

You can configure the PFC200 both via ETHERNET using ssh and via the Linux[®] console using the RS-232 interface via CBM. To call up the CBM log in to both variants at the Linux[®] console and enter the command “cbm” (case sensitive!).

A terminal window showing the WAGO Console Based Management Tool (CBM) main menu. The menu is displayed on a black background with white text. The title is "WAGO Console Based Management Tool" followed by a dashed line. Below it is "Main Menu" followed by another dashed line. A list of options is shown: "0. Quit", "1. Information", "2. CODESYS", "3. Networking", "4. Clock", "5. Administration", "6. Package Server", "7. Mass Storage", "8. Downloads", "9. Ports and Services", and "10. SNMP". The "0. Quit" option is highlighted with a white background. Below the list is a dashed line and the prompt "Select an entry or Q to quit".

```
=====
WAGO Console Based Management Tool
=====
Main Menu
=====
0. Quit
1. Information
2. CODESYS
3. Networking
4. Clock
5. Administration
6. Package Server
7. Mass Storage
8. Downloads
9. Ports and Services
10. SNMP
=====
Select an entry or Q to quit
=====
```

Figure 3: Accessing the CBM using ssh (example)

7.8.3 Configuration using “WAGO ETHERNET Settings”

The “WAGO ETHERNET Settings” program enables you to read system information about your PFC200, make network settings and enable/disable the Web server.

Note



Observe the software version!

To configure the controller, use at least Version 5.4.2.3 dated July 30, 2013 or newer in “WAGO ETHERNET Settings”!

You must select the correct COM port after starting “WAGO ETHERNET Settings”.




Figure 41: “WAGO ETHERNET Settings” – Start screen

For this, click “Settings” and then “Communication”.

In the “Communication settings” window that then opens, adapt the settings to your needs.




Figure 42: “WAGO ETHERNET Settings” – Communication link


Once you have configured “WAGO ETHERNET Settings” and have clicked **[OK]**, connection to the PFC200 is established automatically.

If “WAGO ETHERNET Settings” has already been started with the correct parameters, you can establish connection to the PFC200 by clicking **[Identify]**.

7.8.3.1 Identification Tab

An overview of the connected device is given here.

Besides some fixed values — e.g., item No., MAC address and firmware version — the currently used IP address and the configuration method are also shown here.



Item Number	750-8202
Description	PFC200 CS 2ETH RS
FW Version	02.01.04(01)
HW Version	01
FWL Version	01.01.06 IXD=01
Serial Number	SN20130612T080546-175774068#PFC 0030DEFF009B
MAC address	0030DEFF009B
IP address	192.168.1.17 (Static Configuration)

Figure 43: “WAGO ETHERNET Settings” – Identification tab (example)

7.8.3.2 Network Tab

This tab is used to configure network settings.

Values can be changed in the “Input” column, while the parameters in use are shown in the “Currently in use” column.

Parameter	Edit	Currently used
Address Source	Static Configuration	Static Configuration
IP address	192.168.1.17	192.168.1.17
Subnet Mask	255.255.255.0	255.255.255.0
Gateway	192.168.1.2	192.168.1.2
Preferred DNS-Server	192.168.1.2	192.168.1.2
Alternative DNS-Server	0.0.0.0	0.0.0.0
Time Server	192.168.1.50	192.168.1.50
Hostname		PFC200-FF009B
Domain name		
DIP-Switch IP address	DST not supported!	DST not supported!

Figure 44: “WAGO ETHERNET Settings” – Network tab

Source

Specify how the PFC200 will determine its IP address: Static, via DHCP or via BootP.

IP address, subnet mask, gateway

Specify the specific network parameters for static configuration.

Preferred DNS server, alternative DNS server

Enter the IP address (when required) for an accessible DNS server when identifying network names.

Time server

Specify the IP address for a time server if setting the PFC200's system time via NTP.

Host name


The host name of the PFC200 is displayed here. In the controller's initial state, this name is composed of the string “PFC200” and the last three bytes of the MAC address.

This standard value is also used whenever the chosen name in the “Input” column is deleted.

Domain name

The current domain name is displayed here. This setting can be automatically overwritten with dynamic configurations, e.g., DHCP.

7.8.3.3 Protocol Tab



Identification | Network | **Protocol** | Status

Web Server

HTTP-Port: 80

Additional Protocols

Please use the web base management of the device for additional protocol settings.

Figure 45: “WAGO ETHERNET Settings” – Protocol tab

You can enable or disable the Web server.

7.8.3.4 Status Tab




Figure 46: “WAGO ETHERNET Settings” – Status tab

General information about the device status is displayed here.

The **Bus extension** check box has no function for the PFC200, i.e., the bus extension is always active.

8 Run-time System CODESYS 2.3

8.1 Installing the CODESYS 2.3 Programming System

The WAGO target files must also be included for the installation of CODESYS. These contain all device-specific information for the WAGO 750/758 product series.

Proceed as described below to install the CODESYS 2.3 programming software on the fieldbus controller.

1. Insert the “WAGO-I/O-PRO” CD into your computer drive.
2. To install the programming system, follow the instructions that appear on your screen. A successful installation is indicated by a CODESYS icon on your desktop.

8.2 First Program with CODESYS 2.3

This section uses an example to explain the relevant steps required for the creation of a CODESYS project. It is intended as a set of quick start instructions and does not address the full functional range of CODESYS 2.3.

Note



Additional information

For a detailed description of the full range of functions, refer to the “Manual for PLC Programming using CODESYS 2.3” manual available on the “WAGO-I/O-PRO” (759-911) CD.

8.2.1 Start the CODESYS Programming System

Start CODESYS by double clicking on the CODESYS pictogram on your desktop using the Start menu in your operating system. To do this, click on the “Start” button and choose **Programs > WAGO Software > CODESYS > CODESYS V2.3**.

8.2.2 Creating a Project and Selecting the Target System

1. In the menu bar click on **File** and select **New**. The “Target system settings” window then opens. Here, all available target systems that can be programmed with CODESYS 2.3 are listed.
2. Open the selection box in the “Target system settings” window and select the fieldbus controller you are using. In the example shown here this is the PFC200 CS 2ETH RS CAN “WAGO_750-8204”.

3. Click on **[OK]**. The “Target system settings” configuration window then opens.




Figure 47: Target system settings (1)

4. To accept the default configuration for the fieldbus controller click **[OK]**. The “New component” window opens.




Figure 48: Target system settings (2)

5. In this “New component” window create a new program function block. In the example shown here, the new function block “PLC_PRG” is created in the “ST” programming language.
6. Click on [OK] to create the project. The programming interface opens.




Figure 49: Creating a new function block




Figure 50: Programming interface with the PLC_PRG program module

8.2.3 Creating the PLC Configuration

Note



Procedure for Creating the PLC Configuration

The procedure explained in this section describes the PLC configuration for the I/O modules connected to the controller.

Information about the controller function for any fieldbuses connected to the system is given in the section on the specific fieldbus.

The PLC configuration is used to configure the fieldbus controller, along with the connected I/O modules and to declare variables for accessing the inputs and outputs of the I/O modules.

1. Click on the “Resources” tab.




Figure 51: "Resources" tab

2. In the left window double-click on “PLC configuration”. The PLC configuration for the controller opens.
3. Right-click on the entry “K-Bus[FIX]” and then select “Edit” in the contextual menu. The “configuration” dialog window then opens.





Figure 52: Control configuration – Edit

4. There are three options for accepting the topology for the I/O modules connected to the fieldbus controller. The simplest way is to scan in the topology using *WAGO-I/O-CHECK*. To do this, click on the “Start *WAGO-I/O-CHECK* and scan” button.

Figure 53: “Start *WAGO-I/O-CHECK* and scan” button

Note



Ensure proper installation of *WAGO-I/O-CHECK*!

This function requires that the latest version of *WAGO-I/O-CHECK* be installed and the IP address set under “Online > Communication parameters”, as otherwise communication will not be possible.

5. *WAGO-I/O-CHECK* is started.




Figure 54: WAGO-I/O-CHECK – Starting screen

6. To connect to the controller and read in the module configuration, click **[Identify]**.
7. If this action is successful click **[Save]** and exit WAGO-I/O-CHECK.
8. The detected I/O modules then appear in the configuration window.



Note

Passive I/O Modules

Remember that passive I/O modules, such as a power supply module (750-602) or end module (750-600) will not be shown in the I/O configurator.




Figure 55: I/O Configurator empty

9. You can use the **[Add]** button to add new I/O modules to manually define or change the configuration.



Figure 56: "Add I/O modules" button

10. You can select a module in the new "Module selection" window that then appears.




Figure 57: "Module selection" window

11. You can change the position of an I/O module by marking it and then using the arrow buttons at the right edge of the window to move it up or down.




Figure 58: I/O Configurator with defined I/O modules

12. Use **[Import configuration from file]** to add a configuration imported previously using *WAGO-I/O-CHECK*.
13. To close the I/O Configurator, click **[OK]**.

14. The individual inputs and outputs of the selected I/O module are displayed in the right half of the configuration window. Here, you can declare a dedicated variable in the “Name” column for each input and output, e.g., “Output_1”, “Output_2”, “Input_1”, “Input_2”.




Figure 59: Variable declaration

15. The added I/O modules appear in the control configuration under “K-Bus[FIX]” with their associated fixed addresses and, where applicable, their previously set variable name.




Figure 60: Control configuration: I/O modules with their associated addresses

8.2.4 Editing the Program Function Block

To edit the PLC_PRG program function block, go to the “Function block” tab and double-click on the PLC_PRG program module.




Figure 61: Program function block

The following example illustrates the editing of the program function block. To do this, an input is assigned to an output:

1. Press **[F2]** to open the Input assistant, or right click and select “Input assistant” from the contextual menu.




Figure 62: Input assistant for selecting variables

2. Under “Global variables” select the previously declared variable “Output_1” and click **[OK]** to add it.
3. Enter the allocation “=” behind the variable name.
4. Repeat Step 2 for the “Input_1” variable.




Figure 63: Example of an allocation

5. To compile, click on **Project > Compile all** in the menu bar.

8.2.5 Loading and Running the PLC Program in the Fieldbus Controller (ETHERNET)

Requirement:

- The simulation is deactivated (**Online > Simulation**).
- The PC is linked to the controller via ETHERNET. Refer to Section “Device Description” > ...> “ETHERNET – X1, X2 Network Connection”.

Proceed as follows:

1. In the menu bar click on **Online** and select **Communication parameters** The "Communication Parameters" window opens.
2. To select a communication link click on [**New ...**] in the “Communication Parameters” window. A window opens in which you can define a communication link.




Figure 64: Creating a communication link – Step 1

3. In the “Name” field enter a designation for your fieldbus controller and then click on “Tcp/Ip (Level 2 Route)”. Then click [**OK**].




Figure 65: Creating a communication link – Step 2

4. In the “Communication Parameters” window enter the **IP address of your fieldbus controller** in the “Address” field and then press Enter. To close the window click on **[OK]**.
Zum Auswählen eines bereits angelegten Feldbuscontrollers selektieren Sie diesen im linken Fenster, und klicken Sie anschließend auf **[OK]**.




Figure 66: Creating a communication link – Step 3

5. Transfer the PLC program by clicking on **Online** in the menu bar and select **Login**.
6. Ensure that the Run/Stop switch for the fieldbus controller is set to “Run”.
7. Start the PLC program by clicking on **Online > Start** in the menu bar.

8.2.6 Creating a Boot Project

Create a boot project to ensure that the PLC program starts automatically again after a fieldbus controller restart. In the menu bar select **Online > Create boot project**. You must be logged in to CODESYS to use this function.

Note



Automatic loading of the boot project

In addition, you can load the boot project automatically when starting the fieldbus controller. Click on the “Resources” tab and open “Target system settings”. Select the “General” tab and “Load boot project automatically”.

If a boot project (DEFAULT.PRG and DEFAULT.CHK) is present under */home/codesys* and the “Run/Stop” switch of the fieldbus controller is set to “Run”, the fieldbus controller automatically starts with the processing of the PLC program. The PLC program is not started if the switch is set to “Stop”.

If a PLC program is running in the fieldbus controller, a PLC task starts with the reading of the fieldbus data (only with fieldbus controllers and fieldbus connection), the integrated input and output data and the I/O modules. The output data changed in the PLC program is updated after the PLC task is processed. A change in operating mode (“Stop/Run”) is only carried out at the end of a PLC task. The cycle time includes the time from the start of the PLC program to the next start. If a larger loop is programmed within a PLC program, the task time is prolonged accordingly. The inputs and outputs are updated during processing. These updates only take place at the end of a PLC task.

8.3 Syntax of Logical Addresses

Access to individual memory elements according to IEC 61131-3 is possible using only the following special symbols:

Table 84: Syntax of logical addresses

Item	Prefix	Description	Notes:
1	%	Starts the absolute address	-
2	I	Input	
	Q	Output	
3	M	Flag	Data width
	X	Single bit	
	B-	Byte (8 bits)	
	W	Word (16 bits)	
4	D	Double word (32 bits)	
		Address	

Two examples:

Addressing by word	%QW27 (28th word)
Addressing by bit	%IX1.9 (10th bit in word 2)

Enter the character string of the absolute address without empty spaces. The first bit of a word has an address of 0.

8.4 Creating Tasks

Set the time response and the priority of individual tasks in the task configuration.

Note



Watchdog

In an application program without task configuration, there is no watchdog that monitors the cycle time of the application program (PLC_PRG).

Create a task as follows:

1. Open the task configuration by double-clicking on the “Task configuration” module in the “Resources” tab.




Figure 67: Task configuration

2. To create a task right-click on “Task configuration” and in the contextual menu select “Attach task”.

3. To assign a new name to the task (e.g. PLC_Prog), click on “New Task”. Then select the type of task. In this example, this is the “cyclic” type.

Note



Observe the cycle time!

The minimum cycle time for I/O-based tasks is 2 milliseconds (ms)!




Figure 68: Changing task names 1

4. Add the program module PLC_PRG that you have just created (see Section “Editing the Program Modules”). To do this, right-click on the “Clock” symbol and in the contextual menu select “Attach program call-up”. Then, click the [...] button and [OK].




Figure 69: Call-up to add to the program module

5. Compile the example program by selecting **Project > Rebuild all** in the context menu.

8.4.1 Cyclic Tasks

You can assign a priority for each task in order to establish the task processing sequence.




Figure 70: Cyclic task

Note



Order of Task Processing

The priorities given below do not specify the order of task processing. The tasks start in an arbitrary order.

Priority 0 ... 5:

Important arithmetic operations and synchronized access to I/O module process images are to be carried out as tasks with the highest priorities 0 ... 5. These tasks are processed fully according to priority and correspond to Linux[®] RT priorities -79 through -74.

Priority 6 ... 20:

Real-time access, such as access to ETHERNET and the file system, to fieldbus data and to the RS-232 interface (when available) are to be carried out as tasks with average priorities 6 ... 20. These tasks are processed fully according to priority and correspond to Linux[®] RT priorities -40 through -26.

Priority 21 ... 31:

Applications such as long-lasting arithmetic operations and non-real-time-relevant access to ETHERNET and the file system, to fieldbus data and the RS-232 interface (when provided) are to be carried out as tasks with the lowest priorities 21 ... 31. No priority distinction is made between tasks of priorities 21 ... 31.

These tasks all receive the same computing time from the operating system (“Completely Fair Scheduler” procedure).

8.4.2 Freewheeling Tasks

So-called freewheeling tasks are not processed in cycles. Their processing depends solely on the current capacity of the system. The input field “Priority (0 ... 31)” is provided for freewheeling tasks without a function. These tasks are handled as tasks with priority 21 ... 31.




Figure 71: Freewheeling task

Note



PLC-PRG as Freewheeling Task without Task Configuration

If you do not perform any task configuration, the program PLC_PRG is carried out with the lowest priority at an interval of 10 ms. The runtime of "freewheeling tasks" is not monitored by a CODESYS watchdog.

8.5 System Events

Event tasks can be used in the CODESYS task configuration in addition to cyclical tasks. Event tasks call up certain events in the device.

To activate events and define a program to be called up, open the window “Task configuration” in the “Resources” tab in the CODESYS development environment.




Figure 72: CODESYS – System events

Note



Do not set debug points in the event handlers!

Debug points in event handlers can lead to unforeseeable errors and must therefore not be set!

The following events can be activated:

Table 85: Events

Name	Description
start	The event is called directly after the user program starts.
stop	The event is called directly after the user program stops.
before_reset	The event is called directly before the user program is reset.
after_reset	The event is called directly after the user program is reset.
shutdown	The event is called directly before the user program is shutdown.
excpt_watchdog	The event is called if a task watchdog is recognized.
excpt_access_violation	The event is called if a memory access error to an invalid memory area is recognized. (incorrect pointer, invalid array index, invalid data descriptor)
excpt_dividebyzero	The event is called if a division by zero is recognized.
after_reading_inputs	The event is triggered after reading all of the inputs independent of the user program.
before_writing_outputs	The event is triggered before writing all of the outputs independent of the user program.
debug_loop	This event is triggered at every task call, if a breakpoint was reached in this task and the processing of this task is therefore blocked.
online_change	This event is called up after initialization of the program on an online change.
before_download	This event is always called up before a download from the IDE to the device takes place.

Note



Application stops on a non-defined event handler!

If “excpt” events occur in the system and an event handler has not been defined, the application goes into the "Stop" status.

8.5.1 Creating an Event Handler

The example here is provided to illustrate how to define and use an event handler. The event handler “except_dividebyzero” is used in this example.

First, a program is generated in the PLC_PRG- module which provokes division by 0.




Figure 73: CODESYS program provokes division by “0”

After this, the system event “except_dividebyzero” is activated in the Task Configurator and the name of the event handler to be generated is entered in the column “Called POU”.




Figure 74: CODESYS – Creating and activating an event handler

To generate the event handler, click [**Generate CALLBACK_DIV_BY_ZERO function block**].

A new function having the defined name then appears in the “Function blocks” tab.




Figure 75: CODESYS – New module has been generated

Handling for the event that has occurred is now programmed in this new function.

In the example here, the event is documented in a global variable.




Figure 76: CODESYS – Enter the event in a global variable

The newly created project is now supported and can be loaded to the controller.

After startup, the value of the “Events” variable changes only when counter “i” reaches the value 0, meaning that division by 0 has been performed.




Figure 77: CODESYS – Variable contents prior to division by “0”




Figure 78: CODESYS – Variable contents after division by “0” and call-up of the event handler

8.6 Process Images

A process image is a memory area in which the process data is stored in a defined sequence and consists of the I/O modules attached to the internal bus, the PFC variables, the bit memory address area and the slaves attached to the fieldbus.




Figure 79: Process image




Figure 80: Flag area

8.6.1 Process Images for I/O Modules Connected to the Controller

After starting the fieldbus controller, it automatically detects all connected I/O modules.

The analog input and output data is stored first word by word in the process image. Subsequent to this, come the digital input and output data bits combined to form words.

The size and structure of the process image for the I/O modules connected to the system are described in the appendix.

Note**I/O Module Data Width**

The data width of an I/O module is between 0 and 48 bytes.

Note**I/O Module Process Data**

Check the I/O module process data whenever you add or remove the modules to/from the fieldbus controller. Changing the I/O module topology results in an adjustment of the process image, as the process data addresses also change.

8.6.2 Process Image for Slaves Connected to the Fieldbus

The size and structure of the process image for the slaves connected to the system are described in the section for the specific fieldbus.

Note**No direct access from fieldbus to the process image for I/O modules!**

Any data that is required from the I/O module process image must be explicitly mapped in the CODESYS program to the data in the fieldbus process image and vice versa! Direct access is not possible!

8.7 Access to Process Images of the Input and Output Data via CODESYS 2.3

The following tables describe the possibilities with which you can access the address ranges of the process image for the inputs and outputs connected to the internal data bus.

Table 86: Access to the Process Images of the Input and Output Data – Internal Data Bus

Memory area	Description	Access via PLC	Logical Address Space
Internal data bus input process image	Map of the local input modules (internal data bus, I/O module 1 to 1 bis 64 [*]) in the RAM.	Read	Word %IW0 to %IW999
			Byte %IB0 to %IB1999
Internal data bus output process image	Map of local output modules (internal data bus, I/O module 1 to 64 [*]) in the RAM.	Read/ Write	Word %QW0 to %QW999
			Byte %QB0 to %QB1999

* The use of up to 250 I/O modules is possible with the WAGO internal data bus extension modules.

Table 87: Access to the Process Images of the Input and Output Data – MODBUS

Memory area	Description	Access via PLC	Logical Address Space
MODBUS input process image	MODBUS input variables, addressed by word via MODBUS	Read	Word %IW1000 to %IW1999
			Byte %IB2000 to %IB3999
	MODBUS input variables, addressed by bit via MODBUS	Read	Bit %IX1000.0 ... %IX1000.15 to %IX1384.0 ... %IX1384.15
MODBUS output process image	MODBUS output variables, addressed by word via MODBUS	Read/ Write	Word %QW1000 to %QW1999
			Byte %QB2000 to %QB3999
	MODBUS output variables, addressed by bit via MODBUS	Read/ Write	Bit %QX1000.0 ... %QX1000.15 to %QX1384.0 ... %QX1384.15

Table 88: Access to the Process Images of the Input and Output Data – CANopen

Memory area	Description	Access via PLC	Logical Address Space
CANopen input process image	CANopen master or CANopen slave input variables	Read	Word %IW3000 to %IW4999
			Byte %IB6000 to %IB9999
CANopen output process image	CANopen master or CANopen slave output variables	Read/ Write	Word %QW3000 to %QW4999
			Byte %QB6000 to %QB9999

Table 89: Access to the Process Images of the Input and Output Data – Flags

Memory area	Description	Access via PLC	Logical Address Space
Flag variables	Total of 128 kB remanent memory (65536 words).	Read/ Write	%MW0 to %MW65535
	104 kB addressed by word via MODBUS (53248 words)	Read/ Write	Word (MODBUS) %MW0 to %MW3327
	6.5 kB addressed by bit via MODBUS (3328 words).	Read/ Write	Bit (MODBUS) %MX0.0 ... %MX0.15 to %MX3327.0 ... %MX3327.15
Retain variables	Retain memory addressed by symbols in the NVRAM: 128 kB	Read/ Write	-

* The use of up to 250 I/O modules is possible with the WAGO internal data bus extension modules.

The total size of the memory for flag and retain variables is 128 kB (131060 bytes). The size of these two sections can be customized as required, provided the total (permissible) size is not exceeded.

If you are using bit-oriented addressing, remember that the basic address is word-based. The bits are addressed from 0 to 15.

8.8 Addressing Example

The following addressing example clarifies the access to the process image:

Table 90: Arrangement of the I/O modules for the addressing example


Fieldbus controller	750-400	750-554	750-402	750-504	750-454	750-650	750-468	750-600
	1	2	3	4	5	6	7	8


Table 36: Addressing example

I/O module	Input data	Output data	Description
Type	C*		
750-400	1	%IX8.0	2DI, 24 V, 3 ms: 1. Digital input module with a data width of 2 bits. As the analog input modules already occupy the first 8 words of the input process image, the 2 bits occupy the lowest-value bits of the 8th word.
	2	%IX8.1	
750-554	1	%QW0	2AO, 4 – 20 mA: 1. Analog output module with a data width of 2 words. This module occupies the first 2 words in the output process image.
	2	%QW1	
750-402	1	%IX8.2	4DI, 24 V: 2. Digital input module with a data width of 4 bits. These are added to the 2 bits of the 750-400 module and stored in the 8th word of the input process image.
	2	%IX8.3	
	3	%IX8.4	
	4	%IX8.5	
750-504	1	%QX4.0	4DO, 24 V: 1. Digital output module with a data width of 4 bits. As the analog output module already occupies the first 4 words of the output process image, the 4 bits occupy the lowest-value bits of the 4th word.
	2	%QX4.1	
	3	%QX4.2	
	4	%QX4.3	
750-454	1	%IW0	2AI, 4 – 20 mA: 1. Analog input module with a data width of 2 words. This module occupies the first 2 words in the input process image.
	2	%IW1	
750-650	1	%IW2	RS-232, C 9600/8/N/1: The serial interface module is an analog input and output module, which displays 2 words both in the input process image and in the output process image.
		%IW3	
		%QW2	
		%QW3	
750-468	1	%IW4	4AI, 0 – 10 V S.E: 2. Analog input module with a data width of 4 words. As the 750-454 and 750-650 analog input and output modules already occupy the first 4 words of the input process image, the 4 words of this I/O module are added behind the others.
	2	%IW5	
	3	%IW6	
	4	%IW7	

Table 36: Addressing example

I/O module		Input data		Output data		Description
Type	C*					
750-600						End module The passive 750-600 end module does not transmit any data.

 Analog input and output modules

 Digital input and output modules

*C: Number of the input/output

8.9 Internal Data Bus Synchronization

The internal data bus cycle and the CODESYS task cycle are optimally automatically synchronized: This depends on the number of I/O modules connected and the fastest CODESYS task cycle set in the fieldbus controller. The synchronization cases described below can therefore take place.

In this chapter, CODESYS task denotes only tasks within CODESYS that contain an access to the internal data bus. Tasks that do not access the internal data bus are not synchronized in the same way as described below. For this, see Section “Creating Tasks.”

8.9.1 Case 1: CODESYS Task Interval Set Smaller than the I/O Module Cycle

Execution of the CODESYS tasks is synchronized with internal data bus cycle time.

The CODESYS task is processed in parallel to the internal data bus cycle. The CODESYS task interval is extended to the internal data bus cycle time. This is necessary so that each CODESYS task is started with new input data from the internal data bus and the output values are also set at the module after each CODESYS task.




Figure 81: Internal data bus synchronization 01

CTI: CODESYS Task Interval
 CT: CODESYS Task that accesses the I/O module of the internal data bus
 KBZ: Internal Data Bus Cycle

Example:

CODESYS task interval (CTI): 100 μ s

I/O module cycle (KBZ): 2000 μ s

Result: Matching of the CODESYS task interval to the I/O module cycle of 2000 μ s.

8.9.2 Case 2: CODESYS Task Interval Smaller than Twice the Internal Data Bus Cycle

Execution of the internal data bus is synchronized with the set CODESYS task interval.

At the end of the CODESYS task, the internal bus cycle starts, which is processed synchronously with the fastest CODESYS task. This ensures that when starting each CODESYS Task, current input data are available from the internal data bus and the output values of each CODESYS task are also output to the I/O modules.




Figure 82: I/O module synchronization 02

CTI: CODESYS Task Interval

CT: CODESYS Task that accesses the I/O module of the internal data bus

KBZ: Internal Data Bus Cycle

Example:

CODESYS task interval (CTI): 2500 μ s

Internal data bus cycle (KBZ): 2000 μ s

Result: Execution of the internal data bus cycle every 2500 μ s.

8.9.3 Case 3: CODESYS Task Interval Greater than Twice the Internal Data Bus Cycle

The I/O data from the internal data bus are refreshed once prior to the CODESYS task and once after the CODESYS task.

Prior to processing the CODESYS task, the internal data bus cycle is executed, which provides the current input data for the CODESYS task. After execution of the CODESYS task, an additional internal data bus cycle is started, which provides the output data to the I/O modules.

This ensures that at the start of every CODESYS task, current input data are available from the internal data bus and the output data from each CODESYS task are quickly output to the I/O modules. This prevents processing of internal data bus cycles that would unnecessarily use a great deal of computing time on the CPU.




Figure 83: I/O module synchronization 03

CTI: CODESYS Task Interval

CT: CODESYS Task that accesses the I/O module of the internal data bus

KBZ: Internal Data Bus Cycle

Example:

CODESYS task interval (CTI): 500 μ s

Internal data bus cycle (KBZ): 2000 μ s

Result: Execution of the internal data bus cycle 2000 μ s prior to the CODESYS task and once directly after the CODESYS task.

8.9.4 Case 4: CODESYS Task Interval Greater than 10 ms

Synchronization takes place as in case 3; however, the output modules would be reset to their default state after 150 ms without an internal data bus cycle. This reliably prevents the execution of an internal data bus cycle after at least every 10 ms.

The I/O data from the internal data bus are refreshed once before the CODESYS task and once after the CODESYS task and an additional internal data bus cycle is also executed every 10 ms.




Figure 84: Internal data bus synchronization 04

CTI: CODESYS Task Interval
 CT: CODESYS task that accesses the I/O module of the internal data bus
 KBZ: Internal data bus cycle

Example:

CODESYS task interval (CTI): 150000 μ s

Internal data bus cycle (KBZ): 2000 μ s

Result: Execution of the internal data bus cycle 2000 μ s prior to the CODESYS task, once directly after the CODESYS task and 10 ms after the previous internal data bus cycle.

8.9.5 Internal Data Bus Configuration




Figure 85: Internal data bus settings

Table 91: Internal Data Bus Settings

Parameter	Explanation	
Update Mode	The Update mode is used to configure how the internal data bus process data is to be updated (refreshed).	
	Asynchronous	In the asynchronous update mode process data are refreshed in cycles at a definable interval.
	Synchronous*	In the synchronous update mode the process data are synchronized with the most rapid CODESYS task that accesses the internal data bus.
Internal Data Bus Cycle Time	The update interval for the internal data bus is set by the cycle time. This setting is effective only in the asynchronous mode.	
	1000 μ s	Minimum value 1 millisecond
	10000 μ s*	Default value 10 milliseconds
	50000 μ s	Maximum value 50 milliseconds
Internal Data Bus Thread Priority	This value indicates the priority for the internal data bus thread. This setting is effective only in the asynchronous mode. This priority is equivalent to the priority of the cyclic CODESYS tasks (see Section “Cyclic Tasks”). This setting is effective only in the asynchronous mode.	
	0*	Highest priority
	15	Lowest priority
PLC stop response	Specifies the response of the internal data bus outputs when the PLC application stops.	
	Hold last value	The output states are retained.
	Set to zero*	Outputs are set to zero.

* Default setting

8.9.5.1 Effect of Update Mode on CODESYS Tasks

8.9.5.1.1 Asynchronous Update Mode

In the asynchronous update mode there is no direct influence on CODESYS task behavior.

Note



Internal data bus “freeze” on priority conflicts!

In the asynchronous update mode there is a risk of the internal data bus “freezing”, as the internal data bus thread operates at the same priority as the IEC tasks. The internal data bus thread must therefore use a priority higher than that of the IEC task to prevent this from occurring.

8.9.5.1.2 Synchronous Update Mode

In the synchronous update mode the runtime behavior of CODESYS tasks can be influenced by the internal data bus. The minimum task interval that can then be achieved depends on the duration of an internal data bus cycle. The duration of an internal data bus cycle, on the other hand, is based on the I/O modules connected to the bus. As a rule of thumb: The shorter the internal data bus structure, the shorter the cycle time and digital modules are faster than analog or complex ones.

In the event of an internal data bus error, the CODESYS tasks are blocked until the error is rectified, i.e., when an internal data bus cycle has been successfully executed again.

Note



No call-up of internal data bus status when internal data bus errors are present!

If an internal data bus error has occurred, it is not possible to call up the internal data bus status using `KBUS_ERROR_INFORMATION (mod_com.lib)` while in the synchronous update mode.

8.10 Memory Settings in CODESYS

The list below illustrates the standard memory allocation of the PFC200:

- Program memory: 16 Mbyte (max.)
- Data memory: 64 Mbytes
- Input data: 64 kbytes
- Output data: 64 kbytes
- Flags: 24 kbytes
- Retain: 104 kbytes
- Function block limitation: $12 * 4096 \text{ bytes} = 48 \text{ kbytes}$

8.10.1 Program Memory

The program memory (also code memory) cannot be configured and is limited to a maximum of 16 Mbytes. The memory space actually available is based on the scope of installed applications.




Figure 86: Program memory

8.10.2 Data Memory and Function Block Limitation

The data memory is set for 64 Mbytes in the controller's initial state.

This set value has already been requested after a successful program download in the system and can be utilized to the full extent.

Together with the data memory to be used by the application, memory is required for the individual program function blocks in the system.

The size of the administration space is calculated from the function block limitation * 12 (i.e., normally 4096 * 12).

The sum from the global data memory and function block limitation yields the actual size of the main memory required in the system for data.

This value should not exceed the value specified for “Size of entire data memory”.




Figure 87: Data memory and function block limitation

8.10.3 Remanent Memory

A total of 128 kbytes of remanent memory is available for the IEC-61131 application.

The remanent section is subdivided into the flag area (memory) and the retain area.




Figure 88: Remanent main memory

The breakdown of the flag and retain variables can be customized as required.

It must be ensured, however, that the sum from Memory + Retain does not exceed the maximum value of 128 kbytes (0x20000).




Figure 89: Flag and retain memory

8.11 CODESYS Visualization

CODESYS Web visualization is based on Java technology. All Java programs require a Java runtime environment (JRE), which must be installed on the host PC along with an Internet browser. An applet is stored in the file system of a Web server and is accessible to browsers via an HTML page.

You create all visualization types (HMI and Web visualization) with the same CODESYS graphic editor. Select the visualization type in the “Target system settings” window. A description file in XML format is generated from the information for each of these pages. You can find these files in the subfolder “visu” of the CODESYS installation path. The HTML home page “webvisu.htm” and the Java archive “webvisu.jar” in the applet (webvisu.class) are also saved there in a compressed format.

Once you have selected a visualization type, the following steps must be performed to execute the technique:

1. Click the “Resources” tab and open the “Target system settings.” Specify whether you wish to have visualization displayed as a “Web visualization” using an Internet browser.




Figure 90: Selecting the visualization technique in the target system settings

2. Generate a start page for the visualization. Right-click the “Visualization” folder in the “Visualization” tab. Select **Add object ...** from the contextual menu. The “New visualization” dialog box opens.




Figure 91: Creating the PLC_VISU starting visualization

3. In the “New visualization” dialog window, enter the name **PLC_VISU** for the start visualization. This page is then displayed as the start page upon system startup.
4. Activate the CODESYS Web server in the WBM on the “Ports and Services – CODESYS Services” page in the “CODESYS Webserver” group.
5. Activate the http service in the WBM on the “Ports and Services – Network Services” page in the “HTTP” group.

If you transfer the PLC program to the controller (**Online > Login**) and start the program (**Online > Start**), enter one of the following lines in the address line of the Web browser for online visualization:

- “https://<IP address of the controller>/webvisu”, preferred method (http can also be used instead of https)
- “https://<IP address of the controller>”, if the default Web server in the WBM has been set to “WebVisu” (http can also be used instead of https)
- “http://<IP address of the controller>:8080/webvisu.htm”

You can also have Web visualization displayed via the WBM (see Section “CODESYS - WebVisu” Page).

Information



Frequently Asked Questions

Additional information (FAQs) on CODESYS Web visualization is also provided in the Section “Frequently Asked Questions about CODESYS Web Visualization” and in the online Help function for CODESYS 2.3.

8.11.1 Limits of CODESYS Visualization

The controller supports the “WebVisu” visualization type integrated into CODESYS. Technological limitations can be caused by the visualization type used.

Compared to “HMI”, Web visualization on the controller is performed within significantly narrower physical limits. Whereas “HMI” can access almost unlimited resources on a desktop PC, the following limitations must be observed when using Web visualization:

Adapting to the File System

The overall size of the PLC program, visualization files, bitmaps, log files, configuration files, etc. must fit into the file system.

Process Data Memory

Web visualization uses its own protocol for exchanging process data between applet and control.

The controller transfers process data with ASCII coding. The pipe symbol (“|”) is used to separate two process values. Therefore, the space requirement for a process data variable in the process data memory is dependent not only on the data type, but also on the process value itself. Thus, a variable of the “WORD” type occupies between one byte for the values 0 through 9 and five bytes for values from 10000 and greater. The selected format (ASCII + |) only permits a rough estimate of the space requirement for the individual process data in the process data buffer. If the size of the ASCII coded process data is exceeded, Web visualization no longer works as expected.

Computer Performance/Processor Time

The controller is based on a real-time operating system. This means that high-priority processes (e.g., PLC program) interrupt or block lower priority processes. The Web server responsible for Web visualization is among these lower priority processes.

Note



Processor Time

Make sure when configuring tasks, that there is sufficient processor time available for all processes.

Network Load

The controller's CPU processes both the PLC program and network traffic. ETHERNET communication demands that each received telegram is processed, regardless of whether it is intended for the controller or not.

A significant reduction of the network load can be achieved by using switches instead of hubs.

There is no measure against broadcast telegrams that can be used on the controller, however. These can only be curtailed by the sender, or blocked with configurable switches that have a broadcast limitation. A network monitor such as “wireshark” (www.wireshark.com) provides an overview of the current load in your network.

8.11.2 Eliminating Errors in CODESYS Web Visualization

If you are experiencing problems when working with the CODESYS Web visualization, use the following table to find the solution. If you cannot eliminate the problem, please contact WAGO support.

Table 92: Errors and remedies

Error	Solution
Internet Explorer reports the error "APPLET NOT INITIATED"	Close all Internet Explorer windows and restart. If the error persists, this indicates a missing or damaged file. Using FTP, check if the entire Java archive "webvisu.jar" is available in the "/PLC" folder of the controller. The original file can be found in the installation path of CODESYS (usually under <i>C:\Programme\WAGO Software\CODESYS V2.3\Visu\webvisu.jar</i>). If necessary, replace the damaged file using FTP or force the download of all files in CODESYS with Purge All > Compile All > Log in.
Web visualization is not displayed	Have you installed the JRE? Check the firewall settings, e.g., if port 8080 is open.
Web visualization "freezes". Web visualization stops after an extended period of time.	The call-up intervals selected in the task configuration are too small. As a result, the Web server of the controller — which is executed with a low priority — does not receive sufficient computer time, if any at all. If no (explicit) task configuration has been provided, the PLC_PRG is (implicitly) executed as a free running task with Priority 1. This significantly limits the Web server's computing time. Always provide a task configuration when using Web visualization. In doing so, the call-up interval should not exceed three times the average execution time. When determining the execution time, ensure that the PLC program has reached a "steady state." When determining the execution time, ensure that the PLC program is not "steady state."
Web visualization cannot be loaded into the controller	Not all files may fit into the controller's file system. Delete any unneeded data (e.g., via FTP).
Bitmap is not displayed	If the name of an image file contains umlauts, the Web server cannot interpret these image names.
Java console reports: "Class not found"	The JRE does not find the entry point for the class "webvisu.class" in the Java archive "WebVisu.jar". The Java archive is probably incomplete. Delete "WebVisu.jar" from the Java cache and/or deactivate the cache. In this case, the controller requests the archive (applet) again. If the problem persists, reload the project into the controller.
Web visualization is static, all process values are "0"	Process data communication has failed. If Web visualization is operated over a proxy server, then a SOCKS proxy is also necessary for process data exchange in addition to the actual HTTP proxy.

8.11.3 FAQs about CODESYS Web Visualization

How can I optimize the applet for special screen resolutions?

In order to optimize the Web visualization for display on a device with a fixed resolution, proceed as follows:

In the “Target system settings”, enter the pixel width and height in the tab “Visualization”. When the visualization is created, the visible area is highlighted in gray. However, the actual pixel width and height of the Web visualization is defined by the attributes “Height” and “Width” of the HTML APPLET tag in the “webvisu.htm” file. Do not forget to also adapt these parameters to the existing resolution.

Which JRE should I use?

Java2 standard edition Version 1.5.0 (J2SE1.5.0_06) or higher is recommended. This is available free of charge at www.oracle.com.

Microsoft's MSJVM3810 was also tested. For PDAs, there are runtime environments available from other manufacturers (JamaicaVM, CrEme, etc.). Please consider that for the Web visualization, these solutions can behave differently within their scope of services (e.g., stability) than those mentioned above.

Should the Java Cache be used?

This depends on the situation. After a standard installation, the cache is enabled. If the cache is enabled, the JRE uses it to store applets and Java archives. If the Web visualization is called up a second time, it requires considerably less time to start because the applet (approx. 250 kb) does not need to be reloaded via the network, but is already available in the cache. This is especially useful when network connections are slow.

Note:

The Java archives may not be completely transferred into the cache due to network failures. In this case, the cache must be cleared manually or disabled.

Why does the visualization element “TREND” in the Web visualization only work “Online”?

The following settings must be selected for visualization projects: **Resources** tab > **Target system settings**.

Activate “Web visualization” and “Trend data recording within control”.

Otherwise, the trend data is stored on the hard drive of the CODESYS development PC. This makes a permanent connection between the controller and the CODESYS gateway necessary. If this connection is interrupted, this may lead to the controller behaving unpredictably.

In the TREND configuration dialog, you can choose between “Online” and “History” operating modes. The controller only supports the “Online” operating mode for visualization projects since it is not possible to configure the maximum size (quota) of the trend files (*.trd). Uncontrolled expansion of trend files can lead to unpredictable controller behavior.

In most cases, the use of the “HISTOGRAM” visualization element is the better choice, as this gives full control over the time and number of measurements and thus the amount of memory required.

What needs to be observed when the visualization element “ALARM TABLE” is used in the Web visualization?

The status of this component is best described as “Add-On”, i.e., an extra that is free of charge and not warranted.

The following settings must be selected for visualization projects: **Resources** tab > **Target system settings**.

Activate “Web visualization” (checkmark) and “Alarm handling within control”.

Otherwise, the alarm data is processed on the CODESYS development PC. This makes a permanent connection between the controller and the CODESYS gateway necessary. If this connection is interrupted, this may lead to the controller behaving unpredictably.

9 MODBUS

9.1 General

MODBUS is a non-vendor-specific, open fieldbus standard for a wide range of applications in production and process automation. The MODBUS communications protocol is based on a master/slave or client/server architecture that uses function codes for execution of individual MODBUS services, which have reading or writing access to individual or multiple elements of the MODBUS data model simultaneously.

9.2 Features

The MODBUS slave implemented in the PFC200 has the following features:

- 3 modes: MODBUS TCP, MODBUS UDP and MODBUS RTU, which can be run independently of one another simultaneously
- Each mode can be configured
- 10 supported MODBUS services (Function Codes): FC1 to FC6, FC15, FC16, FC22, FC23
- Data exchange via 1000 registers in each of the local MODBUS process images
- 768-byte sector that can be addressed by bits in each local MODBUS process image
- Access to a 104-kB flag sector (total of 53248 registers/words, 3328 bits of which can be addressed)
- 28 Information and configuration registers
- Up to 1000 TCP connections
- MODBUS communications monitoring using programmable watchdogs
- Configurable response on PLC stop
- Configurable response on disruption of MODBUS communication

9.3 Configuration

All of the MODBUS operating modes are configured using the CODESYS control system configuration.




Figure 92: CODESYS control system configuration - MODBUS settings

The MODBUS slave configuration is composed of four basic parameter groups:

- MODBUS settings,
- MODBUS TCP settings,
- MODBUS UDP settings,
- MODBUS RTU settings.

A detailed description of all the parameter groups is given in the following sections.

9.3.1 MODBUS Settings

The “MODBUS settings” group contains the following configuration parameters:

Table 93: MODBUS Settings

Parameters	Explanation	
PLC stop response	Response of the MODBUS slave when the control system has halted (control system in STOP state)	
	No data exchange	No data exchange possible. MODBUS requests will always be answered by the exception response "ILLEGAL FUNCTION" (0x81).
	Switch to substitute value*	Data exchange possible. Substitute values (0) are provided for MODBUS read requests and the values accepted unchanged in the local MODBUS process image for write requests, without passing these on to the control system.
	Hold last value	Data exchange possible. The last frozen values are provided for MODBUS read requests and the values accepted unchanged in the MODBUS process image for write requests, without passing these on to the control system.
Fieldbus error response	Response of the MODBUS slave on detected fieldbus errors (interruption of communication).	
	No data exchange	No data exchange possible.
	Switch to substitute value*	Data exchange possible. Substitute values (0) are supplied from the MODBUS process image for PLC read functions; for write access the values are accepted unchanged in the MODBUS process image without passing them on to the MODBUS master.
	Hold last value	Data exchange possible. The previously frozen values are supplied from the MODBUS process image for PLC read functions; for write access the values are accepted unchanged in the MODBUS process image without passing them on to the MODBUS master.

* Default setting

9.3.2 MODBUS TCP Settings

The “MODBUS TCP Settings” contains the following configuration parameters for the “MODBUS TCP” mode:

Table 94: MODBUS TCP Settings

Parameters	Explanation	
TCP mode	Enable for the MODBUS TCP mode	
	Off	Operation not permitted
	Active*	Operation possible
TCP port	Port number for the TCP link	
	1	Minimum port number
	502*	MODBUS standard port
	65535	Maximum port number
TCP time-out	Time-out for a TCP link	
	1	100 ms (1 x 100 ms)
	600*	60 seconds (600 x 100 ms)
	65535	1 h 49 min 13 s 500 ms (65535 x 100 ms)

* Default setting

9.3.3 MODBUS UDP Settings

The “MODBUS UDP Settings” group contains the following configuration parameters for the “MODBUS UDP” mode:

Table 95: MODBUS UDP Settings

Parameters	Explanation	
UDP mode	Enable for the MODBUS UDP mode	
	Off	Operation not permitted
	Active*	Operation possible
UDP port	Port number for the UDP link	
	1	Minimum port number
	502*	MODBUS standard port
	65535	Maximum port number

* Default setting

9.3.4 MODBUS RTU Settings

The “MODBUS RTU Settings” group contains the following configuration parameters for the “MODBUS RTU” mode:

Table 96: MODBUS RTU Settings

Parameters	Explanation	
RTU mode	Enable for the MODBUS RTU mode	
	Off*	Operation not permitted
	Active	Operation possible
Device ID	Device ID (device address) for the tty device	
	1*	min. device ID
	247	max. device ID
Maximum response time	Response timeout for a request in [ms]	
	2000	min. response time = 2 seconds. If this value is set lower than 2 seconds, it will be corrected internally to 2 seconds.
	5000*	Default = 5 seconds
	4294967295	max. response time > 71 hours.
Interface	Device name	
	“dev/...”	Name of the tty in the string
	“dev/ttyO0”*	Standard tty
Baud rate	Communication baud rate	
	1200 baud	1200 baud min. transmission speed
	2400 baud	2400 baud
	4800 baud	4800 baud
	9600 baud	9600 baud
	19200 baud	19200 baud
	38400 baud	38400 baud
	57600 baud	57600 baud
	115200 baud*	115200 baud, max. transmission speed
Stop bits	Number of stop bits	
	1 stop bit*	1 stop bit in the frame; must be used when even or odd parity has been selected.
	2 stop bits	2 stop bits in the frame; must be used when "None" has been selected for parity.
Parity	Parity check	
	None	No parity check performed; 2 stop bits must be selected in the configuration for this setting.
	Even*	Even parity
	Odd	Odd parity

Table 96: MODBUS RTU Settings

Parameters	Explanation	
Flow control	Data flow control (Supported only for the setting “RS-232” for the physical interface.)	
	None*	No data flow control
	RTS/CTS	Hardware flow control
Physical interface	Mode for the physical interface	
	RS-232*	RS-232 is used as the physical interface.
	RS-485	RS-485 is used as the physical interface.

* Default setting

9.4 Data Exchange

MODBUS data exchange is performed in cycles or acyclically using MODBUS services. The type and number of usable MODBUS services depends on the area that is addressed. There are generally four MODBUS-relevant address areas in the PFC200:

- **MODBUS input process image** (MODBUS Input) – is an area in the PIO (PIO = Output Process Image), in which data from the PLC is provided in cycles exclusively for MODBUS Read services.
- **MODBUS output process image** (MODBUS Output) – is an area in the PII (PII = Input Process Image), in which MODBUS Write services provide data for cyclic reading by the PLC. MODBUS Read services are also acceptable in this area.
- **MODBUS flag area** – is an area, in which both MODBUS Read and Write services can be executed.
- **MODBUS register** – is an area, in which the WAGO-specific information and configuration registers are contained. Only MODBUS register services may be executed in this area.

9.4.1 Process Image

The main data interfaces between the PLC and the MODBUS slave are the local MODBUS process images in the PLC address area based on IEC 61131. The MODBUS input process image (MODBUS Input) is in the PIO and the MODBUS output process image (MODBUS Output) in the PII. Data memory blocks of 2 kB (1000 registers/word) are available for each local MODBUS input and output process image. The first 768 bytes of each of these data blocks are also provided for executing bit services.




Figure 93: MODBUS process image

As no direct access to the I/O modules is provided by the fieldbus, data can be exchanged via this interface between the PLC and MODBUS for processing in the control system (PLC). Using this data in the individual I/O modules connected to the PLC can then be performed by the application.

9.4.2 Flag Area

MODBUS can also exchange data and fieldbus variables with the PLC via the flag area. Caution is urged, however, when using data and/or variables in this area that is accessed by both MODBUS and the PLC. This “conflicting” access is not protected from either side and could result in data inconsistency.




Figure 94: Flag area

9.4.3 MODBUS Registers

WAGO-specific registers are implemented in the last MODBUS-relevant address area; this simplifies the reading of certain system and MODBUS information, as well as configuration.

The MODBUS address area reserved for these registers ranging from the MODBUS starting address of 4096 (0x1000) up to the MODBUS end address of 12287 (0x2FFF), without any allocation to the IEC 61131 address area. These registers can be queried using the register read services FC3, FC4 and FC23 and with the register write services FC6, FC16, FC22 and FC23. A detailed description of the individual registers is given in the Section “WAGO MODBUS Registers”.

9.4.4 MODBUS Mapping

9.4.4.1 MODBUS Mapping for Write Bit Services FC1, FC2

The table below outlines the mapping for the MODBUS-reading, bit-oriented services:

- FC1 – Read Single Coil,
- FC2 – Read Discrete Inputs.

Table 97: MODBUS Mapping for Read Bit Services FC1, FC2

MODBUS Address (hexadecimal values in parentheses)	IEC 61131 Address	Description
0 ... 6143 (0x0000 ... 0x17FF)	%IX1000.0 ... %IX1383.15	MODBUS Output: 6144 PFC input bit variables in the first 384 registers/words (768 bytes) of the 2kB MODBUS output process image in the PII. Note: In this area, the read bit services return the content from the bit-addressed PII.
6144 ... 12287 (0x1800 ... 0x2FFF)	%QX1000.0 ... %QX1383.15	MODBUS Input: 6144 PFC output bit variables in the first 384 registers/words (768 bytes) of the 2 kB MODBUS-input process image in the PIO.
12288 ... 65535 (0x3000 ... 0xFFFF)	%MX0.0 ... %MX3327.15	Flag area: 53248 bit flags (6.5 kB) in the bit-addressed flag area

9.4.4.2 MODBUS Mapping for Write Bit Services FC5, FC15

The table below outlines the mapping for the MODBUS-writing, bit-oriented services:

- FC5 – Write Single Coil
- FC15 – Write Multiple Coils

Table 98: MODBUS mapping for write bit services FC5, FC15

MODBUS Address (hexadecimal values in parentheses)	IEC 61131 Address	Description
0 ... 6143 (0x0000 ... 0x17FF)	%IX1000.0 ... %IX1383.15	MODBUS Output: 6144 PFC input bit variables in the first 384 registers/words (768 bytes) of the 2kB MODBUS output process image in the PII.
6144 ... 12287 (0x1800 ... 0x2FFF)	%QX1000.0 ... %QX1383.15	MODBUS Output: MODBUS-only area for bit-oriented write access. Bit-based write services for this area are acknowledged by the MODBUS slave with the MODBUS exception code “ILLEGAL DATA ADDRESS” (0x02).
12288 ... 65535 (0x3000 ... 0xFFFF)	%MX0.0 ... %MX3327.15	Flag area: 53248 bit flags (6.5 kB) in the bit- addressed flag area

9.4.4.3 MODBUS Mapping for Read Register Services FC3, FC4, FC23

The table below outlines the mapping for the MODBUS-reading, register-oriented services:

- FC3 – Read Holding Registers,
- FC4 – Read Input Registers,
- FC23 – Read/Write Multiple Registers

Table 99: MODBUS Mapping for Read Register Services FC3, FC4, FC23

MODBUS Address (hexadecimal values in parentheses)	IEC 61131 Address	Description
0 ... 999 (0x0000 ... 0x03E7)	%IW1000 ... %IW1999	MODBUS Output: 1000 PFC input registers/words in the 2 kB MODBUS output process image in the PII. Note: In this area, the read register services return the content from the PII.
1000 ... 1999 (0x03E8 ... 0x07CF)	%QW1000 ... %QW1999	MODBUS Input: 1000 PFC output registers/words in the 2 kB MODBUS input process image in the PIO. Note on FC23: Only the Read portion of this service can be executed.
2000 ... 4095 (0x07D0 ... 0x0FFF)		Inhibited to MODBUS-only area for register-oriented read access. Register- based read services for this area are acknowledged by the MODBUS slave with the MODBUS exception code “ILLEGAL DATA ADDRESS” (0x02).
4096 ... 12287 (0x1000 ... 0x2FFF)	No IEC 61131 address	Information and configuration registers: Not all MODBUS addresses in this range are valid. Valid MODBUS addresses are described in the Section “WAGO MODBUS Registers”. Access to invalid addresses are acknowledged by the MODBUS slave with the MODBUS exception code “ILLEGAL DATA ADDRESS” (0x02). Note on FC23: The Write portion of this service can only be executed for registers that data can be written to.

Table 99: MODBUS Mapping for Read Register Services FC3, FC4, FC23

MODBUS Address (hexadecimal values in parentheses)	IEC 61131 Address	Description
12288 ... 65535 (0x3000 ... 0xFFFF)	%MW0 ... %MW53247	Flag Area: 53248 register/word flags (104 kB) in the flag area

9.4.4.4 MODBUS Mapping for Write Register Services FC6, FC16, FC22, FC23

The table below outlines the mapping for MODBUS-writing, register-oriented services.

- FC6 – Write Single Register,
- FC16 – Write Multiple Registers,
- FC22 – Mask Write Register,
- FC23 – Read/Write Multiple Registers.

Table 100: MODBUS mapping for write register services FC6, FC16, FC22, FC23

MODBUS Address (hexadecimal values in parentheses)	IEC 61131 Address	Description
0 ... 999 (0x0000 ... 0x03E7)	%IW1000 ... %IW1999	MODBUS Output: 1000 PFC input registers/words in the 2 kB MODBUS output process image in the PII.
1000 ... 1999 (0x03E8 ... 0x07CF)	No access to: %QW1000 ... %QW1999	MODBUS Output: Inhibited MODBUS area for register- oriented write access. Register-oriented write services in this area are acknowledged by the MODBUS slave with the MODBUS exception code “ILLEGAL DATA ADDRESS” (0x02).
2000 ... 4095 (0x07D0 ... 0x0FFF)		Inhibited MODBUS area for register- oriented write access. Register-oriented write services in this area are acknowledged by the MODBUS slave with the MODBUS exception code “ILLEGAL DATA ADDRESS” (0x02).
4096 .. 12287 (0x1000 ... 0x2FFF)	No IEC 61131 address	Information and Configuration Registers: Not all MODBUS addresses in this area are valid and not all registers can be written to. Valid MODBUS addresses are described in the Section “WAGO MODBUS Registers”. Access to invalid addresses are acknowledged by the MODBUS slave with the MODBUS exception code “ILLEGAL DATA ADDRESS” (0x02).

Table 100: MODBUS mapping for write register services FC6, FC16, FC22, FC23

MODBUS Address (hexadecimal values in parentheses)	IEC 61131 Address	Description
12288 ... 65535 (0x3000 ... 0xFFFF)	%MW0 ... %MW53247	Flag Area: 53248 register/word flags (104 kB) in the flag area

9.5 WAGO MODBUS Register

System and MODBUS data can be read and some MODBUS parameters configured using the WAGO MODBUS registers. The following table lists all of the WAGO MODBUS registers.

Table 101: WAGO MODBUS Registers

MODBUS Address		Data Length in Words	Access	Description
Dec.	Hex.			
4130	0x1022	1	ro	Number of registers in the MODBUS input process image in the PIO
4131	0x1023	1	ro	Number of registers in the MODBUS output process image in the PII
4132	0x1024	1	ro	Number of bits in the MODBUS input process image in the PIO
4133	0x1025	1	ro	Number of bits in the MODBUS output process image in the PII
4136	0x1028	1	ro	IP configuration: BootP(1), DHCP(2) or fixed, coded IP address(4)
4138	0x102A	1	ro	Number of established TCP connections
4144	0x1030	1	r/w	MODBUS TCP Timeout (Changes apply only to new connections)
4145	0x1031	3	ro	MAC ID of the ETHERNET interface (eth0)
4151	0x1037	1	r/w	MODBUS TCP response delay
4160	0x1040	1	ro	PLC status
4352	0x1100	1	wo	Watchdog Command
4353	0x1101	1	ro	WatchdogStatus
4354	0x1102	1	rw	Watchdog Timeout (configuration register)
4355	0x1103	1	rw	Watchdog Config (configuration register)
8192	0x2000	1	ro	0x0000 (constant)
8193	0x2001	1	ro	0xFFFF (constant)
8194	0x2002	1	ro	0x1234 (constant)
8195	0x2003	1	ro	0xAAAA (constant)
8196	0x2004	1	ro	0x5555 (constant)

Table 101: WAGO MODBUS Registers

MODBUS Address		Data Length in Words	Access	Description
Dec.	Hex.			
8197	0x2005	1	ro	0x7FFF (constant)
8198	0x2006	1	ro	0x8000 (constant)
8199	0x2007	1	ro	0x3FFF (constant)
8200	0x2008	1	ro	0x4000 (constant)
8208	0x2010	1	ro	Revision (Firmware Index)
8209	0x2011	1	ro	Series code
8210	0x2012	1	ro	Device code
8211	0x2013	1	ro	Major Firmware Version
8212	0x2014	1	ro	Minor Firmware Version
8213	0x2015	1	ro	MBS Version

The WAGO MODBUS registers are described in more details in the following sections.

9.5.1 Process Image Properties

9.5.1.1 Register 0x1022 – Number of Registers in the MODBUS Input Process Image

This register contains the number of registers available in the MODBUS input process image (MODBUS input).

9.5.1.2 Register 0x1023 – Number of Registers in the MODBUS Output Process Image

This register contains the number of registers available in the MODBUS output process image (MODBUS output).

9.5.1.3 Register 0x1024 – Number of Bits in the MODBUS Input Process Image

This register contains the number of bits available in the MODBUS input process image (MODBUS input).

9.5.1.4 Register 0x1025 – Number of Bits in the MODBUS Output Process Image

This register contains the number of bits available in the MODBUS output process image (MODBUS output).

9.5.2 Network Configuration

9.5.2.1 Register 0x1028 – IP Configuration

This register contains information about the set IP configuration.

Possible values:

- 1 = BootP
- 2 = DHCP
- 4 = Fixed IP address

9.5.2.2 Register 0x102A – Number of Established TCP Connections

This register supplies the number of established TCP connections.

The maximum number of MODBUS TCP connections is 1000.

9.5.2.3 Register 0x1030 – MODBUS TCP Socket Timeout

This register contains the timeout value for the TCP sockets.

This value is given in units of 100ms (ticks). A new value is accepted only for new connections which have not yet been established. In the event of any changes, pre-established connections will continue to operate using the previously set timeout value.

9.5.2.4 Register 0x1031 – MAC Address for ETHERNET-Interface 1 (eth0)

This register provides the MAC address for the first ETHERNET interface (eth0). MAC may also provide a partial result.

9.5.2.5 Register 0x1037 - MODBUS TCP Response Delay

This register saves the value of the MODBUS response delay.

This value is specified in ms units. The maximum delay is 32 ms, default value is 0 ms (no delay). Transmission of the response to a MODBUS request is delayed from the time of processing (read and/or write register values) by the time set. In the meantime, incoming requests can only be processed when the previous response is sent. For MODBUS UDP, this applies to all requests and for MODBUS TCP, for each connection. The actual length of time between a MODBUS request and the associated response depends on the number of parallel requests overall system utilization; it is always greater than the response delay set. Changes to the response delay become effective immediately for each subsequent request.

9.5.3 PLC Status Register

Register 0x1040 provides the status (state) that the controller is currently in.
Possible values:

- 1 = PLC running – PLC status is RUNNING.
- 2 = PLC stopped – PLC status is STOPPED.

9.5.4 MODBUS Watchdog

The MODBUS watchdog monitors ongoing MODBUS communication. In the event that the configured monitoring time (see “Watchdog Timeout” Register) is exceeded without one single valid MODBUS query (trigger) being received from a MODBUS slave, the watchdog reacts and initiates the “Watchdog Timeout” reaction (previously configured in the “Watchdog Config” register). The watchdog must be continuously triggered by the MODBUS master to ensure that the set monitoring time does not expire. Triggering is performed by receiving any arbitrary MODBUS query from the entire volume of services supported by the MODBUS slave. These MODBUS-slave-supported services are listed in the Section “MODBUS Mapping”. The Explicit Trigger Mode is an exception to this rule and is elucidated in detail in the description of the “MODBUS Config” register (0x1103).

9.5.4.1 Register 0x1100 – Watchdog Command

This register receives commands for the MODBUS watchdog.
The following commands are accepted:

Table 102: Watchdog Commands

Value	Name	Explanation
0x5555	WATCHDOG_START	Starts the watchdog
	Error-free response	Watchdog has been successfully started, or restarted, and has the status "Running".
	Error response	ILLEGAL FUNCTION (0x01) ILLEGAL DATA VALUE (0x03)
0x55AA	WATCHDOG_STOP	Stops the watchdog
	Error-free response	Watchdog was stopped successfully and has the status "Stopped".
	Error response	ILLEGAL FUNCTION (0x01) ILLEGAL DATA VALUE (0x03)
0xAAAA	WATCHDOG_RESET	Resets the watchdog after a timeout
	Error-free response	Watchdog was reset successfully and has the status "Stopped" or "Unconfigured" when the "Watchdog Timeout" register (0x1102) contains the value 0.
	Error response	ILLEGAL DATA VALUE (0x03)

The watchdog is only started by the command WATCHDOG_START. A prerequisite for successful startup is a valid timeout value in the "Watchdog Timeout" register (0x1102) and the status "Stopped" or "Running" (for restart), which the watchdog must have (see "Watchdog Status" register 0x1101). A response of ILLEGAL_DATA_VALUE indicates that the watchdog has not yet been configured (status "Unconfigured", timeout value is "0"). If the watchdog has the status "Expired", the WATCHDOG_START command is also rejected by the ILLEGAL_FUNCTION acknowledgement.

A running watchdog can be stopped by the command WATCHDOG_STOP. A stop request received several times in a row does not have any impact on the behavior of the watchdog and is therefore not acknowledged with an error response. By contrast, a stop command received when the watchdog has the status "Unconfigured" is rejected with the acknowledgement ILLEGAL_DATA_VALUE; if the watchdog has the status "Expired" this command is rejected by the exception code ILLEGAL_FUNCTION.

If the watchdog monitoring time has expired, the watchdog can only be reset by the command WATCHDOG_RESET. The watchdog cannot be restart until this

command is executed. Resetting the watchdog does not necessarily restart it automatically, however. To restart the watchdog after a reset, the command WATCHDOG_START must be sent. Possible reactions to expiring of the watchdog monitoring time (timeout) are described in the “Watchdog Config” register (0x1102). If the command WATCHDOG_RESET is received when the watchdog has a status other than “Expired”, this command is rejected with the exception code ILLEGAL_DATA_VALUE.

9.5.4.2 Register 0x1101 – Watchdog Status

This register provides the current status of the MODBUS watchdog. The watchdog can have any of the four following statuses:

Table 103: Watchdog Status

Value	Name	Explanation
0xFFFF	WATCHDOG_UNCONFIGURED	Watchdog not configured, i.e., the watchdog time-out register (0x1102) contains the value 0.
0x0000	WATCHDOG_STOPPED	Watchdog is not active (not started).
0x0001	WATCHDOG_RUNNING	Watchdog is active (started).
0x0002	WATCHDOG_EXPIRED	Watchdog monitoring time has expired.

If the “Watchdog Timeout” register (0x1102) contains the value 0, the Watchdog has not been configured – WATCHDOG_UNCONFIGURED. If the timeout value remains unchanged (0), the Watchdog cannot leave this state. After a configuration, the Watchdog switches to “Stopped” and can now be started.

The watchdog can only be started by the command WATCHDOG_START. When the watchdog is started, it assumes the status “Running” - WATCHDOG_RUNNING. Configuration changes in this state are no longer possible.

When the watchdog expires (status WATCHDOG_EXPIRED), the registers “Watchdog Status” (0x1101), “Watchdog Timeout” (0x1102) and “Watchdog Config” (0x1103) are the only registers that can be read. Access to other registers, with the exception of write access to the “Watchdog Command” register (0x1100), and bit access is acknowledged by the error ILLEGAL_FUNCTION.

The configuration registers can only be written in the watchdog statuses WATCHDOG_UNCONFIGURED, WATCHDOG_STOPPED or WATCHDOG_EXPIRED. Only read access is permitted for these registers in the status WATCHDOG_RUNNING.

9.5.4.3 Register 0x1102 – Watchdog Timeout

This configuration register contains the watchdog timeout value. As the basic unit is 100 ms, the timeout value must be a multiple of 100 ms. Thus, the minimum timeout value can be set to 100 ms, while the maximum value can be set to 6553.5 seconds. If this value is 0, the watchdog cannot be started and will have the status

“Unconfigured”. The watchdog timeout register can be rewritten to the states “Unconfigured”, “Stopped” or “Expired”. Access to this register is read only while the watchdog is active.

9.5.4.4 Register 0x1103 – Watchdog Config

This register contains the configuration parameters for the watchdog. The following parameters can be configured:

Table 104: Watchdog Configuration

Bit	Name/Bit Identifier	Explanation
0	Explicit triggering EXPLICIT_ TRIGGER_ONLY	Controls explicit triggering
		0 All supported MODBUS queries are considered watchdog triggers (default setting). There is a special rule for the “Watchdog Status” register. See the description for bit 1 EXPLICIT_TRIGGER_ON_STATUS_REG.
1	Triggering by access to the watchdog status register TRIGGER_ON_STATUS_REG	1 Explicit Trigger Mode – only the command WATCHDOG_START (0x5555), sent to the “Watchdog Command” register (0x1100), or reading of the “Watchdog Status” registers (0x1101), when Bit 1 EXPLICIT_TRIGGER_ON_STATUS_REG has been set accordingly, are considered valid trigger events for the MODBUS watchdog.
		0 Read access to the “Watchdog Status” register is not considered a trigger event (default setting).
2	Close-down of established TCP connections CLOSE_ALL_TCP_CONNECTIONS	Controls triggering by read-only access to the “Watchdog Status” register
		1 Read access to the “Watchdog Status” register is considered a trigger event.
		Closes down all established TCP connections
		0 All established connections remain open.
		1 All established connections are closed (default setting).

The individual options are activated when the specific bit, or bit combination, is set.

The “Watchdog Config” register can be rewritten to the statuses “Unconfigured”, “Stopped” or “Expired”. Access to this register is read only while the watchdog is active.

9.5.5 MODBUS Constants Register

Registers 0x2000 ... 0x2008 provide constants based on the table “WAGO MODBUS Register”. It is possible to read all of the constants, or a consecutive portion of them, at once.

9.5.6 Electronic Nameplate

Registers 0x2010 to 0x2015 contain information from the electronic nameplate. It is possible to read the entire nameplate, or a consecutive portion of it, all at once.

9.5.6.1 Register 0x2010 – Revision (Firmware Index)

This register provides the consecutive revision index (firmware index) for the PFC200.

Example: 5 for Version 5.

9.5.6.2 Register 0x2011 – Series Designator

This register provides the designation for the WAGO series (Series Code) of the PFC200.

Example: 750 for WAGO-I/O SYSTEM 750.

9.5.6.3 Register 0x2012 – Device ID

This register provides the device ID (WAGO Item No.) of the controller.

Example: 8206.

9.5.6.4 Register 0x2013 – Major Firmware Version

This register provides the major part for the firmware version.

9.5.6.5 Register 0x2014 – Minor Firmware Version

This register provides the minor part for the firmware version.

9.5.6.6 Register 0x2015 – MBS Version

This register provides the version of the MODBUS slave library. The high byte contains the major version number and the low byte, the minor version number.

Example:

0x010A => Major version number = 1, Minor version number = 10.

9.6 Diagnostics

9.6.1 Diagnostics for the MODBUS Master

The status of the PLC, or of the control system, can be queried by the MODBUS master by reading the WAGO-specific register 0x1040 – “PLC Status” using MODBUS services FC3 (Read Holding Registers) or FC4 (Read Input Registers). The WAGO-specific register 0x1040 – “PLC Status” is explained in the Section “PLC Status Registers”.

The status of the MODBUS Watchdog can be requested using a register service (FC3 or FC4) with a query to the WAGO-specific register 0x1101 – “Watchdog Status Register”. Information about this is given in the Section “MODBUS Watchdog”.

The MODBUS service “Get Communication Event Counter” (FC11) is not supported in the current MODBUS slave Version V1.0.

9.6.2 Diagnostics for the Runtime System

Diagnostics for the MODBUS slaves can be executed by integrating the CODESYS library “BusDiag.lib” via the runtime system. The required function block, “DiagGetBusState() indicates the status of the fieldbus (here MODBUS) and is located in this library. Details about this function block are provided both in this document and in the online Help function for CODESYS.

9.6.3 Diagnostics for the Error Server

The MODBUS slave also supports the error service implemented in the PFC and generates diagnostic messages, which are stored permanently (in a file), or temporarily (in the RAM) and can be displayed directly via the WBM client. The following diagnoses are generated by the MODBUS slave:

Table 105: Diagnostics for the Error Server

Diagnosics ID	Diagnostic text	Method of saving	Explanation
0x00090000	Modbus Slave library loaded	Temporary	MODBUS slave library has been successfully loaded.
0x00090001	Modbus Slave library closed	Temporary	MODBUS slave library has been successfully unloaded.
0x00090002	Modbus Slave TCP started	Temporary	MODBUS slave successfully started in TCP mode.
0x00090003	Modbus Slave TCP start failed	Permanent	Starting the MODBUS slave in the TCP mode failed.
0x00090004	Modbus Slave TCP terminated	Temporary	MODBUS slave TCP mode successfully terminated.
0x00090005	Modbus Slave UDP started	Temporary	MODBUS slave successfully started in UDP mode.
0x00090006	Modbus Slave UDP start failed	Permanent	Starting the MODBUS slave in UDP mode failed.

Table 105: Diagnostics for the Error Server

Diagnostics ID	Diagnostic text	Method of saving	Explanation
0x00090007	Modbus Slave UDP terminated	Temporary	MODBUS slave UDP mode successfully terminated.
0x00090008	Modbus Slave RTU started	Temporary	MODBUS slave successfully started in the RTU mode.
0x00090009	Modbus Slave RTU start failed	Permanent	Starting the MODBUS slave in RTU mode failed.
0x0009000A	Modbus Slave RTU terminated	Temporary	MODBUS slave RTU mode successfully terminated.
0x0009000B	Modbus Slave data exchange started by PLC	Temporary	MODBUS slave data exchange started.
0x0009000C	Modbus Slave data exchange stopped by PLC	Temporary	MODBUS slave data exchange stopped.
0x0009000F	Modbus Slave PLC watchdog timer expired	Permanent	Monitoring time for controller (PLC) expired.
0x00090100	Modbus Slave common configuration failed.	Permanent	MODBUS slave configuration failed.
0x00090101	Modbus Slave TCP configured successfully.	Temporary	MODBUS slave TCP configuration completed successfully.
0x00090102	Modbus Slave TCP configuration failed.	Permanent	MODBUS slave TCP configuration failed.
0x00090103	Modbus Slave UDP configured successfully	Temporary	MODBUS slave UDP configuration completed successfully.
0x00090104	Modbus Slave UDP configuration failed.	Permanent	MODBUS slave UDP configuration failed.
0x00090105	Modbus Slave RTU configured successfully.	Temporary	MODBUS slave RTU configuration completed successfully.
0x00090106	Modbus Slave RTU configuration failed	Permanent	MODBUS slave RTU configuration failed.
0x00090107	Port for Modbus Slave RTU operation not free.	Permanent	Serial port for MODBUS slave RTU configuration already occupied.

Table 105: Diagnostics for the Error Server

Diagnostics ID	Diagnostic text	Method of saving	Explanation
0x00090108	Modbus Slave RTU configuration in RS-485 mode failed.	Permanent	MODBUS slave RTU configuration for the RS-485 mode has failed.
0x00090200	Modbus Slave Watchdog activated.	Temporary	MODBUS watchdog activated.
0x00090201	Modbus Slave Watchdog deactivated.	Temporary	MODBUS watchdog deactivated.
0x00090202	Modbus Slave Watchdog Timer expired.	Permanent	MODBUS watchdog monitoring time expired.
0x00090203	Modbus Slave has terminated all established TCP connections.	Permanent	All MODBUS TCP connections terminated due to timeout.
0x00090300	Modbus Slave: obtaining system resource failed	Permanent	Request for system resources by the MODBUS slave has failed.
0x00090301	Modbus Slave: processing system resource failed.	Permanent	Access to system resources by the MODBUS slave has failed.

10 CANopen Master and Slave

Based on IEC 61131-3 programming, data processing occurs on site in the controller. The process results can be output directly to the actuators, or transmitted via the bus.

Process data is exchanged with PDOs and SDOs. The controller supports 512 TX PDOs and 512 RX PDOs and SDOs to send process data via the CANopen fieldbus.

In the local process image, a range of 4000 bytes serves as each input and output range for data exchange via the CANopen interface. This range is situated between the addresses 6000 to 9999. Direct access to the I/O modules via the fieldbus is not provided.

All entries of the object directory can be mapped as required to the RX PDOs and TX PDOs. The complete input and output process image can be transmitted via SDOs.

10.1 Object Directory

All communication objects and all user objects are compiled in the object directory. The figure below provides a rough overview of this:

Table 106: Overview of addresses in the object directory

Index Range	Use
0000	Not used
0001-009F	Data types
00A0-0FFF	Reserved (addresses used for other services)
1000-1FFF	Communication profile
2000-5FFF	Vendor-specific range
6000-9FFF	Up to eight standardized device profiles
A000-AFFF	Process images from IEC 61131 devices
B000-BFFF	Process images from CANopen gateways acc. CiA 302-7
C000-FFFF	Reserved

The objects, which are made available by the controller, are described below.

10.2 Communications Profile

0x1000 Device Type

The stack responds on the bus as the DS-405 device (IEC 61131-3 programmable device), regardless of being configured as the master or slave. As direct access to the I/O modules via the bus is prohibited, the bits for information about inputs and outputs are 0.

Entry 0x000191 = DS 405 for master and slave

0x1001 Error Register

This entry contains an 8-bit item of information about the error status. At present, bit 4 is used specifically for communication and bit 5 for the device profile. Bit 0 is set for each error.

0x1003 Pre-defined Error Field

This entry contains the list of accumulated errors which were signaled in error register 0x1001. Sub-index 0 contains the number of entries. If a new error occurs, it is added to sub-index 1 and all existing errors are moved down one sub-index. A maximum of 20 error entries is supported. If more than 20 errors occur, the error at sub-index 20 is overwritten. By writing a “0” into sub-index 0, the complete error memory is deleted.

Standard values: 0 in all entries

0x1005 COB ID Sync

This object defines the COB ID for the synchronization message.

Default: 0x80

0x1006 Communication Cycle Period

The duration of the synchronization cycle given in μs , or 0 for cyclic synchronization. Internal resolution is 1 ms. If this value is 0, SYNC monitoring does not occur.

Default: 0

0x1008 Manufacturer Device Name

This object specifies the device name.

Entry: Item No. for the PFC200, e.g., “750-8206”

0x1009 Manufacturer Hardware Version

Entry: “V 1.0” or higher

0x100A Manufacturer Software Version

Entry: “V 1.00” or higher

0x100C Node Guarding Time

The object specifies the “Guarding Time” in milliseconds. An NMT master requests the state of the NMT slave in a cyclical manner. The time between two requests is the “Guarding Time.”

Default: 0 (Node guarding disabled)

0x100D Life Time Factor

The “Life Time Factor” is part of the node guarding protocol. The NMT slave checks whether it was queried within the node lifetime (guarding time multiplied by the lifetime factor). If not, the slave must assume that the NMT master is no longer in normal operation; it then initiates a “life guarding event”.

Default: 0 (Node guarding off)

0x1012h COB-ID Time Stamp Object

The time stamp object enables every device's clock on the bus to be synchronized. The ID for this object is indicated here. Although the synchronization signal is not evaluated by the runtime, it may be used with library functions.

Default: 0x100 (Time Stamp Consumer)

0x1014h Emergency COB ID

An emergency message is transmitted in the event of CANopen device errors. The ID for this object is indicated here.

Default: 0x80 + Device ID

0x1015h Emergency Inhibit Time

This object specifies the minimum time that must elapse before another emergency object is sent. An entry equal to zero disables delayed sending. One time unit amounts to 100µs.

Default: 0

0x1016h Consumer Heartbeat Time

This entry can be used for monitoring of other devices on the bus. A check is made to determine whether each module defined in this object has generated a heartbeat within the set time. If the set time has been exceeded, a heartbeat event is triggered. The "Heartbeat Time" is entered in milliseconds. If the time is 0, monitoring is deactivated. The number of devices to be monitored is entered in index 0, the heartbeat time is entered in ms in the bottom 16 bits and the ID of the bus device in the 8 bits above that.

Default:

Index 0: 0 (currently still 127 = Number of possible entries)

All other entries are 0 (this function is not yet supported by the CAN master in Firmware 1.0).

0x1017h Producer Heartbeat Time

This object defines the time (in milliseconds) between two transmitted heartbeat messages. No heartbeat is sent if the time is set to 0.

Default: 0

0x1200, 0x1201 Server SDO Parameter Channels

The communication parameters for an SDO as the server are entered here. Two server SDO channels are supported.

0x1280 ... 0x128E Client SDO Parameter Channels

The communication parameters for an SDO transfer as the client are entered here. 16 client SDO channels are supported.

0x1018h Identity

This object specifies the device being used. The manufacturer ID contains a unique number for each vendor. WAGO has been assigned an ID of 33. The device description reflects the family of products used.

The Rev. No. contains a specific CANopen behavior. The Major Rev. No. contains the CANopen functionality. If the functionality is changed, the Major Rev. No. is increased. You can use the Minor Rev. No. to distinguish between different versions with the same CANopen behavior.

Sub-index 0 No. of entries: 4

Sub-index 1 vendor ID: 33

Sub-index 2 product_code: e.g., 8206 for 750-8206

Sub-index 3 revision_number: 0x00010001 or higher

Sub-index 4 serial_number corresponds to the last 4 bytes of the MAC address.

0x1029h Error Behavior

This object defines how the slave responds in the event of an error.

Sub-Index Sub-index 0 No. of entries: 1

Sub-Index 1 Communication Error:

1	No change (Standard)
0	Change from operational to preoperational
2	Change to stop

0x1F51 Program Control

The status of the PLC can be read out using this object. Writing is prohibited.

Entries: 0 = Stop 1 = Run 2 = Reset 3 = Clear

10.2.1 Master Configuration

These objects are only available at the bus end when the master has been configured.

0x102A NMT Inhibit Time

This object indicates the minimum time that must elapse before another NMT telegram is sent. An entry equal to zero deactivates delayed sending. One unit of time is 100 μ s.

Default: 0

0x1F80 NMT Start-up

This object contains the configuration bits for the master status. If automatic startup is deactivated, the master can be started by writing of 0x1F to this object.

0x1F81 ... 0x1F8A Slave Configuration

The configured slaves are entered in these lists. All of the entries are checked when the master is started and transferred to the slaves.

0x1F81 NMT Slave-Assignment

Sub-Index 0: 127 = Number of possible entries

Sub-Index 1 ... 127

- Bit 0: Slave available
- Bit 2: Slave required for start
- Bit 3: Slave reset performed on start
- Bit 8 ... 15: Guard Retry Factor
- Bit 16 ... 31: Guard Time

0x1F82 Request-NMT

Sub-Index 0: 127 = Number of possible entries

Sub-Index = Master Node ID NMT state of the master

0x1F84 Device Type Identification

Sub-Index 0: 127 = Number of possible entries

Sub-Index 1 ... 127: Slave device type

0x1F85 Vendor Identification

Sub-Index 0: 127 = Number of possible entries

Sub-Index 1 ... 127: Slave device type (not used by default)

0x1F86 Product Code

Sub-Index 0: 127 = Number of possible entries

Sub-Index 1 ... 127: Slave device type (not used by default)

0x1F87 Revision number

Sub-Index 0: 127 = Number of possible entries

Sub-Index 1 ... 127: Slave device type (not used by default)

0x1F88 Serial Number

Sub-Index 0: 127 = Number of possible entries

Sub-Index 1 ... 127: Slave device type (not used by default)

0x1F89 Boot Time

Time in ms between the start of slaves and operational readiness of all slaves.

Default: 0 = deactivated

0x1F8A Restore Configuration

Sub-Index 0: 127 = Number of possible entries

Sub-Index 1 ... 127: Bit 0 = 1 Send restore configuration to slave on start

10.3 Data Exchange

Process data exchange occurs via the communication objects with the CANopen fieldbus controller.

Each object consists of a CAN telegram with a maximum of 8 bytes process data and a COB (Communication Object Identifier) ID that is unique within the network.

These communication objects transmit data, trigger events, signal error statuses, etc.

The parameters required for the communication objects, as well as CANopen device parameters and data are stored in an object directory.

10.3.1 Controller Communication Objects

The PFC200 supports the following communication objects:

512 Tx-PDOs for process data exchange from input data of the fieldbus node

- 512 Rx-PDOs for process data exchange from output data of the fieldbus node
- Synchronization objects (SYNC) for network synchronization
- Emergency objects (EMCY)
- Network management objects
 - Module Control Protocols
 - Error Control Protocols
 - Boot-up Protocol

10.3.2 Fieldbus-Specific Addressing

The CODESYS variable for the CAN bus (%QB6000 ... %QB9999 and %IB6000 ... %IB9999) are mapped to an object directory after configuring the CAN interface as a master or slave (initialization). A CANopen fieldbus device uses the 16-bit indices and 8-bit sub-indices of the object directory to address data via PDOs or SDOs and to access the data. The position of the data in the process image is therefore not directly significant for the CANopen user at the fieldbus end.

The variables entered into the object directory are distinguished by data type (Integer8, Unsigned8, Boolean, Integer16, etc.) and by input/output. Access via PDOs can be either for reading or writing. Direct access via SDO can be read-only.

As CANopen does not transfer data by bits, the variable data is combined from a Boolean data type to bytes and assigned to the corresponding index; Boolean input variable data is assigned to index 0xA080, Boolean output variable data to index 0xA500.

Variable data that has a data width of 1 byte or more is assigned to the corresponding indices in a similar manner.



Note

Observe the direction of data flow!

The IEC 61131-3 input variables are defined from the perspective of the CAN bus. These are output variables from the perspective of the PFC. Accordingly, the IEC 61131-3 output variables are input variables for the PFC.

This table provides an overview of the indices of “IEC 61131-3” variables.

Table 107: Indexing of “IEC 61131-3” Variable Data in the Object Directory

Data Type	IEC 61131-3 Output Variables	IEC 61131-3 Input Variables
	Index	
Integer8	0xA000	0xA480
Unsigned8	0xA040	0xA4C0
Boolean	0xA080	0xA500
Integer16	0xA0C0	0xA540
Unsigned16	0xA100	0xA580
Integer24	0xA140	0xA5C0
Unsigned24	0xA180	0xA600
Integer32	0xA1C0	0xA640
Unsigned32	0xA200	0xA680
Float32	0xA240	0xA6C0
Unsigned40	0xA280	0xA700
Integer40	0xA2C0	0xA740
Unsigned48	0xA300	0xA780
Integer48	0xA340	0xA7C0
Unsigned56	0xA380	0xA800
Integer56	0xA3C0	0xA840
Integer64	0xA400	0xA880
Unsigned64	0xA440	0xA8C0

Using the associated indices for data types with a data width of 1 byte (Integer8, Unsigned8 and Boolean), read-only byte-by-byte access is possible from the fieldbus to data in the controller memory.

The sub-index is utilized to select a specific byte.

In contrast, when the indices for larger data blocks are used, several bytes can be accessed simultaneously.

For example, the described PFC output variable data can be accessed in a word-by-word manner using the index for Integer16 (0xA0C0) or for Unsigned16 (0xA100), three bytes can be accessed using index 0xA140 for Integer24, etc.

Example:

The first three bytes of the PFC output data for the data type integer or unsigned are accessed from the fieldbus:

Table 108: Fieldbus access to PFC output data

Access	PFC Output Data	Reading with Index (Integer / Unsigned)	Sub-Index
By byte (with Integer8 / Unsigned8)	Byte 6000	(0xA000 / 0xA040)	1
	Byte 6001	(0xA000 / 0xA040)	2
	Byte 6002	(0xA000 / 0xA040)	3
By word (with Integer16 / Unsigned16)	Word 3000 (Byte 6000/6001)	(0xA0C0 / 0xA100)	1
	Word 3001 (Byte 6002/6003)	(0xA0C0 / 0xA100)	2
3 Bytes (with Integer24 / Unsigned24)	Bytes 6000 ... 6002	(0xA140 / 0xA180)	1

The following tables give an overview of addressing data with different data widths.

In this case, the corresponding indexing is assigned to the memory space for fieldbus variables (byte 6000 to byte 9999) as a function of the data width.

The indexing indicated in the tables continues up to the respective maximum index and sub-index.

Note



Observe the direction of data flow!

The PFC output variables are defined from the perspective of the controller; from the perspective of the CAN fieldbus these are input variables. Accordingly, the PFC input variables for IEC 61131-3 access are output variables for the fieldbus.

Thus: IEC 61131-3 input variable = PFC output variable

PFC input variable = IEC 61131-3 input variable.




Figure 95: Correlation between “IEC 61131-3” variables and PFC variables

10.3.3 Examples for the Definition of PFC Fieldbus Variables

The examples below show the allocation of several definitions for PFC variables with different data types to the associated object directory entries.

10.3.3.1 CODESYS Access to PFC Variables

Table 109: Examples for CODESYS access to PFC variables

Data Type of PFC Variables	PFC Input Variables		PFC Output Variables	
	Definition based on IEC 61131-3	Index/sub-index	Definition based on IEC 61131-3	Index/sub-index
Unsigned8	InByte0 AT %IB6000: BYTE;	0xA4C0/1	OutByte0 AT %QB6000: BYTE;	0xA040 /1
	InByte0 AT %IB6001: BYTE;	0xA4C0/2	OutByte0 AT %QB6001: BYTE;	0xA040 /2
Integer16	InInt0 AT %IW3000: INT;	0xA540 /1	OutInt0 AT %QW3000: INT;	0xA0C0/1
	InInt1 AT %IW3001: INT;	0xA540 /2	OutInt1 AT %QW3001: INT;	0xA0C0/2
Unsigned16	InWord0 AT %IW3000: WORD;	0xA580 /1	OutWord0 AT %QW3000: WORD;	0xA100 /1
	InWord0 AT %IW3001: WORD;	0xA580 /2	OutWord0 AT %QW3001: WORD;	0xA100 /2
Unsigned32	InDWord0 AT %ID1500: DWORD;	0xA680 /1	OutDWord0 AT %QD1500: DWORD;	0xA200 /1
	InDWord0 AT %ID1501: DWORD;	0xA680 /2	OutDWord0 AT %QD1501: DWORD;	0xA200 /2

10.3.3.2 Maximum Indices

The maximum indices and sub-indices are yielded from the memory size of the fieldbus controller at 4000 bytes and the corresponding data width for the data types.

The table below provides an overview of the maximum indices and sub-indices of the IEC 61131-3 variables.

Table 110: Maximum indices and sub-indices for “IEC 61131-3” variables

Data Type	IEC 61131-3 Input Variables		IEC 61131-3 Output Variables	
	Max. Index	Max. sub-index	Max. Index	Max. sub-index
Integer8	0xA00F	0xFF	0xA487	0xFF
Unsigned8	0xA04F	0xFF	0xA4C7	0xFF
Boolean	0xA08F	0xFF	0xA507	0xFF
Integer16	0xA0C7	0xFF	0xA543	0xFF
Unsigned16	0xA107	0xFF	0xA583	0xFF
Integer24	0xA145	0x55	0xA5C0	0x55
Unsigned24	0xA185	0x55	0xA600	0x55
Integer32	0xA1C3	0xFF	0xA643	0xFF
Unsigned32	0xA203	0xFF	0xA683	0xFF
Float32	0xA243	0xFF	0xA6C3	0xFF
Unsigned40	0xA283	0x33	0xA703	0x33
Integer40	0xA2C3	0x33	0xA743	0x33
Unsigned48	0xA302	0xAA	0xA780	0xAA
Integer48	0xA342	0xAA	0xA7C0	0xAA
Unsigned56	0xA382	0x49	0xA802	0x49
Integer56	0xA3C2	0x49	0xA842	0x49
Integer64	0xA401	0xFF	0xA880	0xFF
Unsigned64	0xA441	0xFF	0xA8C0	0xFF

Example:

514 bytes of output variables are addressed by word by the data type Unsigned16.

Addressing of 257 data words then occurs with:

- Index 0xA580, sub-index 1 to 255
- Index 0xA581, sub-index 1 and 2.

Table 111: Example of “IEC 61131-3” output variables

Index	Sub-Index	Contents	Description
0xA580	1	D1 *)	1st output variable block
	2	D2 *)	2nd output variable block

	255	D255 *)	255th output variable block
0xA581	1	D256 *)	256th output variable block
	2	D257 *)	257th output variable block

*) D1 = Data word output variable 1, D255 = Data word output variable 255, etc.

10.3.4 CANopen Master Control Configuration

Note



Calling up the addresses or the symbolic name of the inputs and outputs
Addresses or symbolic names of the inputs and outputs have to be called up explicitly, otherwise the process image is not updated. Alternatively, you can also create an array of max. 240 bytes at the memory addresses IB%6000 or QB%6000. This array has to be called up in the PLC program.

An application must be configured in CODESYS before it can access the connected CAN network.

10.3.4.1 Selecting the Master

To add the CANopen Master to the control configuration, right-click “COS unused[Slot]” and select “Replace element -> CANopen Master”.




Figure 96: Adding the CANopen master

10.3.4.2 Setting the Master Parameters

No input should be made on the Basic parameters tab.

The screenshot shows a configuration window with two tabs: 'Base parameters' and 'CAN parameters'. The 'CAN parameters' tab is active. The following parameters are visible:

- Module id: 5
- Node id: 2
- Input address: %IB6000
- Output address: %QB6000
- Diagnostic address: %MB6000
- Comment: (empty text box)

Figure 97: Master basic parameters tab

Table 112: Description of Basic Parameters

Parameters	Explanation
Module ID	Parameters that use the runtime system CODESYS.
Node ID	
Input address	
Output address	
Diagnostic address	
Comment	Input field for comments.

Normally, you must only check the baud rate on the CAN parameters tab.

Figure 98: Master CAN Parameters tab

Table 113: Description of the CAN parameters

Parameters	Explanation
Baud rate	Specify the baud rate that will apply to the transfer on the CAN bus (default setting: 125000 baud).
Com. Cycle Period (µsec)	Specify the time interval (in µsec) that the synchronization notification will be sent by the controller. Smallest time interval: 1000 µsec
Sync. Window Length (µsec)	Not currently implemented.
Sync. COB-ID	You can enable or disable sending of synchronization notification by the controller. Default setting: COB ID 128 (0x80).
Node ID	Station address (node ID) of the controller on the CAN bus.
Start automatically	When you mark this check box, the controller automatically sets the CAN master and slaves to the “Operational” based on the defined parameters. If you do not mark this check box, starting can be performed using the CIA405NMT library command.

Table 113: Description of the CAN parameters

Parameters	Explanation
Support ... DSP 301	If you mark this check box, modular CAN slaves as well as additional extensions adhering to the DSP301 V3.01 and DSP 306 standards are supported by the control configuration.
Heartbeat Master	If the “Heartbeat Generation” option is enabled, the CAN device transmits heartbeats in ms intervals specified in “Heartbeat Producer Time”. Heartbeat consumption is not currently implemented.

10.3.4.3 Adding Slaves

To select one (or several) CANopen slaves, right-click on the CANopen master and select “Attach subelements”. In this example, the 750-337 was selected as the slave.

Note



EDS Files

The EDS files for current components of the WAGO-I/O-SYSTEM are integrated in the target files for the controller. The associated EDS files are required for incorporation of non-WAGO devices. For this, click “Tools” > “Add configuration file” in the menu bar.




Figure 99: Adding a CANopen slave

No input must be made on the Basic parameters tab.




Figure 100: Basic parameters tab

Table 114: Description of Basic Parameters

Parameters	Explanation
Module ID	Recognition of the slave.
Node ID	Node number of the slave used in the CODESYS runtime environment.
Input address	Starting address for the input data: The address space always begins at %IB 6000 and is assigned automatically.
Output address	Starting address for the output data: The address space always begins at %QB 6000 and is assigned automatically.
Diagnostic address	Memory area for internal diagnostic processing.
Comment	Input field for comments.

Normally, you must only check the Node ID on the CAN parameters tab.

The screenshot shows a software interface with four tabs: "Base parameters", "CAN parameters", "CAN Module Selection", and "Receive PDO-Mapping". The "CAN parameters" tab is active. It contains several sections:

- General:** Node ID: 2; Write DCF: ; Create all SDO's: ; Reset Node: ; MappingSDOs: ; CommSDOs: ; BasicSDOs: .
- Node guard:** Nodeguarding; Guard COB-ID: 0x700+NodeID; Guard time (ms): 0; Life time factor: 0; Info... button.
- Heartbeat settings:** Activate heartbeat generation; Heartbeat producer time: 0 ms; Activate heartbeat consumer.
- Emergency telegram:** Emergency; COB-ID: \$NodeID+0x80.
- Communication Cycle:** Cycle; Period (µsec): 0.

Figure 101: CAN parameters tab

Table 115: Description of the CAN parameters

Parameters	Explanation
General	
Node ID	The node ID (1–126) is the station address under which the controller communicates with the slave on the CAN network.
Write DCF	Currently not implemented.
Generate all SDOs	When this check box is marked, SDOs are generated for all objects in the EDS file. In addition, the corresponding options must be activated. If the node-guarding objects are to be written, for example, the checkbox for the “Node-Guarding” option must also be marked. If the checkbox is not marked, SDOs are only generated for the objects in which the default values deviate from the EDS file.
Reset node	If you activate this option, the slave is reset by the controller (receives a “reset node”) before the configuration is sent to the slave. This function is not currently implemented.
Mapping SDOs	Activate or deactivate each of the three SDO ranges of the slave configuration here.
Comm SDOs	Mapping SDOs: Objects 0x1600 ... 0x1620 Objects 0x1A00 ... 0x1A20 Comm SDOs:
Basic SDOs	Objects 0x1400 ... 0c1420 Objects 0x1800 ... 0x1820 Basic SDOs: Objects 0x100C ... 0x1017
Node Guard	
Node-Guarding	With Node-Guarding enabled, the slave monitors the PFC for any potential disruption of fieldbus communication.
Guard COB ID	Default setting: 0x700 + Node ID.
Guard Time (ms)	Under “Guard Time” specify the interval at which the PFC expects to receive “Confirmation” from the slave.
Lifetime factor	In the field “Lifetime factor” (≥ 2) specify the multiplier for the “Guard time”. If the time yielded from “Guard time” x “Lifetime factor” (“Node lifetime”) has expired, the slave is brought into the predefined state. This function is deactivated by “0”.

Table 115: Description of the CAN parameters

Parameters	Explanation
Heartbeat Settings	
Activate heartbeat generation	If the “Heartbeat Generation” option is enabled, the CAN device transmits heartbeats in ms intervals specified in “Heartbeat Producer Time”. This function is disabled by “0”.
Heartbeat producer time (ms)	
Activate heartbeat consumption	If the “Heartbeat Consumption” option is enabled, the CAN device monitors the heartbeat of the master. Only “Heartbeat” or “Node-Guarding” can be used for monitoring.
Emergency Telegram	
Emergency	<p>If you mark this checkbox, the slave sends error and status messages that are stored as emergency messages to the diagnostic address in the flag area. These error and status messages are read out using “BusDiag.lib”.</p> <p>If you do not mark this checkbox, SDO 0x1014 is not transmitted to the slave. The default setting for the slave would then still apply.</p>
COB-ID	Default: Node ID + 0x80
Communication Cycle	
Cycle	These functions are currently not implemented.
Period (µsec)	

Click **[Info ...]** to display the parameters “FileInfo” and “DeviceInfo” from the EDS file.

You can now select the installed input and output modules in the CAN module selection tab. In the example shown here, one 8-bit input and output module each.




Figure 102: CAN module selection tab

10.3.4.4 Configuring the Slave PDOs

Now, configure the receiving PDOs for the slave (output from the perspective of the controller) and the send PDOs. The PDOs for the module have already been created by the Configurator. The eight bits have been placed in the first PDO.




Figure 103: PDO mapping tab

Table 116: Receiving and Sending Description for PDO Mapping

Parameters	Explanation
Insert PDO	<p>Depending on the I/O modules selected for the CANopen slave, the corresponding CANopen objects appear on the “Receive PDO Mapping” (PFC → slave) and “Send PDO Mapping” (slave → PFC) tabs. Using these tabs, you can change the “Default Mapping” described in the EDS file.</p> <p>Click on the button [Add PDO] to match the PDOs to the I/O module topology. The PDO properties window opens for defining certain properties for the PDO. More information about this is provided under “Properties”.</p> <p>In order to assign one of the PDOs an object from the left window, mark both the corresponding object and the corresponding PDO and then click [>>]. Then the object will be added below the PDOs in the right window. The first 64 digital and the first 12 analog inputs and outputs are then assigned automatically to the PDOs 1–4.</p>
Remove	Click [Remove] to remove the item currently marked in the right window from the configuration.
Features	A dialog box with information about the PDO properties opens (see next page).

Further configuration of the PDOs is also possible using the “Properties” button.




Figure 104: PDO properties window

Table 117: Description of the PDO Properties window

Parameters	Explanation
COB-ID	CAN Identifier
Inhibit Time (* 100 μ s)	Here, specify the time span of a PDO to reduce communication incidence; this is the time that must pass before it can be sent again. This value is not used for synchronous transmission. This value is insignificant for a receive PDO.
Transmission Type	<p>Here, select the transmission mode for the PDO:</p> <p>acyclic-synchronous: (transmission type 0) The PDO is transmitted synchronously, but not periodically. For receive PDOs, the transmission types 0–240 are handled the same way.</p> <p>cyclic-synchronous: (transmission type 1–240) The PDO is transmitted synchronously, whereby “Number of Syncs” specifies the number of synchronization messages that lie between two transmissions of the PDO. For receive PDOs, the transmission types 0–240 are handled the same way.</p> <p>synchronous - only RTR: (transmission type 252) The PDO is updated after a synchronization message, but not sent. It is only transmitted with an explicit inquiry “Remote Transmission Request” (not implemented).</p> <p>asynchronous - only RTR: (transmission type 253) The PDO is only updated and transmitted with an explicit inquiry “Remote Transmission Request” (not implemented).</p> <p>asynchronous-vendor-specific: (transmission type 254) The PDO is only transmitted after particular events.</p> <p>asynchronous-device-profile-specific: (transmission type 255) The PDO is only transmitted after specific events.</p>
Number of Syncs	Depending on the “transmission type,” this field can be edited to enter the number of synchronization messages from 1–240. This value is insignificant for a receive PDO.

Table 117: Description of the PDO Properties window

Parameters	Explanation
Event Time	Depending on the “transmission type”, enter the time span (in ms) that should elapse between two transmissions of the PDO. This value is insignificant for a receive PDO.

10.3.4.5 Configuring the Service Data Objects

Service data objects can also be configured in addition to the configuration performed on the previous tabs.





Figure 105: Service data objects tab

All objects of the EDS file are listed here, which range from index 0x2000 to 0x9FFF and can be described.

For each object, the index, name, value, type and default are specified.

The value of the objects can be changed. To do this, mark the field in question in the “Value” column and overwrite the value with your input, then press **[Enter]**. On initialization of the CAN bus, the set values will be transmitted to the slaves as SDOs.

An example here is the activation of sending PDOs on a change in analog values, which is normally deactivated:



5201su...	module 58	0	Unsigne...	0
5201su...	module 59	0	Unsigne...	0
5201su...	module 60	0	Unsigne...	0
5201su...	module 61	0	Unsigne...	0
5201su...	module 62	0	Unsigne...	0
5201su...	module 63	0	Unsigne...	0
5201su...	module 64	0	Unsigne...	0
6005	Global Interrupt Enable Digital 8-Bit	0x01	Unsigne...	0x01
6423	Analogue Input Global Interrupt Enable	<input type="text" value="0x01"/>	Unsigne...	0x00
67fesub1	Communication error	0	Unsigne...	0

Figure 106: Adapting SDOs

The starting parameters for the slave can now be set on the “Module parameters” tab.




Figure 107: “Module parameters” tab

Table 118: Description of the module parameters (slave)

Parameters	Explanation
EnableCANopenStartup	<p>Yes (default): During the boot-up phase of the CANopen network, all basic SDO frames are sent to the selected CANopen slave.</p> <p>No: With this setting, no SDO frames are sent to the CANopen slave.</p>
EnableNMTStartNode	<p>Yes (default): During the boot-up phase of the CANopen network, the NMT command “Start remote node” is sent to the selected CANopen slave (communication connection is established).</p> <p>No: With this setting, no start command is transmitted. The CANopen slave can be started at any time using the “Start remote node” command. Note: to do this, deactivate the parameter “Start automatically”:</p>

10.3.5 CANopen Slave Control Configuration

An application must be configured in CODESYS before it can access the connected CAN network.

To add the CANopen slave to the control configuration, right-click “COS unused[Slot]” and select “Replace element -> CANopen slave”.




Figure 108: Attaching a CANopen slave

Right-click on CANopen Slave and select “Edit” to configure the slave.




Figure 109: Configuring a CANopen slave

10.3.5.1 CANopen Variables Configuration




Figure 110: Configuration of the CANopen slave variables

CANopen variables can be added by clicking the [+] (Add) button. After this, you must specify the data type and communication direction (I/O type).

Table 119: Description of the CANopen Slave Variables Window

Parameters	Explanation
Name	You can edit the name for the variable or for its bits.
Address	Output of the CODESYS address in the input or output area, based on data type.
Data Type	The following data types may be used: BOOL, BYTE, WORD, DWORD, SINT, INT, DINT, USINT, UINT, UDINT, REAL, BYTE(Array) The byte array can be extended by adding bytes until the required size is achieved. The maximum length of the array is eight bytes.
Comment	Input field for a comment
I/O type	Input or output
Fieldbus access	Output of the address offset in bytes, relative to the beginning of the CAN data range

10.3.5.2 Configuring of CANopen Parameters




Figure 111: Configuration of CANopen slave parameters

Table 120: Description of CANopen Slave Settings

Parameters	Explanation
Baud rate	Specify the baud rate to apply for the transfer on the CAN bus (default setting: 125000 baud).
Node ID	PFC's Node ID on the CAN bus.

10.4 Fieldbus Coupler Diagnostics

This section requires substantial knowledge of the CODESYS programming tool. It only describes the procedure to create diagnostics using the fieldbus master.

Configured slaves (e.g., a fieldbus coupler or a fieldbus controller) are required for diagnostics in fieldbus networks.

10.4.1 DiagGetBusState() and DiagGetState()

To evaluate the diagnostics, you need the following function blocks from the BusDiag.lib library:

- **DiagGetBusState()** for bus diagnostics
This function block provides general information on each connected slave (e.g., number of slaves).
- **DiagGetState()** for participant diagnostics
This function block provides detailed information on each slave (e.g., information on diagnostics).

10.4.2 Creating Diagnostics 7 in CODESYS 2.3

In order to execute bus diagnostics or device diagnostics for the slaves, it is necessary to integrate the BusDiag.lib library into CODESYS. This library contains the necessary function blocks DiagGetBusState() for bus diagnostics and DiagGetState() for participant diagnostics.

Integrate the BusDiag.lib library into CODESYS as described below:

1. Click the “Resources” tab.




Figure 112: “Resources” tab

2. In the left column, double-click “Library Manager”.

- In the menu bar, click on **Insert > Additional library**. The “Open” dialog window then opens. Select the “BusDiag.lib” and click **[Open]** to add it to the project.




Figure 113: “Open” dialog window

- In the menu bar, click the “Box” symbol.




Figure 114: Module symbol in the menu bar; FUP programming language

- Press **[F2]** on your keyboard. The “Input Assistant” dialog window opens. Click the “Standard function block” option and select the function block `DiagGetBusState()`.
- Create an entity for the function block `DiagGetBusState()`. Enter a name above the function block. In the example shown here this is “GeneralBusInformation”.




Figure 115: Entity for the function block `DiagGetBusState()` in FUP

7. Call up the function block DiagGetBusState() for the slave diagnostics from the library BusDiag.lib.
8. Create an entity for the function block DiagGetState().
Shown in this example is “DiagnosticsNode”.




Figure 116: Function block DiagGetState() in FUP

In this example, both function blocks are called up during the program sequence. In order to not prolong the cycle times during the program sequence, do not set the input “ENABLE” of DiagGetState() to “TRUE” until you have conducted diagnostics.

10.4.3 Calling Up the Diagnostics Function Block

Call up the function block as shown in the following figure.

```

PLC_PRG (PRG-FUP)
0001 PROGRAM PLC_PRG
0002 VAR
0003   GeneralBusInformation AT%MB0: DiagGetBusState;
0004   DeviceNumber: INT;
0005   enableKnoten: BOOL;
0006
0007 (*----- DiagGetState -----*)
0008   DiagnoseKnoten: DiagGetState;
0009   DiagnosticNodeID: DWORD;
0010
0011   readyKnoten: BOOL;
0012   stateKnoten: NDSTATE;
0013   infoKnoten: ARRAY[0..99] OF BYTE;
0014 END_VAR

```

Figure 117: Offline view of the variable window in CODESYS

10.4.4 Executing a Bus Diagnosis using DiagGetBusState()

To perform bus diagnostics, proceed as follows:

1. Log into CODESYS. To do this, click in the menu bar on **Online > Login**. Information about the variables is then displayed in the Variable window (Online view).
2. To start the PLC program, click **Online > Start** in the menu bar. Starting this program also calls up the DiagGetBusState() function block and outputs diagnostics information to the EXTENDEDINFO array.

In the online view of the Variable window, the array EXTENDEDINFO provides information on the status of the slaves. An entry is reserved in the array for each slave. The slave address is allocated to the array index. In this example, it is the slaves with the station addresses 2 and 5 that store the diagnostics information. If the device is configured as a slave, only the information for its own address is available.

Note



Display of Diagnostics Information

The diagnostic information is only displayed for the duration of one program cycle. If the diagnostic information should be available for longer, a suitable program must be written.




Figure 118: Online view of the variable window (top window) in FUP

- The binary code facilitates the evaluation of the individual diagnostic bits. You can have the diagnostic information of the array EXTENDEDINFO displayed as binary code. To do this, right click in the variable window and select **binary**.




Figure 119: Example of diagnostics

- Compare the three lowest value bits of the diagnostic information of the slaves with station addresses 2 and 5 with the bits from the following table:

Table 121: Diagnostics Information Bits

2nd bit		1st bit		0 bit	
1	0	1	0	1	0
Diagnostics information is present at the slave.	No diagnostics information is present at the slave.	Slave is active.	Slave is inactive.	Slave projected.	Slave not designed.

- The slave with station address 2 delivers the value 011. This means that the slave is configured and is active.
- The slave with station address 5 delivers the value 111. This means that the slave is configured, is active and that error information is available for this slave. Subscriber diagnostics must be performed to evaluate this error information. Refer to Section “Performing Subscriber Diagnostics using DiagGetState()” for more information about this.

Note



Diagnostic information

If READY = TRUE, then STATE indicates the current bus status with one of the following values:

BUSOK: All configured slaves exchanging data with the DP master.

BUSFAULT: One or more configured slaves is not exchanging data with the DP master

BUSNOTCOMMUNICATION: All configured slaves are not exchanging data with the DP master.

10.4.5 Performing Subscriber Diagnostics using DiagGetState()

If the bus diagnostics have revealed that an I/O module contains diagnostic information, then perform participant diagnostics on the corresponding slave. Proceed as follows:

1. Call up the function block DiagGetState() by setting the input ENABLE to “True.”
2. Specify the slave that provides the diagnostic information at the input variable BUSMEMBERID. In this example, it is the slave with the fieldbus address 5.




Figure 120: DiagGetState() diagnostic call

- **DRIVERNAME:**
The input parameter DRIVERNAME is specified through the instance data of the function block DiagGetBusState.
- **DEVICENUMBER:**
The DEVICENUMBER is device-specific and the variable “DeviceNumber” must be adapted accordingly based on the information given in the Section “Appendix” > ... > “BusDiag.lib”.

10.4.6 Evaluating the CANopen Diagnosis (Emergency Messages)

The array elements [0] to [3] listed in the illustration below are reserved for the CANopen status information in bytes. The emergency messages of the slaves are stored starting with array element [4].

Address	Value	Annotation
16	EXTENDEDINFO	
17	EXTENDEDINFO[0] = 2#00000010	→ Byte 1 → Byte 2 → Range for CANopen status information
18	EXTENDEDINFO[1] = 2#00000000	
19	EXTENDEDINFO[2] = 2#00000000	
20	EXTENDEDINFO[3] = 2#00000000	
21	EXTENDEDINFO[4] = 2#00000000	Range for slave emergency messages
22	EXTENDEDINFO[5] = 2#00011100	
23	EXTENDEDINFO[6] = 2#00000101	
24	EXTENDEDINFO[7] = 2#00000001	
25	EXTENDEDINFO[8] = 2#00001000	
26	EXTENDEDINFO[9] = 2#00001100	
27	EXTENDEDINFO[10] = 2#00000000	
28	EXTENDEDINFO[11] = 2#00000001	
29	EXTENDEDINFO[12] = 2#10110111	
30	EXTENDEDINFO[13] = 2#01010100	
31	EXTENDEDINFO[14] = 2#01001001	
32	EXTENDEDINFO[15] = 2#00001000	
33	EXTENDEDINFO[16] = 2#00000000	
34	EXTENDEDINFO[17] = 2#00000000	
35	EXTENDEDINFO[18] = 2#00000000	
36	EXTENDEDINFO[19] = 2#00000000	
37	EXTENDEDINFO[20] = 2#00000000	
38	EXTENDEDINFO[21] = 2#00000000	
39	EXTENDEDINFO[22] = 2#00000000	
40	EXTENDEDINFO[23] = 2#00000111	
41	EXTENDEDINFO[24] = 2#10100000	
42	EXTENDEDINFO[25] = 2#00000000	
43	EXTENDEDINFO[26] = 2#00000000	
44	EXTENDEDINFO[27] = 2#00000000	
45	EXTENDEDINFO[28] = 2#00000000	
46	EXTENDEDINFO[29] = 2#00000000	
47	EXTENDEDINFO[30] = 2#10000100	
48	EXTENDEDINFO[31] = 2#01000000	
49	EXTENDEDINFO[32] = 2#10101000	
50	EXTENDEDINFO[33] = 2#10000100	
51	EXTENDEDINFO[34] = 2#01000001	
52	EXTENDEDINFO[35] = 2#10101000	
53	EXTENDEDINFO[36] = 2#00000000	

Figure 121: Online view of the EXTENDEDINFO array in the binary representation

The CANopen status information and the slaves' emergency messages are described on the following pages.

Description of the Function Block's Diagnostic Information
DiagGetState.EXTENDEDINFO for CANopen

The EXTENDEDINFO array contains the following status information:

Byte 0

- Bit 0: Slave entered
- Bit 1: Slave entered and configured
- Bit 2: Slave configuration invalid
- Bit 3: Diagnosis: Emergency event active
- Bit 4: Slave status "Operational"
- Bit 5: Slave status "Stop"
- Bit 6: Slave status "Preoperational"
- Bit 7: Erroneous configuration structure (from Master)

Byte 1

- Bit 0: Configuration structure incompatible with slave
- Bit 1: Slave device detection error

Byte 2

- Bit 0: An emergency message is present in the list

Byte 3

Not used

Byte 4 ... 11

Last emergency message in the list

10.5 Data Exchange between Simple CAN Subscribers and PFC200 in the CANopen Network

The EDS file “Generic CAN device”, which has been reduced to the essentials, has been created to simplify the control configuration for adding CAN Layer2 device. The EDS file contains 16 send and receive PDOs, each of which has 8x1-byte entries. You only have to deactivate the configuration and monitoring telegrams typical of CANopen for these subscribers.

You can also execute the control configuration with any EDS file for CANopen.

1. To add the CANopen Master to the control configuration, right-click “COS unused[Slot]” and select “Replace element -> CANopen Master”.




Figure 122: Attaching the CANopen master

2. In the “CAN Parameters” tab, select the required baud rate.




Figure 123: Setting the baud rate

- To add a slave, right-click **CANopen Master[SLOT]** and select **Attach sub-element > Generic CAN Device (EDS) ...** in the contextual menu.




Figure 124: EDS file “Generic CAN Device”

- Open the **Module parameters** tab of the slave. For communication with simple CAN Layer2 devices, deactivate transmission of the configuration to the slave with **EnableCANopenStartup** (= “No”).




Figure 125: “Module parameters” tab

- Open the **CAN parameters** tab of the slave. Deactivate the parameters **CommSDO**, **MappingSDO**, **Basic SDO** and **Nodeguarding**.




Figure 126: “CAN parameters“ tab

6. You can now use the commands of the CAN Layer2 library (see Section “CODESYS Libraries” > ... > “WagoCANLayer2_01.lib”) to access the devices.
To configure the CAN frames for CAN Layer2 devices, refer to the Section “CANopen Master and Slaves” > ... > “Configuring the slave PDOs”.

10.6 Data Exchange between CAN Subscribers and the PFC200 in a CAN Layer2 Network

If there are only CAN Layer2 devices in the network, the CANopen functions are not necessary. A separate device has been defined that provides only the CAN Layer2 basic functions.

1. To add the CAN Layer2 device to the control configuration, right-click “COS unused[Slot]” and select “Replace element -> CAN Layer2 Device”.




Figure 127: Attaching the CAN Layer2 device

2. The CAN interface can now be opened with the function blocks from the WagoCANLayer2_02.lib, the CAN LED set and the data exchanged.

11 Diagnostics

11.1 Operating and Status Messages

The following tables contain descriptions of all operating and status messages for the controller which are indicated by LEDs.

11.1.1 Power Supply Indicating Elements




Figure 128: Power supply indicating elements

Table 122: Legend for Figure “Power Supply Indicating Elements”

Description	Color	Description
A	Green/off	Status of system power supply voltage
B	Green/off	Status of field-side power supply voltage

Table 123: Field-Side Supply Diagnostics

Status	Explanation	Solution
Green	24V field-side supply voltage present	---
Off	No 24V field-side supply voltage present	Switch on the power supply. Check the supply voltage.

Table 124: System Power Supply Diagnostics

Status	Explanation	Solution
Green	24V system power supply voltage present	---
Off	No 24V system power supply voltage present	Switch on the power supply. Check the supply voltage.

11.1.2 Fieldbus/System Indicating Elements




Figure 129: Indicating elements for fieldbus/system

Table 125: Diagnostics SYS LED

Status	Explanation	Solution
Green	System start completed without errors	---
Orange	Usage > Limit 1 The system is at full capacity; real-time response can no longer be guaranteed.	Try to reduce the load on the system: <ul style="list-style-type: none"> - Change the CODESYS program. - End any fieldbus communication that is not essential, or reconfigure the fieldbuses. - Remove any non-critical tasks from the RT area.
Orange flashing	The IP address was temporarily set to a defined value via the FIC IP function with the RST button.	Connect to the device via the standard address (192.168.1.17), or restart the device to restore the set value.
Red	Usage > Limit 2 The system is overloaded; real-time response is no longer guaranteed.	Try to reduce the load on the system: <ul style="list-style-type: none"> - Change the CODESYS program. - End any fieldbus communication that is not essential, or reconfigure the fieldbuses. - Remove any non-critical tasks from the RT area.

Table 126: Diagnostics RUN LED

Status	Explanation	Solution
Green	PLC program has the status "Run".	---
Green flashing	PLC program at a debug point.	Resume the program in the linked IDE (Integrated Development Environment) using "Single step" or "Start". If the connection has been interrupted, set the Run/Stop switch to "Stop" and then back to "Run" to enable the program to continue.
Green/red flashing	PLC is at a debug point and the Run/Stop switch has been set to "Stop".	Set the Run/Stop switch to "Run" to enable the program to continue.
Red	No PLC-program loaded or PLC program has the status "Stop".	Load the PLC program. Set the Run/Stop switch to "Run" to start the current program.

Table 127: Diagnostics I/O LED

Status	Explanation	Solution
Green	Data cycle on the internal data bus, normal operating status.	---
Orange flashing	Startup phase; the internal data bus is being initialized. The startup phase is indicated by rapid flashing for about 1 ... 2 seconds.	Wait until initialization has been completed.
Red	A hardware fault is present.	Contact WAGO Support.
Red flashing (2 Hz)	An error which may be able to be eliminated is present.	First, try to eliminate the error by switching the device (power supply) off and then back on. Check the entire node structure for any errors. If you cannot eliminate the error, contact WAGO Support.
Red flashing (flashing sequence)	An internal data bus error is present.	An explanation of the flashing sequence is given in the section "Diagnostics Messages (I/O LEDs)".
Off	A library was not loaded, or a library function was not called up.	Restart the device. If you cannot eliminate the error, contact WAGO Support.

Table 128: Diagnostics CAN LED

Status	Explanation	Solution
Off	The CAN interface has not been configured	---
Alternating red 50 ms / green 50 ms	Configuration in progress	---
Alternating red 200 ms / green 200 ms	Configuration invalid	Check the configuration in the CODESYS Configurator.
Green 200 ms / off 800 ms	The CANopen interface has the status "Stop".	---
Green 200 ms / off 200 ms	The CANopen interface has the status "Preoperational".	---
Green	The CANopen interface has the status "Operational".	---
Red	The CANopen interface has the status "Bus Off" (short-circuit or other major fault).	Check the bus connections and the baud rate.
Error in the status "Preoperational"		
1* red flashing / 2 * green flashing	"Bus Warning Level" exceeded.	Check the wiring for the CAN bus.
2* red flashing / 2 * green flashing	"Guarding Error", slave incorrectly configured or not available.	Check the slaves and the configuration.
3* red flashing / 2 * green flashing	"Sync Error"	Change the time interval for the synchronization message.
Error in the status "Operational"		
1* red flashing / green 800 ms on	"Bus Warning Level" exceeded.	Check the wiring for the CAN bus.
2* red flashing / green 800 ms on	"Guarding Error"	Check the slaves and the configuration.
3* red flashing / green 800 ms on	"Sync Error"	Change the time interval for the synchronization message.

11.2 Diagnostics Messages (I/O LED)

11.2.1 Flashing Sequence

A diagnosis (fault/error) is always displayed as three flashing sequences in a cyclic manner:

1. The first flashing sequence (flickering) initiates reporting of the fault/error.
2. After a short break (approx. 1 second), the second flashing sequence starts. The number of blink pulses indicates the **error code**, which describes the type of error involved.
3. After a further break the third flashing sequence is initiated. The number of blink pulses indicates the **error argument**, which provides an additional description of the error, e.g., which of the I/O modules connected to the controller exhibits an error.




Figure 130: Flashing sequence process diagram

11.2.2 Example of a Diagnostics Message Indicated by a Blink Code

The example below illustrates the representation of a diagnostics message via the blink code. A data error is indicated on the internal data bus, caused by the removal of an I/O module located at the 6th position of the bus node.

Initiation of the Start Phase

1. The I/O LED flashes for 1 cycle at about 10 Hz (10 flashes/second).
2. This is followed by a pause of about one second.

Error Code 4: Data Error in the Internal Data Bus

3. The I/O LED flashes for 4 cycles of about 1Hz.
4. This is followed by a pause of about 1 second.

Error Argument 5: I/O Module at the 6th Slot

5. The I/O LED flashes for 5 cycles at 1 Hz.
This indicates that a disruption has occurred at the I/O module downcircuit of the 5th I/O module.
6. The blink code starts flickering when the start phase is initiated again. If there is only one error, this process is repeated.

11.2.3 Meaning of Blink Codes and Procedures for Troubleshooting

This section describes the diagnostics presented as blink codes via the I/O LEDs.

If the diagnostics cannot be cleared by the measured specified for them, contact WAGO support. Be ready to explain to them the blink code that is displayed.

Phone: +49 571 887 555
Fax: +49 571 887 8555
E-mail: support@wago.com

Table 129: Overview of Error Codes

Error code	Explanation
1	Hardware and configuration error
2	Not used
3	Internal data bus protocol error
4	Physical error on the internal data bus
5	Internal data bus initialization error
6	Design error in the node configuration
7	Not used
8	Not used
9	CPU exception error

Table 130: Error Code 1, Explanation of Blink Codes and Procedures for Troubleshooting

Error Argument	Cause	Solution
--	Invalid parameter checksum for internal data bus interface	<ul style="list-style-type: none"> - Switch off the power to the controller and replace it. - After this, switch the power back on.
1	Internal buffer overflow (max. amount of data exceeded) during inline code generation	<ul style="list-style-type: none"> - Switch off the power to the controller. - Reduce the number of I/O modules. - Switch the power back on.
2	Data type of the I/O module(s) is not supported	<ul style="list-style-type: none"> - Update the controller firmware. If this error persists, there is an error in the I/O module. Determine this error as follows: - Switch off the power supply. - Place the end module in the middle of the I/O modules connected to the system. - Switch the power back on. - If the I/O flashes red switch off the power supply again and place the end module in the middle of the first half of the I/O modules (toward the controller). - If the LED is no longer flashing, switch off the power supply and place the end module in the middle of the second half of the I/O modules (away from the controller). - Switch the power back on. - Repeat this procedure until you establish which I/O module is defective. Then replace that module.
3	Unknown module type of the flash program memory	<ul style="list-style-type: none"> - Switch off the power to the controller and replace it. - After this, switch the power back on.
4	Error occurred while writing to the flash memory	<ul style="list-style-type: none"> - Switch off the power to the controller and replace it. - After this, switch the power back on.
5	Error occurred while erasing a flash sector	
6	The I/O module configuration after an internal data bus reset differs from the one after the last controller startup.	<ul style="list-style-type: none"> - Restart the controller by first switching off the power supply and then switching it back on, or by pressing the Reset button on the controller.
7	Error occurred while writing to the serial EEPROM	<ul style="list-style-type: none"> - Switch off the power to the controller and replace it. - After this, switch the power back on.

Table 130: Error Code 1, Explanation of Blink Codes and Procedures for Troubleshooting

Error Argument	Cause	Solution
8	Invalid hardware/ firmware combination	
9	Invalid checksum in the serial EEPROM	
10	Fault when initializing the serial EEPROM.	
11	Error occurred while reading from the serial EEPROM	<ul style="list-style-type: none"> - Switch off the power supply to the controller and reduce the number of I/O modules. - After this, switch the power back on.
12	Time to access the serial EEPROM exceeded	<ul style="list-style-type: none"> - Switch off the power to the controller and replace it. - After this, switch the power back on.
14	Maximum number of gateway or mailbox modules exceeded.	<ul style="list-style-type: none"> - Switch off the power to the controller. - Reduce the number of gateway or mailbox modules. - After this, switch the power back on.

Table 131: Error Code 3, Explanation of Blink Codes and Procedures for Troubleshooting

Error Argument	Cause	Solution
--	Internal data bus communication error; defective I/O module cannot be identified	<p>If a power supply module (e.g., 750-602) is connected to the controller, ensure that this module functions properly (see Section “LED Signaling”). If the supply module does not exhibit any errors/faults, the I/O module is defective. Identify the defective I/O module as follows:</p> <ul style="list-style-type: none"> - Switch off the power supply. - Place the end module in the middle of the I/O modules connected to the system. - Switch the power back on. - If the I/O LED continues to flash red switch off the power supply again and place the end module in the middle of the first half of the I/O modules (toward the controller). <p>If only one I/O module is left and the LED continues to flash, either this module or the controller internal data bus interface is defective. Replace the defective module or the controller.</p> <ul style="list-style-type: none"> - If the LED is no longer flashing, switch off the power supply and place the end module in the middle of the second half of the I/O modules (away from the controller). - Switch the power back on. - Repeat this procedure until you establish which I/O module is defective. Then replace that module.

Table 132: Error Code 4, Explanation of Blink Codes and Procedures for Troubleshooting

Error Argument	Cause	Solution
--	Maximum permissible number of I/O modules exceeded.	<ul style="list-style-type: none"> - Switch off the power to the controller. - Reduce the number of I/O modules to an acceptable value. - Switch the power back on.
n*	Internal data bus disruption after the n th process data module.	<ul style="list-style-type: none"> - Switch off the power to the controller. - Replace the (n+1)th process data module. - Switch the power back on. <p>I/O modules that do not provide any data are ignored (e.g., supply module without diagnostics).</p>

Table 133: Error Code 5, Explanation of Blink Codes and Procedures for Troubleshooting

Error Argument	Cause	Solution
n*	Register communication error during internal data bus initialization	<ul style="list-style-type: none"> - Switch off the power to the controller. - Replace the (n+1)th process data module. - Switch the power back on. <p>I/O modules that do not provide any data are ignored (e.g., supply module without diagnostics).</p>

Table 134: Error Code 6, Explanation of Blink Codes and Procedures for Troubleshooting

Error Argument	Cause	Solution
5	Maximum size of the process image exceeded	<ul style="list-style-type: none"> - Switch off the power supply to the controller and reduce the number of I/O modules. - Switch the power back on.

Table 135: Error Code 9, Explanation of Blink Codes and Procedures for Troubleshooting

Error Argument	Cause	Solution
1	Invalid program statement	Malfunction of the program sequence. - Please contact WAGO Support.
2	Stack overflow	Malfunction of the program sequence. - Please contact WAGO Support.
3	Stack underflow	Malfunction of the program sequence. - Please contact WAGO Support.
4	Invalid event (NMI)	Malfunction of the program sequence. - Please contact WAGO Support.

12 Service

12.1 Inserting and Removing the Memory Card

12.1.1 Inserting the Memory Card

1. Use an actuating tool or a screwdriver to open the transparent cover flap by flipping it upwards. The points of application for the tool are marked by arrows.
2. Hold the memory card such that the contacts are visible on the right side and the sloping edge is at the top, as depicted in the figure below.
3. Insert the memory card in this position into the slot of the fieldbus controller.
4. Push the memory card all the way in. When you let go, the memory card will move back a little and then snap in.
5. Close the cover flap by flipping it down and pushing it in until it snaps into place.
6. You can seal the closed flap through the hole in the enclosure next to the flap.




Figure 131: Inserting the memory card

12.1.2 Removing the Memory Card

1. First, remove any seal that may be in place.
2. Use an actuating tool or a screwdriver to open the transparent cover flap by flipping it upwards. The points of application for the tool are marked by arrows.
3. To remove the memory card you must first push it into the slot. This releases the mechanical locking mechanism.
4. As soon as you let go of the memory card, the memory card is pushed out a bit and you can remove it.

5. Close the cover flap by flipping it down and pushing it in until it snaps into place.

13 Removal

⚠ CAUTION

Risk of injury due to sharp-edged blade contacts!

The blade contacts are sharp-edged. Handle the I/O module carefully to prevent injury.

13.1 Removing Devices

NOTICE

Perform work on devices only if they are de-energized!

Working on energized devices can damage them. Therefore, turn off the power supply before working on the devices.

13.1.1 Removing the Fieldbus Coupler/Controller

1. Use a screwdriver blade to turn the locking disc until the nose of the locking disc no longer engages behind the carrier rail.
2. Remove the fieldbus coupler/controller from the assembly by pulling the release tab.

Electrical connections for data or power contacts to adjacent I/O modules are disconnected when removing the fieldbus coupler/controller.




Figure 132: Release Tab of Controller

Note



Do not take the controller enclosure apart!

The enclosure sections are firmly joined. The feed-in section with the CAGE CLAMP® connections cannot be separated from the other enclosure section.

13.1.2 Removing the I/O Module

1. Remove the I/O module from the assembly by pulling the release tab.




Figure 133: Removing the I/O Module (Example)

Electrical connections for data or power jumper contacts are disconnected when removing the I/O module.

Note



Do not take the controller enclosure apart!

The enclosure sections are firmly joined. The feed-in section with the CAGE CLAMP® connections cannot be separated from the other enclosure section.

14 Appendix

14.1 Structure of Process Data for the I/O Modules

The process image for the I/O modules on the internal data bus is built up word-by-word in the PFC200 controller (with word alignment). The internal mapping method for data greater than one byte conforms to Intel formats.

The following section describes the representation for WAGO-I/O SYSTEM 750 (750 and 753 Series) I/O modules in the process image, as well as the configuration of the process values.

NOTICE

Equipment damage due to incorrect address!

To prevent any damage to the device in the field you must always take the process data for all previous byte or bit-oriented I/O modules into account when addressing an I/O module at any position in the fieldbus node.

Note



No direct access from fieldbus to the process image for I/O modules!

Any data that is required from the I/O module process image must be explicitly mapped in the CODESYS program to the data in the fieldbus process image and vice versa! Direct access is not possible!

14.1.1 Digital Input Modules

Digital input modules supply one bit of data per channel to specify the signal state for the corresponding channel. These bits are mapped into the Input Process Image.

Some digital modules have an additional diagnostic bit per channel in the Input Process Image. The diagnostic bit is used for detecting faults that occur (e.g., wire breaks and/or short circuits).

When analog input modules are also present in the node, the digital data is always appended after the analog data in the Input Process Image, grouped into bytes.

14.1.1.1 1 Channel Digital Input Module with Diagnostics

750-435

Table 136: 1 Channel Digital Input Module with Diagnostics

Input Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
						Diagnostic bit S 1	Data bit DI 1

14.1.1.2 2 Channel Digital Input Modules

750-400, -401, -405, -406, -410, -411, -412, -427, -438, (and all variations),
753-400, -401, -405, -406, -410, -411, -412, -427

Table 137: 2 Channel Digital Input Modules

Input Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
						Data bit DI 2 Channel 2	Data bit DI 1 Channel 1

14.1.1.3 2 Channel Digital Input Module with Diagnostics

750-419, -421, -424, -425,
753-421, -424, -425

Table 138: 2 Channel Digital Input Module with Diagnostics

Input Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
				Diagnostic bit S 2 Channel 2	Diagnostic bit S 1 Channel 1	Data bit DI 2 Channel 2	Data bit DI 1 Channel 1

14.1.1.4 2 Channel Digital Input Module with Diagnostics and Output Process Data

750-418,
753-418

The digital input module supplies a diagnostic and acknowledge bit for each input channel. If a fault condition occurs, the diagnostic bit is set. After the fault condition is cleared, an acknowledge bit must be set to re-activate the input. The diagnostic data and input data bit is mapped in the Input Process Image, while the acknowledge bit is in the Output Process Image.

Table 139: 2 Channel Digital Input Module with Diagnostics and Output Process Data

Input Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
				Diagnostic bit S 2 Channel 2	Diagnostic bit S 1 Channel 1	Data bit DI 2 Channel 2	Data bit DI 1 Channel 1

Output Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
				Acknowledgement bit Q 2 Channel 2	Acknowledgement bit Q 1 Channel 1	0	0

14.1.1.5 4 Channel Digital Input Modules

750-402, -403, -408, -409, -414, -415, -422, -423, -428, -432, -433, -1420, -1421, -1422, -1423
753-402, -403, -408, -409, -415, -422, -423, -428, -432, -433, -440

Table 140: 4 Channel Digital Input Modules

Input Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
				Data bit DI 4 Channel 4	Data bit DI 3 Channel 3	Data bit DI 2 Channel 2	Data bit DI 1 Channel 1

14.1.1.6 8 Channel Digital Input Modules

750-430, -431, -436, -437, -1415, -1416, -1417, -1418
753-430, -431, -434

Table 141: 8 Channel Digital Input Modules

Input Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Data bit DI 8 Channel 8	Data bit DI 7 Channel 7	Data bit DI 6 Channel 6	Data bit DI 5 Channel 5	Data bit DI 4 Channel 4	Data bit DI 3 Channel 3	Data bit DI 2 Channel 2	Data bit DI 1 Channel 1

14.1.1.7 8 Channel Digital Input Module PTC with Diagnostics and Output Process Data

750-1425

The digital input module PTC provides via one logical channel 2 byte for the input and output process image.

The signal state of PTC inputs DI1 ... DI8 is transmitted to the fieldbus coupler/controller via input data byte D0.

The fault conditions are transmitted via input data byte D1.

The channels 1 ... 8 are switched on or off via the output data byte D1. The output data byte D0 is reserved and always has the value "0".

Table 142: 8 Channel Digital Input Module PTC with Diagnostics and Output Process Data

Input Process Image															
Input Byte D0								Input Byte D1							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Signal status DI 8 Channel 8	Signal status DI 7 Channel 7	Signal status DI 6 Channel 6	Signal status DI 5 Channel 5	Signal status DI 4 Channel 4	Signal status DI 3 Channel 3	Signal status DI 2 Channel 2	Signal status DI 1 Channel 1	Wire break/short circuit DB/KS 8 Channel 8	Wire break/short circuit DB/KS 7 Channel 7	Wire break/short circuit DB/KS 6 Channel 6	Wire break/short circuit DB/KS 5 Channel 5	Wire break/short circuit DB/KS 4 Channel 4	Wire break/short circuit DB/KS 3 Channel 3	Wire break/short circuit DB/KS 2 Channel 2	Wire break/short circuit DB/KS 1 Channel 1

Output Process Image															
Output Byte D0								Output Byte D1							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
0	0	0	0	0	0	0	0	DI Off 8 Channel 8 0: Channel ON 1: Channel OFF	DI Off 7 Channel 7 0: Channel ON 1: Channel OFF	DI Off 6 Channel 6 0: Channel ON 1: Channel OFF	DI Off 5 Channel 5 0: Channel ON 1: Channel OFF	DI Off 4 Channel 4 0: Channel ON 1: Channel OFF	DI Off 3 Channel 3 0: Channel ON 1: Channel OFF	DI Off 2 Channel 2 0: Channel ON 1: Channel OFF	DI Off 1 Channel 1 0: Channel ON 1: Channel OFF

14.1.1.8 16 Channel Digital Input Modules

750-1400, -1402, -1405, -1406, -1407

Table 143: 16 Channel Digital Input Modules

Input Process Image															
Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Data bit DI 16 Channel 16	Data bit DI 15 Channel 15	Data bit DI 14 Channel 14	Data bit DI 13 Channel 13	Data bit DI 12 Channel 12	Data bit DI 11 Channel 11	Data bit DI 10 Channel 10	Data bit DI 9 Channel 9	Data bit DI 8 Channel 8	Data bit DI 7 Channel 7	Data bit DI 6 Channel 6	Data bit DI 5 Channel 5	Data bit DI 4 Channel 4	Data bit DI 3 Channel 3	Data bit DI 2 Channel 2	Data bit DI 1 Channel 1

14.1.2 Digital Output Modules

Digital output modules use one bit of data per channel to control the output of the corresponding channel. These bits are mapped into the Output Process Image.

Some digital modules have an additional diagnostic bit per channel in the Input Process Image. The diagnostic bit is used for detecting faults that occur (e.g., wire breaks and/or short circuits). For modules with diagnostic bit is set, also the data bits have to be evaluated.

When analog output modules are also present in the node, the digital image data is always appended after the analog data in the Output Process Image, grouped into bytes.

14.1.2.1 1 Channel Digital Output Module with Input Process Data

750-523

The digital output modules deliver 1 bit via a process value Bit in the output process image, which is illustrated in the input process image. This status image shows "manual mode".

Table 144: 1 Channel Digital Output Module with Input Process Data

Input Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
						not used	Status bit "Manual Operation"

Output Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
						not used	controls DO 1 Channel 1

14.1.2.2 2 Channel Digital Output Modules

750-501, -502, -509, -512, -513, -514, -517, -535, (and all variations),
753-501, -502, -509, -512, -513, -514, -517

Table 145: 2 Channel Digital Output Modules

Output Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
						controls DO 2 Channel 2	controls DO 1 Channel 1

14.1.2.3 2 Channel Digital Input Modules with Diagnostics and Input Process Data

750-507 (-508), -522,
753-507

The digital output modules have a diagnostic bit for each output channel. When an output fault condition occurs (i.e., overload, short circuit, or broken wire), a diagnostic bit is set. The diagnostic data is mapped into the Input Process Image, while the output control bits are in the Output Process Image.

Table 146: 2 Channel Digital Input Modules with Diagnostics and Input Process Data

Input Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
						Diagnostic bit S 2 Channel 2	Diagnostic bit S 1 Channel 1

Output Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
						controls DO 2 Channel 2	controls DO 1 Channel 1

750-506,
753-506

The digital output module has 2-bits of diagnostic information for each output channel. The 2-bit diagnostic information can then be decoded to determine the exact fault condition of the module (i.e., overload, a short circuit, or a broken wire). The 4-bits of diagnostic data are mapped into the Input Process Image, while the output control bits are in the Output Process Image.

Table 147: 2 Channel Digital Input Modules with Diagnostics and Input Process Data 75x-506

Input Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
				Diagnostic bit S 3 Channel 2	Diagnostic bit S 2 Channel 2	Diagnostic bit S 1 Channel 1	Diagnostic bit S 0 Channel 1

Diagnostic bits S1/S0, S3/S2: = '00' standard mode
 Diagnostic bits S1/S0, S3/S2: = '01' no connected load/short circuit against +24 V
 Diagnostic bits S1/S0, S3/S2: = '10' Short circuit to ground/overload

Output Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
				not used	not used	controls DO 2 Channel 2	controls DO 1 Channel 1

14.1.2.4 4 Channel Digital Output Modules

750-504, -516, -519, -531,
753-504, -516, -531, -540

Table 148: 4 Channel Digital Output Modules

Output Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
				controls DO 4 Channel 4	controls DO 3 Channel 3	controls DO 2 Channel 2	controls DO 1 Channel 1

14.1.2.5 4 Channel Digital Output Modules with Diagnostics and Input Process Data

750-532

The digital output modules have a diagnostic bit for each output channel. When an output fault condition occurs (i.e., overload, short circuit, or broken wire), a diagnostic bit is set. The diagnostic data is mapped into the Input Process Image, while the output control bits are in the Output Process Image.

Table 149: 4 Channel Digital Output Modules with Diagnostics and Input Process Data

Input Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
				Diagnostic bit S 4 Channel 4	Diagnostic bit S 3 Channel 3	Diagnostic bit S 2 Channel 2	Diagnostic bit S 1 Channel 1

Diagnostic bit S = '0' no Error

Diagnostic bit S = '1' overload, short circuit, or broken wire

Output Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
				controls DO 4 Channel 4	controls DO 3 Channel 3	controls DO 2 Channel 2	controls DO 1 Channel 1

14.1.2.6 8 Channel Digital Output Module

750-530, -536, -1515, -1516
753-530, -534

Table 150: 8 Channel Digital Output Module

Output Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
controls DO 8 Channel 8	controls DO 7 Channel 7	controls DO 6 Channel 6	controls DO 5 Channel 5	controls DO 4 Channel 4	controls DO 3 Channel 3	controls DO 2 Channel 2	controls DO 1 Channel 1

14.1.2.7 8 Channel Digital Output Modules with Diagnostics and Input Process Data

750-537

The digital output modules have a diagnostic bit for each output channel. When an output fault condition occurs (i.e., overload, short circuit, or broken wire), a diagnostic bit is set. The diagnostic data is mapped into the Input Process Image, while the output control bits are in the Output Process Image.

Table 151: 8 Channel Digital Output Modules with Diagnostics and Input Process Data

Input Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Diagnostic bit S 8 Channel 8	Diagnostic bit S 7 Channel 7	Diagnostic bit S 6 Channel 6	Diagnostic bit S 5 Channel 5	Diagnostic bit S 4 Channel 4	Diagnostic bit S 3 Channel 3	Diagnostic bit S 2 Channel 2	Diagnostic bit S 1 Channel 1

Diagnostic bit S = '0' no Error
Diagnostic bit S = '1' overload, short circuit, or broken wire

Output Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
controls DO 8 Channel 8	controls DO 7 Channel 7	controls DO 6 Channel 6	controls DO 5 Channel 5	controls DO 4 Channel 4	controls DO 3 Channel 3	controls DO 2 Channel 2	controls DO 1 Channel 1

14.1.2.8 16 Channel Digital Output Modules

750-1500, -1501, -1504, -1505

Table 152: 16 Channel Digital Output Modules

Output Process Image															
Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
controls DO 16 Channel 16	controls DO 15 Channel 15	controls DO 14 Channel 14	controls DO 13 Channel 13	controls DO 12 Channel 12	controls DO 11 Channel 11	controls DO 10 Channel 10	controls DO 9 Channel 9	controls DO 8 Channel 8	controls DO 7 Channel 7	controls DO 6 Channel 6	controls DO 5 Channel 5	controls DO 4 Channel 4	controls DO 3 Channel 3	controls DO 2 Channel 2	controls DO 1 Channel 1
	115	114	113	112	111	110	109	108	107	106	105	104	103	102	101

14.1.2.9 8 Channel Digital Input/Output Modules

750-1502, -1506

Table 153: 8 Channel Digital Input/Output Modules

Input Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Data bit DI 8 Channel 8	Data bit DI 7 Channel 7	Data bit DI 6 Channel 6	Data bit DI 5 Channel 5	Data bit DI 4 Channel 4	Data bit DI 3 Channel 3	Data bit DI 2 Channel 2	Data bit DI 1 Channel 1

Output Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
controls DO 8 Channel 8	controls DO 7 Channel 7	controls DO 6 Channel 6	controls DO 5 Channel 5	controls DO 4 Channel 4	controls DO 3 Channel 3	controls DO 2 Channel 2	controls DO 1 Channel 1

14.1.3 Analog Input Modules

The analog input modules provide 16-bit measured data and 8 control/status bits per channel.

The PFC200 controller only uses the 8 control/status bits internally for configuration/parameterization (e.g., via *WAGO-I/O-CHECK*).

Therefore, only the 16-bit measurement values for each channel are in Intel format and are mapped by word in the input process image for the PFC200 controller.

When digital input modules are also present in the node, the analog input data is always mapped into the Input Process Image in front of the digital data.

Information



Information on the structure of control and status bytes

For detailed information on the structure of a particular I/O module's control/status bytes, please refer to that module's manual. Manuals for each module can be found on the Internet at www.wago.com.

14.1.3.1 1 Channel Analog Input Modules

750-491, (and all variations)

Table 154: 1 Channel Analog Input Modules

Input Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	D1	D0	Measured Value U_D
1	D3	D2	Measured Value U_{ref}

14.1.3.2 2 Channel Analog Input Modules

750-452, -454, -456, -461, -462, -465, -466, -467, -469, -472, -474, -475, 476, -477, -478, -479, -480, -481, -483, -485, -492, (and all variations),
753-452, -454, -456, -461, -465, -466, -467, -469, -472, -474, -475, 476, -477, 478, -479, -483, -492, (and all variations)

Table 155: 2 Channel Analog Input Modules

Input Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	D1	D0	Measured Value Channel 1
1	D3	D2	Measured Value Channel 2

14.1.3.3 4 Channel Analog Input Modules

750-450, -453, -455, -457, -459, -460, -468, (and all variations),
753-453, -455, -457, -459

Table 156: 4 Channel Analog Input Modules

Input Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	D1	D0	Measured Value Channel 1
1	D3	D2	Measured Value Channel 2
2	D5	D4	Measured Value Channel 3
3	D7	D6	Measured Value Channel 4

14.1.3.4 3-Phase Power Measurement Module

750-493

The above Analog Input Modules have a total of 9 bytes of user data in both the Input and Output Process Image (6 bytes of data and 3 bytes of control/status). The following tables illustrate the Input and Output Process Image, which has a total of 6 words mapped into each image. Word alignment is applied.

Table 157: 3-Phase Power Measurement Module

Input Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	-	S0	Status byte 0
1	D1	D0	Input data word 1
2	-	S1	Status byte 1
3	D3	D2	Input data word 2
4	-	S2	Status byte 2
5	D5	D4	Input data word 3

Output Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	-	C0	Control byte 0
1	D1	D0	Output data word 1
2	-	C1	Control byte 1
3	D3	D2	Output data word 2
4	-	C2	Control byte 2
5	D5	D4	Output data word 3

14.1.3.5 8 Channel Analog Input Modules

750-451

Table 158: 8 Channel Analog Input Modules

Input Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	D1	D0	Measured Value Channel 1
1	D3	D2	Measured Value Channel 2
2	D5	D4	Measured Value Channel 3
3	D7	D6	Measured Value Channel 4
4	D9	D8	Measured Value Channel 5
5	D11	D10	Measured Value Channel 6
6	D13	D12	Measured Value Channel 7
7	D15	D14	Measured Value Channel 8

14.1.4 Analog Output Modules

The analog output modules provide 16-bit output values and 8 control/status bits per channel.

The PFC200 controller only uses the 8 control/status bits internally for configuration/parameterization (e.g., via *WAGO-I/O-CHECK*).

Therefore, only the 16-bit measurement values for each channel are in Intel format and are mapped by word in the output process image for the PFC200 controller.

When digital output modules are also present in the node, the analog output data is always mapped into the Output Process Image in front of the digital data.



Information

Information on the structure of control and status bytes

For detailed information on the structure of a particular I/O module's control/status bytes, please refer to that module's manual. Manuals for each module can be found on the Internet at www.wago.com.

14.1.4.1 2 Channel Analog Output Modules

750-550, -552, -554, -556, -560, -562, 563, -585, (and all variations),
753-550, -552, -554, -556

Table 159: 2 Channel Analog Output Modules

Output Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	D1	D0	Output Value Channel 1
1	D3	D2	Output Value Channel 2

14.1.4.2 4 Channel Analog Output Modules

750-553, -555, -557, -559,
753-553, -555, -557, -559

Table 160: 4 Channel Analog Output Modules

Output Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	D1	D0	Output Value Channel 1
1	D3	D2	Output Value Channel 2
2	D5	D4	Output Value Channel 3
3	D7	D6	Output Value Channel 4

14.1.5 Specialty Modules

WAGO has a host of Specialty I/O modules that perform various functions. With individual modules beside the data bytes also the control/status byte is mapped in the process image.

The control/status byte is required for the bidirectional data exchange of the module with the higher-ranking control system. The control byte is transmitted from the control system to the module and the status byte from the module to the control system.

This allows, for example, setting of a counter with the control byte or displaying of overshooting or undershooting of the range with the status byte.

The control/status byte always is in the process image in the Low byte.

Information



Information to the structure of the Control/Status byte

For detailed information about the structure of a particular module's control/status byte, please refer to that module's manual. Manuals for each module can be found on the Internet under: www.wago.com.

14.1.5.1 Counter Modules

750-404, (and all variations except of /000-005),
753-404, (and variation /000-003)

The above Counter Modules have a total of 5 bytes of user data in both the Input and Output Process Image (4 bytes of counter data and 1 byte of control/status). The counter value is supplied as 32 bits. The following tables illustrate the Input and Output Process Image, which has a total of 3 words mapped into each image. Word alignment is applied.

Table 161: Counter Modules 750-404, (and all variations except of /000-005),
753-404, (and variation /000-003)

Input Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	-	S	Status byte
1	D1	D0	Counter value
2	D3	D2	

Output Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	-	C	Control byte
1	D1	D0	Counter setting value
2	D3	D2	

750-404/000-005

The above Counter Modules have a total of 5 bytes of user data in both the Input and Output Process Image (4 bytes of counter data and 1 byte of control/ status). The two counter values are supplied as 16 bits. The following tables illustrate the Input and Output Process Image, which has a total of 3 words mapped into each image. Word alignment is applied.

Table 162: Counter Modules 750-404/000-005

Input Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	-	S	Status byte
1	D1	D0	Counter Value of Counter 1
2	D3	D2	Counter Value of Counter 2

Output Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	-	C	Control byte
1	D1	D0	Counter Setting Value of Counter 1
2	D3	D2	Counter Setting Value of Counter 2

750-638,
753-638

The above Counter Modules have a total of 6 bytes of user data in both the Input and Output Process Image (4 bytes of counter data and 2 bytes of control/status). The two counter values are supplied as 16 bits. The following tables illustrate the Input and Output Process Image, which has a total of 4 words mapped into each image. Word alignment is applied.

Table 163: Counter Modules 750-638, 753-638

Input Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	-	S0	Status byte von Counter 1
1	D1	D0	Counter Value von Counter 1
2	-	S1	Status byte von Counter 2
3	D3	D2	Counter Value von Counter 2

Output Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	-	C0	Control byte von Counter 1
1	D1	D0	Counter Setting Value von Counter 1
2	-	C1	Control byte von Counter 2
3	D3	D2	Counter Setting Value von Counter 2

14.1.5.2 Pulse Width Modules

750-511, (and all variations /xxx-xxx)

The above Pulse Width modules have a total of 6 bytes of user data in both the Input and Output Process Image (4 bytes of channel data and 2 bytes of control/status). The two channel values are supplied as 16 bits. Each channel has its own control/status byte. The following table illustrates the Input and Output Process Image, which has a total of 4 words mapped into each image. Word alignment is applied.

Table 164: Pulse Width Modules 750-511, /xxx-xxx

Input and Output Process			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	-	C0/S0	Control/Status byte of Channel 1
1	D1	D0	Data Value of Channel 1
2	-	C1/S1	Control/Status byte of Channel 2
3	D3	D2	Data Value of Channel 2

14.1.5.3 Serial Interface Modules with alternative Data Format

750-650, (and the variations /000-002, -004, -006, -009, -010, -011, -012, -013),
750-651, (and the variations /000-001, -002, -003),
750-653, (and the variations /000-002, -007),
753-650, -653

Note



The process image of the / 003-000-variants depends on the parameterized operating mode!

With the freely parameterizable variations /003 000 of the serial interface modules, the desired operation mode can be set. Dependent on it, the process image of these modules is then the same, as from the appropriate variation.

The above Serial Interface Modules with alternative data format have a total of 4 bytes of user data in both the Input and Output Process Image (3 bytes of serial data and 1 byte of control/status). The following table illustrates the Input and Output Process Image, which have a total of 2 words mapped into each image. Word alignment is applied.

Table 165: Serial Interface Modules with alternative Data Format

Input and Output Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	D0	C/S	Data byte	Control/status byte
1	D2	D1	Data bytes	

14.1.5.4 Serial Interface Modules with Standard Data Format

750-650/000-001, -014, -015, -016
750-653/000-001, -006

The above Serial Interface Modules with Standard Data Format have a total of 6 bytes of user data in both the Input and Output Process Image (5 bytes of serial data and 1 byte of control/status). The following table illustrates the Input and Output Process Image, which have a total of 3 words mapped into each image. Word alignment is applied.

Table 166: Serial Interface Modules with Standard Data Format

Input and Output Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	D0	C/S	Data byte	Control/status byte
1	D2	D1	Data bytes	
2	D4	D3		

14.1.5.5 Data Exchange Module

750-654, (and the variation /000-001)

The Data Exchange modules have a total of 4 bytes of user data in both the Input and Output Process Image. The following tables illustrate the Input and Output Process Image, which has a total of 2 words mapped into each image. Word alignment is applied.

Table 167: Data Exchange Module

Input and Output Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	D1	D0	Data bytes
1	D3	D2	

14.1.5.6 SSI Transmitter Interface Modules

750-630 (and all variations)

Note



The process image of the / 003-000-variants depends on the parameterized operating mode!

The operating mode of the configurable /003-000 I/O module versions can be set. Based on the operating mode, the process image of these I/O modules is then the same as that of the respective version.

The above SSI Transmitter Interface modules have a total of 4 bytes of user data in the Input Process Image, which has 2 words mapped into the image. Word alignment is applied.

Table 168: SSI Transmitter Interface Modules

Input Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	D1	D0	Data bytes
1	D3	D2	

14.1.5.7 Incremental Encoder Interface Modules

750-631/000-004, -010, -011

The above Incremental Encoder Interface modules have 5 bytes of input data and 3 bytes of output data. The following tables illustrate the Input and Output Process Image, which have 4 words into each image. Word alignment is applied.

Table 169: Incremental Encoder Interface Modules 750-631/000-004, --010, -011

Input Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	-	S	not used Status byte
1	D1	D0	Counter word
2	-	-	not used
3	D4	D3	Latch word

Output Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	-	C	not used Control byte
1	D1	D0	Counter setting word
2	-	-	not used
3	-	-	not used

750-634

The above Incremental Encoder Interface module has 5 bytes of input data (6 bytes in cycle duration measurement mode) and 3 bytes of output data. The following tables illustrate the Input and Output Process Image, which has 4 words mapped into each image. Word alignment is applied.

Table 170: Incremental Encoder Interface Modules 750-634

Input Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	-	S	not used Status byte
1	D1	D0	Counter word
2	-	(D2) *)	not used (Periodic time)
3	D4	D3	Latch word

*) If cycle duration measurement mode is enabled in the control byte, the cycle duration is given as a 24-bit value that is stored in D2 together with D3/D4.

Output Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	-	C	not used Control byte
1	D1	D0	Counter setting word
2	-	-	not used
3	-	-	

750-637

The above Incremental Encoder Interface Module has a total of 6 bytes of user data in both the Input and Output Process Image (4 bytes of encoder data and 2 bytes of control/status). The following table illustrates the Input and Output Process Image, which have 4 words mapped into each image. Word alignment is applied.

Table 171: Incremental Encoder Interface Modules 750-637

Input and Output Process Image			
Offset	Byte Destination		Description
	High Byte	Low Byte	
0	-	C0/S0	Control/Status byte of Channel 1
1	D1	D0	Data Value of Channel 1
2	-	C1/S1	Control/Status byte of Channel 2
3	D3	D2	Data Value of Channel 2

750-635,
753-635

The above Digital Pulse Interface module has a total of 4 bytes of user data in both the Input and Output Process Image (3 bytes of module data and 1 byte of control/status). The following table illustrates the Input and Output Process Image, which have 2 words mapped into each image. Word alignment is applied.

Table 172: Digital Pulse Interface Modules 750-635

Input and Output Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	D0	C0/S0	Data byte	Control/status byte
1	D2	D1	Data bytes	

14.1.5.8 DC-Drive Controller

750-636

The DC-Drive Controller maps 6 bytes into both the input and output process image. The data sent and received are stored in up to 4 input and output bytes (D0 ... D3). Two control bytes (C0, C1) and two status bytes (S0/S1) are used to control the I/O module and the drive.

In addition to the position data in the input process image (D0 ... D3), it is possible to display extended status information (S2 ... S5). Then the three control bytes (C1 ... C3) and status bytes (S1 ... S3) are used to control the data flow.

Bit 3 of control byte C1 (C1.3) is used to switch between the process data and the extended status bytes in the input process image (Extended Info_ON). Bit 3 of status byte S1 (S1.3) is used to acknowledge the switching process.

Table 173: DC-Drive Controller 750-636

Input Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	S1	S0	Status byte S1	Status byte S0
1	D1*) / S3**)	D0*) / S2**)	Actual position*) / Extended status byte S3**)	Actual position (LSB) / Extended status byte S2**)
2	D3*) / S5**)	D2*) / S4**)	Actual position (MSB) / Extended status byte S3**)	Actual position*) / Extended status byte S4**)

*) ExtendedInfo_ON = '0'.

***) ExtendedInfo_ON = '1'.

Output Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	C1	C0	Control byte C1	Control byte C0
1	D1	D0	Setpoint position	Setpoint position (LSB)
2	D3	D2	Setpoint position (MSB)	Setpoint position

14.1.5.9 Stepper Controller

750-670

The Stepper controller RS422 / 24 V / 20 mA 750-670 provides the fieldbus coupler 12 bytes input and output process image via 1 logical channel. The data to be sent and received are stored in up to 7 output bytes (D0 ... D6) and 7 input bytes (D0 ... D6), depending on the operating mode.

Output byte D0 and input byte D0 are reserved and have no function assigned.

One I/O module control and status byte (C0, S0) and 3 application control and status bytes (C1 ... C3, S1 ... S3) provide the control of the data flow.

Switching between the two process images is conducted through bit 5 in the control byte (C0 (C0.5)). Activation of the mailbox is acknowledged by bit 5 of the status byte S0 (S0.5).

Table 174: Stepper Controller RS 422 / 24 V / 20 mA 750-670

Input Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	reserved	S0	reserved	Status byte S0
1	D1	D0	Process data*) / Mailbox**)	
2	D3	D2		
3	D5	D4		
4	S3	D6	Status byte S3	Process data*) / reserved**)
5	S1	S2	Status byte S1	Status byte S2

*) Cyclic process image (Mailbox disabled)

***) Mailbox process image (Mailbox activated)

Output Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	reserved	C0	reserved	Control byte C0
1	D1	D0	Process data*) / Mailbox**)	
2	D3	D2		
3	D5	D4		
4	C3	D6	Control byte C3	Process data*) / reserved**)
5	C1	C2	Control byte C1	Control byte C2

*) Cyclic process image (Mailbox disabled)

***) Mailbox process image (Mailbox activated)

14.1.5.10 RTC Module

750-640

The RTC Module has a total of 6 bytes of user data in both the Input and Output Process Image (4 bytes of module data and 1 byte of control/status and 1 byte ID for command). The following table illustrates the Input and Output Process Image, which have 3 words mapped into each image. Word alignment is applied.

Table 175: RTC Module 750-640

Input and Output Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	ID	C/S	Command byte	Control/status byte
1	D1	D0	Data bytes	
2	D3	D2		

14.1.5.11 DALI/DSI Master Module

750-641

The DALI/DSI Master module has a total of 6 bytes of user data in both the Input and Output Process Image (5 bytes of module data and 1 byte of control/status). The following tables illustrate the Input and Output Process Image, which have 3 words mapped into each image. Word alignment is applied.

Table 176: DALI/DSI Master Module 750-641

Input Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	D0	S	DALI Response	Status byte
1	D2	D1	Message 3	DALI Address
2	D4	D3	Message 1	Message 2

Output Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	D0	C	DALI command, DSI dimming value	Control byte
1	D2	D1	Parameter 2	DALI Address
2	D4	D3	Command extension	Parameter 1

14.1.5.12 DALI Multi-Master Module

753-647

The DALI Multi-Master module occupies a total of 24 bytes in the input and output range of the process image.

The DALI Multi-Master module can be operated in "Easy" mode (default) and "Full" mode. "Easy" mode is used to transmit simply binary signals for lighting control. Configuration or programming via DALI master module is unnecessary in "Easy" mode.

Changes to individual bits of the process image are converted directly into DALI commands for a pre-configured DALI network. 22 bytes of the 24-byte process image can be used directly for switching of electronic ballasts (ECG), groups or scenes in "Easy" mode. Switching commands are transmitted via DALI and group addresses, where each DALI and each group address is represented by a 2-bit pair.

The structure of the process data is described in detail in the following tables.

Table 177: Overview of Input Process Image in the "Easy" Mode

Input process image			
Offset	Byte designation		Note
	High byte	Low byte	
0	-	S	res. Status, activate broadcast Bit 0: 1-/2-button mode Bit 2: Broadcast status ON/OFF Bit 1,3-7: -
1	DA4...DA7	DA0...DA3	Bitpaar für DALI-Adresse DA0: Bit 1: Bit set = ON Bit not set = OFF Bit 2: Bit set = Error Bit not set = No error Bit pairs DA1 ... DA63 similar to DA0.
2	DA12...DA15	DA8...DA11	
3	DA20...DA23	DA16...DA19	
4	DA28...DA31	DA24...DA27	
5	DA36...DA39	DA32...DA35	
6	DA44...DA47	DA40...DA43	
7	DA52...DA55	DA48...DA51	
8	DA60...DA63	DA56...DA59	
9	GA4...GA7	GA0...GA3	Bit pair for DALI group address GA0: Bit 1: Bit set = ON Bit not set = OFF Bit 2: Bit set = Error Bit not set = No error Bit pairs GA1 ... GA15 similar to GA0.
10	GA12...GA15	GA8...GA11	
11	-	-	

DA = DALI address
GA = Group address

Table 178: Overview of the Output Process Image in the "Easy" Mode

Output process image			
Offset	Byte designation		Note
	High byte	Low byte	
0	-	S	res. Broadcast ON/OFF and activate: Bit 0: Broadcast ON Bit 1: Broadcast OFF Bit 2: Broadcast ON/OFF/dimming Bit 3: Broadcast short ON/OFF Bits 4 ... 7: reserved
1	DA4...DA7	DA0...DA3	Bit pair for DALI address DA0: Bit 1: short: DA switch ON long: dimming, brighter Bit 2: short: DA switch OFF long: dimming, darker Bit pairs DA1 ... DA63 similar to DA0.
2	DA12...DA15	DA8...DA11	
3	DA20...DA23	DA16...DA19	
4	DA28...DA31	DA24...DA27	
5	DA36...DA39	DA32...DA35	
6	DA44...DA47	DA40...DA43	
7	DA52...DA55	DA48...DA51	
8	DA60...DA63	DA56...DA59	
9	GA4...GA7	GA0...GA3	Bitpaar für DALI-Gruppenadresse GA0: Bit 1: short: GA switch ON long: dimming, brighter Bit 2: short: GA switch OFF long: dimming, darker Bit pairs GA1 ... GA15 similar to GA0.
10	GA12...GA15	GA8...GA11	
11	Bit 8...15	Bit 0...7	

DA = DALI address
GA = Group address

14.1.5.13 LON[®] FTT Module

753-648

The process image of the LON[®] FTT module consists of a control/status byte and 23 bytes of bidirectional communication data that is processed by the WAGO-I/O-*PRO* function block "LON_01.lib". This function block is essential for the function of the LON[®] FTT module and provides a user interface on the control side.

14.1.5.14 EnOcean Radio Receiver

750-642

The EnOcean radio receiver has a total of 4 bytes of user data in both the Input and Output Process Image (3 bytes of module data and 1 byte of control/status). The following tables illustrate the Input and Output Process Image, which have 2 words mapped into each image. Word alignment is applied.

Table 179: EnOcean Radio Receiver 750-642

Input Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	D0	S	Data byte	Status byte
1	D2	D1	Data bytes	

Output Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	-	C	not used	Control byte
1	-	-	not used	

14.1.5.15 MP Bus Master Module

750-643

The MP Bus Master Module has a total of 8 bytes of user data in both the Input and Output Process Image (6 bytes of module data and 2 bytes of control/status). The following table illustrates the Input and Output Process Image, which have 4 words mapped into each image. Word alignment is applied.

Table 180: MP Bus Master Module 750-643

Input and Output Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	C1/S1	C0/S0	extended Control/Status byte	Control/status byte
1	D1	D0	Data bytes	
2	D3	D2		
3	D5	D4		

14.1.5.16 Bluetooth® RF-Transceiver

750-644

The size of the process image for the *Bluetooth*® module can be adjusted to 12, 24 or 48 bytes.

It consists of a control byte (input) or status byte (output); an empty byte; an overlay able mailbox with a size of 6, 12 or 18 bytes (mode 2); and the *Bluetooth*® process data with a size of 4 to 46 bytes.

Thus, each *Bluetooth*® module uses between 12 and 48 bytes in the process image. The sizes of the input and output process images are always the same.

The first byte contains the control/status byte; the second contains an empty byte.

Process data attach to this directly when the mailbox is hidden. When the mailbox is visible, the first 6, 12 or 18 bytes of process data are overlaid by the mailbox data, depending on their size. Bytes in the area behind the optionally visible mailbox contain basic process data. The internal structure of the *Bluetooth*® process data can be found in the documentation for the *Bluetooth*® 750-644 RF Transceiver.

The mailbox and the process image sizes are set with the startup tool WAGO-I/O-CHECK.

Table 181: Bluetooth® RF-Transceiver 750-644

Input and Output Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	-	C0/S0	not used	Control/status byte
1	D1	D0	Mailbox (0, 3, 6 or 9 words) and Process data (2-23 words)	
2	D3	D2		
3	D5	D4		
...		
max. 23	D45	D44		

14.1.5.17 Vibration Velocity/Bearing Condition Monitoring VIB I/O

750-645

The Vibration Velocity/Bearing Condition Monitoring VIB I/O has a total of 12 bytes of user data in both the Input and Output Process Image (8 bytes of module data and 4 bytes of control/status). The following table illustrates the Input and Output Process Image, which have 8 words mapped into each image. Word alignment is applied.

Table 182: Vibration Velocity/Bearing Condition Monitoring VIB I/O 750-645

Input and Output Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	-	C0/S0	not used	Control/status byte (log. Channel 1, Sensor input 1)
1	D1	D0	Data bytes (log. Channel 1, Sensor input 1)	
2	-	C1/S1	not used	Control/status byte (log. Channel 2, Sensor input 2)
3	D3	D2	Data bytes (log. Channel 2, Sensor input 2)	
4	-	C2/S2	not used	Control/status byte (log. Channel 3, Sensor input 1)
5	D5	D4	Data bytes (log. Channel 3, Sensor input 3)	
6	-	C3/S3	not used	Control/status byte (log. Channel 4, Sensor input 2)
7	D7	D6	Data bytes (log. Channel 4, Sensor input 2)	

14.1.5.18 KNX/EIB/TP1 Module

753-646

The KNX/TP1 module appears in router and device mode with a total of 24-byte user data within the input and output area of the process image, 20 data bytes and 2 control/status bytes. Even though the additional bytes S1 or C1 are transferred as data bytes, they are used as extended status and control bytes. The opcode is used for the read/write command of data and the triggering of specific functions of the KNX/EIB/TP1 module. Word-alignment is used to assign 12 words in the process image. Access to the process image is not possible in router mode. Telegrams can only be tunneled.

In device mode, access to the KNX data can only be performed via special function blocks of the IEC application. Configuration using the ETS engineering tool software is required for KNX.

Table 183: KNX/EIB/TP1 Module 753-646

Input Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	-	S0	not used	Status byte
1	S1	OP	extended Status byte	Opcode
2	D1	D0	Data byte 1	Data byte 0
3	D3	D2	Data byte 3	Data byte 2
4	D5	D4	Data byte 5	Data byte 4
5	D7	D6	Data byte 7	Data byte 6
6	D9	D8	Data byte 9	Data byte 8
7	D11	D10	Data byte 11	Data byte 10
8	D13	D12	Data byte 13	Data byte 12
9	D15	D14	Data byte 15	Data byte 14
10	D17	D16	Data byte 17	Data byte 16
11	D19	D18	Data byte 19	Data byte 18

Output Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	-	C0	not used	Control byte
1	C1	OP	extended Control byte	Opcode
2	D1	D0	Data byte 1	Data byte 0
3	D3	D2	Data byte 3	Data byte 2
4	D5	D4	Data byte 5	Data byte 4
5	D7	D6	Data byte 7	Data byte 6
6	D9	D8	Data byte 9	Data byte 8
7	D11	D10	Data byte 11	Data byte 10
8	D13	D12	Data byte 13	Data byte 12
9	D15	D14	Data byte 15	Data byte 14
10	D17	D16	Data byte 17	Data byte 16
11	D19	D18	Data byte 19	Data byte 18

14.1.5.19 AS-interface Master Module

750-655

The length of the process image of the AS-interface master module can be set to fixed sizes of 12, 20, 24, 32, 40 or 48 bytes.

It consists of a control or status byte, a mailbox with a size of 0, 6, 10, 12 or 18 bytes and the AS-interface process data, which can range from 0 to 32 bytes.

The AS-interface master module has a total of 6 to maximally 24 words data in both the Input and Output Process Image. Word alignment is applied.

The first Input and output word, which is assigned to an AS-interface master module, contains the status / control byte and one empty byte.

Subsequently the mailbox data are mapped, when the mailbox is permanently superimposed (Mode 1).

In the operating mode with suppressible mailbox (Mode 2), the mailbox and the cyclical process data are mapped next.
The following words contain the remaining process data.

The mailbox and the process image sizes are set with the startup tool WAGO-I/O-CHECK.

Table 184: AS-interface Master Module 750-655

Input and Output Process Image				
Offset	Byte Destination		Description	
	High Byte	Low Byte		
0	-	C0/S0	not used	Control/status byte
1	D1	D0	Mailbox (0, 3, 5, 6 or 9 words)/ Process data (0-16 words)	
2	D3	D2		
3	D5	D4		
...		
max. 23	D45	D44		

14.1.6 System Modules

14.1.6.1 System Modules with Diagnostics

750-610, -611

The modules provide 2 bits of diagnostics in the Input Process Image for monitoring of the internal power supply.

Table 185: System Modules with Diagnostics 750-610, -611

Input Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
						Diagnostic bit S 2 Fuse	Diagnostic bit S 1 Fuse

14.1.6.2 Binary Space Module

750-622

The Binary Space Modules behave alternatively like 2 channel digital input modules or output modules and seize depending upon the selected settings 1, 2, 3 or 4 bits per channel. According to this, 2, 4, 6 or 8 bits are occupied then either in the process input or the process output image.

Table 186: Binary Space Module 750-622 (with Behavior Like 2 Channel Digital Input)

Input and Output Process Image							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
(Data bit DI 8)	(Data bit DI 7)	(Data bit DI 6)	(Data bit DI 5)	(Data bit DI 4)	(Data bit DI 3)	Data bit DI 2	Data bit DI 1

14.2 CODESYS Libraries

Additional functions for the controller 750-8204 are provided using libraries.

14.2.1 General Libraries

This section contains general CODESYS libraries supported by the controller 750-8204.

14.2.1.1 CODESYS System Libraries

All of the functions of the CODESYS system libraries listed below are supported.

Table 187: CODESYS System Libraries

Library	Function	C/IEC 61131
Analyzation.lib	Analysis of boolean expressions	C and IEC 61131
AnalyzationNew.lib	Analysis of boolean expressions	C and IEC 61131
Iecsfc.lib	Provision of implicit variables in the SFC (sequential function chart)	IEC 61131
NetVarUdp_LIB_V23.lib	Implementation for network variables	IEC 61131
Standard.LIB	Offers various standard functions	C
SysLibAlarmTrend.lib	Supports alarm and trend tasks	IEC 61131
SysLibCallback.lib	For installing call-back handlers and event handlers	C
SysLibDir.lib	For accessing directories	C
SysLibDirect.lib	Access to variables using indices	C
SysLibEvent.lib	Handling of events in the system	C
SysLibFileStream.lib	File handling using ANSI-C functions	C
SysLibGetAddress.lib	Returns addresses and the size of memory segments	C
SysLibIecTasks.lib	Administration of IEC tasks	C
SysLibMem.lib	Memory administration	C
SysLibPlcCtrl.lib	Control of the PLC from outside the PLC program	C
SysLibProjectInfo.lib	Reading out of information about the CODESYS project	C
SysLibSem.lib	Handling of semaphores	C
SysLibSockets.lib	Socket handling	C
SysLibSocketsAsync.lib	Socket handling, asynchronous	C
SysLibStr.lib	String functions	C
SysLibTasks.lib	Administration of tasks	C
SysLibTime.lib	Administration of real-time clock	C
SysLibVisu.lib	Dynamic visualization	C

Table 187: CODESYS System Libraries

Library	Function	C/IEC 61131
SysTaskInfo.lib	Evaluation of task information in the Online mode	IEC 61131
Util.lib	Various logical operations	IEC 61131
Util_no_Real.lib	Various logical operations	IEC 61131

Additional information about the libraries is given in the online Help function for CODESYS-IDE.

14.2.1.2 SysLibCom.lib

The controller 750-8204 supports the following function blocks of the “SysLibCom.lib” library:

- SysComClose
- SysComGetVersion2300
- SysComOpen
- SysComRead
- SysComSetSettings
- SysComSetSettingsEx
- SysComWrite

Note



Observe restrictions on the settings for stop bits!

The setting “1.5 stop bits” is not supported by controller 750-8204.

Additional information about this is given in the online Help function for CODESYS-IDE.

14.2.1.3 SysLibFile.lib

The controller 750-8204 supports the following function blocks of the “SysLibCom.lib” library:

- SysFileClose
- SysFileCopy
- SysFileDelete
- SysFileEOF
- SysFileGetPos
- SysFileGetSize
- SysFileGetTime
- SysFileOpen
- SysFileRead
- SysFileRename
- SysFileSetPos
- SysFileWrite

Note



Ensure that files are saved!

Files are not reliably saved on the data medium until you call up the “SysFileClose” function block!

Additional information about this is given in the online Help function for CODESYS-IDE.

14.2.1.4 SysLibFileAsync.lib

The controller 750-8204 supports the following function blocks of the “SysLibCom.lib” library:

- SysFileCloseAsync
- SysFileCopyAsync
- SysFileDeleteAsync
- SysFileEOFAsync
- SysFileGetPosAsync
- SysFileGetSizeAsync
- SysFileGetTimeAsync
- SysFileOpenAsync
- SysFileReadAsync
- SysFileRenameAsync
- SysFileSetPosAsync
- SysFileWriteAsync

Note



Ensure that files are saved!

Files are not reliably saved to the data medium until you call up the “SysFileCloseAsync” function block.

Additional information about this is given in the online Help function for CODESYS-IDE.

14.2.1.5 SysLibRtc.lib

The controller 750-8204 supports the following function blocks of the “SysLibRtc.lib” library:

- SysRtcGetHourMode
- SysRtcGetTime
- SysRtcSetTime

Additional information about this is given in the online Help function for CODESYS-IDE.

14.2.1.6 BusDiag.lib

The controller 750-8204 supports the following function blocks of the “BusDiag.lib” library:

- DiagGetBusState
- DiagGetState

The document containing a description of this library and the function blocks it includes is available for download on the Internet at www.wago.com.

The values for the input variables “DEVICE NUMBER” of the “DiagGetBusState” and “DiagGetState” functions are based on the particular device and bus system and are as follows for the controller 750-8204:

Table 188: Input Variable “DEVICE NUMBER”

Bus System	Value
Internal data bus	0
MODBUS	1
CANopen	2

14.2.1.7 mod_com.lib

The controller 750-8204 supports the following function blocks of the “mod_com.lib” library:

- ADD_PI_INFORMATION
- CRC16
- FBUS_ERROR_INFORMATION
- GET_DIGITAL_INPUT_OFFSET
- GET_DIGITAL_OUTPUT_OFFSET
- KBUS_ERROR_INFORMATION
- MOD_COM_VERSION
- PI_INFORMATION
- SET_DIGITAL_INPUT_OFFSET
- SET_DIGITAL_OUTPUT_OFFSET
- SLAVE_ADDRESS

The document containing a description of this library and the function blocks it includes is available for download on the Internet at www.wago.com.

14.2.1.8 SerComm.lib

The controller 750-8204 supports the following function blocks of the “SerComm.lib” library:

- SERCOMM
- SERCOMM_VERSION

The document containing a description of this library and the function blocks it includes is available for download on the Internet at www.wago.com.

14.2.1.9 WagoConfigToolLIB.lib

The following table shows call-ups that allow you to configure and parameterize the controller from the PLC program or Linux[®] via the “ConfigToolFB” function block (see parameter “stCallString”). In addition to WBM and the CBM, this is another variant to configure the controller for operational requirements.

The configuration directory for this under Linux[®] is: `/etc/config-tools/`




Figure 134: Graphical Representation of the “ConfigToolFB” Function Block

Table 189: Description of the Configuration Scripts for “Information”

Parameters	Status	Call-Up	Output/Input	Effective
Controller Details: Identifies various information about the controller				
Product Description	read	get_coupler_details product-description	Product description	Immediately
Order Number	read	get_coupler_details order-number	Item number of the controller	Immediately
Firmware Revision	read	get_coupler_details firmware-revision	Firmware version of the controller	Immediately
Licence Information	read	get_coupler_details license-information	CODESYS license details	Immediately
Network Details X1: Identifies the parameters currently used for the ETHERNET interface X1/X2 in “switched” mode or for the ETHERNET interface X1 in “separated” mode				
State	read	get_actual_eth_config X1 state	Status of the interface. Possible return values: - enabled - disabled	Immediately
Mac Address	read	get_actual_eth_config X1 mac-address	Display of the MAC address	Immediately
IP Address	read	get_actual_eth_config X1 ip-address	Display of current IP address	Immediately
Subnet Mask	read	get_actual_eth_config X1 subnet-mask	Display of the current subnet mask	Immediately
Network Details X2: Identifies the parameters currently used for the ETHERNET interface X2 in “separated” mode				
See “Network Details X1”. When calling these up, replace “X1” with “X2” (in “separated” mode only).				

Table 190: Description of the Configuration Scripts for “CODESYS”

Parameters	Status	Call-Up	Output/Input	Effective
Information				
CODESYS Web-Server Version	read	get_coupler_details codesys-Web-Server-version	CODESYS Web server version	Immediately
Project Details				
Date	read	get_rts_info project date	Display of the project information specified in CODESYS (Menu > Project > Project Information)	Immediately
Title	read	get_rts_info project title		Immediately
Version	read	get_rts_info project version		Immediately
Author	read	get_rts_info project author		Immediately
Description	read	get_rts_info project description		Immediately
CODESYS State				
State	read	get_rts_info state	Display of the CODESYS status (RUN or STOP)	Immediately
Boot Project Location				
Boot Project Location	read	get_rts3scfg_value PLC Files	Reading of the storage location of the boot project Possible return values: - HOME:// - CARD://	Immediately
	write	change_rts_config area=PLC Files=<value>	Change the storage location for the boot project. Possible entries for <Value>: - HOME:// - CARD://	

Table 191: Description of the Configuration Scripts for “Networking - Host-/Domain-Name”

Parameters	Status	Call-Up	Output/Input	Effective
Host Name				
Host Name	read	get_coupler_details hostname	Display of the host name. The return value is blank when /etc/hostname is empty. For details see the parameter “Actual Hostname”.	Immediately
	write	change_hostname hostname=<String>	Changing the host name. Input a host name for <String>.	After restart
Actual Hostname	read	get_coupler_details actual-hostname	The actual host name (if /etc/hostname is empty, a unique host name is generated from the MAC address)	Immediately
Domain Name				
Domain Name	read	get_coupler_details domain-name	Display of domain name	Immediately
	write	edit_dns_server domain-name=<String>	Change the domain name. Enter the domain name for <String>.	

Table 192: Description of the Configuration Scripts for “Networking - TCP/IP”

Parameters	Status	Call-Up	Output/Input	Effective
IP Address X1: Identifies the parameters currently used for the ETHERNET interface X1/X2 in “switched” mode or for the ETHERNET interface X1 in “separated” mode				
Type of IP address configuration	read	get_eth_config X1 config-type	Method by which the interface receives its IP address: Possible return values: - static (set statically) - dhcp (per DHC) - bootp (per BootP)	Immediately
	write	config_interfaces interface=X1 config-type=<value> state=enabled	Activate the method by which the interface receives its IP address. Possible entries for <Value>: - static (set statically) - dhcp (per DHC) - bootp (per BootP)	
IP address	read	get_eth_config X1 ip-address	Address set for using a static IP address (static IP).	Immediately
	write	config_interfaces interface=X1 ip-address=<value>	Change IP address for static IP. <Value> must have an IP address with the format “Number.Number.Number.Number”.	
Subnet Mask	read	get_eth_config X1 subnet-mask	Subnet mask set for using a static IP address (Static IP).	Immediately
	write	config_interfaces interface=X1 subnet-mask=<value>	Change subnet mask for static IP. <Value> must have an IP address with the format “Number.Number.Number.Number”.	
IP Address X2: Identifies the parameters currently used for the ETHERNET interface X2 in “separated” mode				
See “IP Address X1”. When calling these up, replace “X1” with “X2” (in “separated” mode only).				

Table 192: Description of the Configuration Scripts for “Networking - TCP/IP”

Parameters	Status	Call-Up	Output/Input	Effective
Default Gateway				
Default Gateway	read	get_coupler_details default-gateway	Display of the standard gateway address.	Immediately
	read	get_eth_config X1 default-gateway	Display of the standard gateway address. Use of “X2” leads to the same result because the value is always written for both interfaces at the same time.	Immediately
	write	config_default_gateway interface=<value> default-gateway- value=<value>	Select the interface you want to use as the standard gateway. Possible entries for interface: - X1 - X2 - none (no standard gateway selected) Default-gateway-value is an IP address with the format “Number.Number.Number.Number”.	Immediately
DNS server				
DNS Server 1	read	get_dns_server 1	DNS server address with the consecutive number 1.	Immediately
	write/ change	edit_dns_server dns-server-nr=1 change=change dns-server- name=<value>	Set the address of the DNS server with 1 as the consecutive number. <Value> is an IP address with the format “Number.Number.Number.Number”.	
	write/ delete	edit_dns_server dns-server-nr=1 delete=delete	Delete the DNS server with the consecutive number 1.	
DNS Server 2 ... n	See “DNS Server 1”. Change the server number each time you call this up (ascending order).			Immediately
Add DNS server	write	edit_dns_server add=add dns-server- name=<value>	Add additional DNS addresses here. <Value> is an IP address with the format “Number.Number.Number.Number”.	Immediately

Table 193: Description of the Configuration Scripts for “Networking - ETHERNET”

Parameters	Status	Call-Up	Output/Input	Effective
Switch Configuration				
Interface Mode	read	get_dsa_mode	Query the switch configuration: Possible return values: - 0 = „switched“ mode - 1 = „separated“ mode	Immediately
	write	set_dsa_mode -v <value>	Set the switch configuration: Possible entries for <value>: - 0 = „switched“ mode - 1 = „separated“ mode	
Interface X1				
Port State	read	get_eth_config X1 state	Query the port state: Possible return values: - enabled - disabled	Immediately
	write	config_ethernet port=X1 state=enabled	Activate port: enabled	
		config_ethernet port=X1 state=disabled	Deactivate port: disabled	
Autonegotiation	read	get_eth_config X1 autoneg	Query the status of the autonegotiation function: Possible return values: - on - off	Immediately
	write	config_ethernet port=X1 autoneg=on	Activate the autonegotiation function: on	
		config_ethernet port=X1 autoneg=off speed=<value> duplex=<value>	Deactivate the autonegotiation function: off Note: You must also indicate the speed and duplex value when you deactivate the autonegotiation function. Possible entries for speed: - 10M - 100M Possible entries for duplex: - half - full	
Speed and Duplex Settings	read	get_eth_config X1 speed	Display of ETHERNET speed	Immediately
	read	get_eth_config X1 duplex	Display of the Duplex mode	
	write	config_ethernet port=X1 autoneg=off speed=<value> duplex=<value>	Change the ETHERNET speed and the Duplex mode. Possible entries for speed: - 10M - 100M Possible entries for duplex: - half - full	
Interface X2				
See “Interface X1”. When calling these up, replace “X1” with “X2”.				

Table 194: Description of the Configuration Scripts for “CODESYS”

Parameters	Status	Call-Up	Output/Input	Effective
Transmission Mode X1				
Autonegotiation	read	get_eth_config X1 autoneg	Query the status of the autonegotiation function. Possible return values: - on - off	Immediately
	write	config_ethernet port=X1 autoneg=on	Activate the autonegotiation function: on	
			config_ethernet port=X1 autoneg=off speed- duplex=<value>	Deactivate the autonegotiation function: off Note: You must also indicate the speed and duplex value when you deactivate the autonegotiation function. Possible entries for <Value>: - 10-half - 10-full - 100-half - 100-full
Speed and Duplex Settings	read	get_eth_config X1 speed	Display of ETHERNET speed	Immediately
	read	get_eth_config X1 duplex	Display of Duplex mode	
	write	config_ethernet port=X1 autoneg=off speed-duplex=<value>	Change the ETHERNET speed and the Duplex mode. Possible entries for <Value>: - 10-half - 10-full - 100-half - 100-full	
Transmission Mode X2				
See “Transmission Mode X1”. When calling, replace “X1” with “X2”.				

Table 195: Description of the Configuration Scripts for “NTP”

Parameters	Status	Call-Up	Output/Input	Effective
Configuration Data				
State	read	get_ntp_config state	Query the status of the NTP server. Possible return values: - enabled - disabled	Immediately
	write	config_sntp state=<value>	Possible entries for <Value>: - enabled - disabled	
Port	read	get_ntp_config port	Port number of the NTP server	Immediately
	write	config_sntp port=<value>	Enter the port number for <Value>.	
Time Server	read	get_ntp_config time-server	Query the IP address of the Time server.	Immediately
	write	config_sntp time-server=<value>	Enter the IP address of the Time server. The <value> can contain an IP address in the format “Number.Number.Number.Number” or a domain name as a string.	
Update Time (seconds)	read	get_ntp_config update-time	Query the polling cycle of the time server.	Immediately
	write	config_sntp update-time=<value>	Specify the time-server's query cycle (in s) for <value>.	

Table 196: Description of the Configuration Scripts for “Clock”

Parameters	Status	Call-Up	Output/Input	Effective
Clock				
Time and Date				
Date on device, local	read	get_clock_data date-local	Local time and date	Immediately
	write	config_clock type=local date=<Datum>	Change date. The format for <date> is: DD.MM.YYYY	
Time on device, UTC	read	get_clock_data time-utc	Time/UTC	Immediately
	write	config_clock type=utc time=<Time>	Change time, based on UTC time. The format for <time> is: hh:mm:ss xx	
Time on device, local	read	get_clock_data time-local	Time/local time	Immediately
	write	config_clock type=local time=<Time>	Change time, based on local time. The format for <time> is: hh:mm:ss xx	
12-Hour-Format	read	get_clock_data display-mode	Presentation format either as 12 or 24-hour format: Possible return values: - 12-hour-format - 24-hour-format	Immediately
	write	config_clock_ display_mode display-mode=<value>	Set the presentation format for the time. Possible entries for <Value>: - 12-hour-format - 24-hour-format	
Time Zone				
TZ-String	read	get_clock_data tz-string	Currently set time zone – original TZ string as stored in the operating system.	Immediately
	write	config_timezone tz-string=<String>	Change TZ string directly. Example of <String>: CET-1CEST, M3.5.0/2,M10.5.0/3	

Table 197: Description of the Configuration Scripts for “Administration”

Parameters	Status	Call-Up	Output/Input	Effective
Administration				
Configuration of Serial Interface				
Configuration of serial interface	read	get_coupler_details RS232-owner	User of the serial interface. Possible return values: - Linux® - None	immediately
	write	config_RS232 owner=<value>	User of the serial interface. Possible entries for <Value>: - Linux® - None	
Reboot Controller				
-	write	start_reboot	Restart the controller.	immediately

Table 198: Description of Configuration Scripts for “Package Server”

Parameters	Status	Call-Up	Output/Input	Valid
Firmware Update				
Medium for active partition	read	get_filesystem_data active-partition-medium	Specifies the medium for the active partition (memory card, internal flash).	Right away
Create firmware backup	write	firmware_backup package-settings=<Value1> package-codesys=<Value2> package-system=<Value3> device-medium=<Value4> auto-update=<Value5>	Generates a backup of the selected packet on the specified medium. Parameter: <Value1> = 1, if “Settings” packet is to be selected. <Value2> = 1, if the “CODESYS Project” packet is to be selected. <Value3> = 1, if the “System” packet is to be selected. <Value4> = Target medium for saving the backup. (memory card, internal flash) <Value5> = 1, if Auto Update is to be activated. Parameters, which are not to be set (1) can either be set to 0 or omitted completely.	Right away

Table 199: Description of Configuration Scripts for “Ports and Services”

Parameters	Status	Call-Up	Output/Input	Valid
Port				
Telnet				
Telnet Port	read	get_port_state telnet	Read the status of the Telnet server. Possible return values: - enabled - disabled	Right away
	write	config_port port=telnet state=<Value>	Possible entries for <Value>: - enabled - disabled	
FTP				
FTP Port	read	config_ssl ftp-status	Read the status of the FTP server. Possible return values: - enabled - disabled	Right away
	write	config_port port=ftp state=<Value>	Possible entries for <Value>: - enabled - disabled	
FTPS				
FTPS Port	read	Config_ssl ftps-status	Read the status of the FTPS port. Possible return values: - enabled - disabled	Right away
	write	config_port port=ftps state=<Value>	Activate/Deactivate FTPS. Possible entries for <Value>: - enabled - disabled	

Table 199: Description of Configuration Scripts for “Ports and Services”

Parameters	Status	Call-Up	Output/Input	Valid
HTTP				
HTTP Port	read	Config_ssl http-status	Read the status of the HTTP port. Possible return values: - enabled - disabled	Right away
	write	config_port port=http state=<Value>	Activate/Deactivate HTTP. Possible entries for <Value>: - enabled - disabled	
HTTPS				
HTTPS Port	read	Config_ssl https-status	Read the status of the HTTPS port. Possible return values: - enabled - disabled	Right away
	write	config_port port=https state=<Value>	Activate/Deactivate HTTPS. Possible entries for <Value>: - enabled - disabled	

Table 199: Description of Configuration Scripts for “Ports and Services”

Parameters	Status	Call-Up	Output/Input	Valid
SSH				
SSH	read	get_ssh_config state	Read the status of the SSH port. Possible return values: - enabled - disabled	Right away
	read	get_ssh_config root-access-state	Indicates whether logon as root is permitted. Possible return values: - enabled - disabled	
	read	get_ssh_config password-request-state	Indicates whether authentication by password (instead of PKI key files) is permitted. Possible return values: - enabled - disabled	
	read	get_ssh_config port-number	Specifies the SSH port	
	write	config_ssh state=<Value>	Activate/Deactivate SSH service. Possible entries for <Value>: - enabled - disabled	
	write	config_ssh port-number=<Value>	Set the SSH port	
	write	config_ssh root-access-state-value=<Value>	Permit/Prohibit logon as root. Possible entries for <Value>: - enabled - disabled	
write	config_ssh password-request-state-value=<Value>	Permit/Prohibit authentication by password. Possible entries for <Value>: - enabled - disabled		
TFTP				
TFTP	read	get_tftp_config state	Read the status of the TFTP port. Possible return values: - enabled - disabled	Right away
	read	get_tftp_config download-dir	Read the TFTP main directory.	
	write	config_tftp state=<Value>	Activate/Deactivate TFTP port. Possible entries for <Value>: - enabled - disabled	
	write	config_tftp download-dir=<Value>	Set the TFTP main directory.	

Table 199: Description of Configuration Scripts for “Ports and Services”

Parameters	Status	Call-Up	Output/Input	Valid
CODESYS				
CODESYS Webserver Port	read	get_port_state codesys-webserver	Read status of the CODESYS Web server. Possible return values: - enabled - disabled	Right away
	write	config_port port=codesys-webserver state=<Value>	Enable/disable the CODESYS Web server. Possible entries for <Value>: - enabled - disabled	
CODESYS Port	read	get_rts3scfg_value PLC DisableTcpIp Programming	Query the status of the value for “DisableTcpIpProgramming” in the CODESYS configuration. Possible return values: - YES: CODESYS port not being used. - NO: CODESYS port in use	Right away
	write	change_rts_config area=PLC disable- tcpip=<Value>	Possible entries for <Value>: - YES: CODESYS port not being used. - NO: CODESYS port in use.	
CODESYS Port Number	read	get_rts3scfg_value PLC TcpIpPort	Value set in the CODESYS configuration for the TCP/IP port.	Right away
	write	change_rts_config area=PLC TcpIpPort=<Value>	Change the CODESYS port number. Enter the TCP/IP port number for <Value>.	
CODESYS Authentication	read	get_rts3scfg_value PASSWORD USEPWD	Read the status of the CODESYS access password query. Possible return values: - 1 - 0	Right away
	write	change_rts_config area=PASSWORD USEPWD=<Value>	Activate/Deactivate CODESYS access password query. Possible entries for <Value>: - 1 - 0	
Change CODESYS Authentication Password	write	config_linux_user user=admin new- password=<Value> confirm- password=<Value>	Change the CODESYS access password	Right away

Table 200: Description of configuration scripts for “SNMP”

Parameters	Status	Call-Up	Output/Input	Valid
General SNMP information parameters				
Name of device	read	get_snmp_data device-name	Specifies the SNMP parameter “sysName”.	Right away
	write	config_snmp device-name=<Value>	Change the SNMP parameter “sysName” (<Value> = string). *	After restart
Description	read	get_snmp_data description	Specifies the SNMP parameter “sysDescr”.	Right away
	write	config_snmp description=<Value>	Change the SNMP parameter “sysDescr” (<Value> = string). *	After restart
Physical location	read	get_snmp_data physical-location	Specifies the SNMP “sysLocation” parameter.	Right away
	write	config_snmp physical-location=<Value>	Change the SNMP parameter “sysLocation” (<Value> = string). *	After restart
Contact	read	get_snmp_data contact	Specifies the SNMP “sysContact” parameter.	Right away
	write	config_snmp contact=<Value>	Change the SNMP parameter “sysContact” (<Value> = string).	After restart
* When entering values, the blank characters must be filled by either “+” or “%20”. If this is not done, the input is not recognized as a coherent string.				
SNMP Manager configuration for v1 and v2c				
Protocol status	read	get_snmp_data v1-v2c-state	Outputs the status of the SNMP protocol for v1/v2c as a string. Possible return values: - enabled - disabled	Right away
Local Community Name	read	get_snmp_data v1-v2c-community-name	Specifies the community name set for v1/v2c/	Right away
Protocol Status/Community Name	write	config_snmp v1-v2c-state=<Value1> v1-v2c-community-name=<Value2>	Activates/deactivates the v1/v2c protocol (<Value1> = enabled or disabled) and assigns a community name. (<Value2> = string without spaces, min. 1, max. 32 characters). Note: No community name is required for deactivation. Activation is only possible by entering a community name. A community name can only be saved when the protocol is activated.	After restart

Table 200: Description of configuration scripts for “SNMP”

Parameters	Status	Call-Up	Output/Input	Valid
SNMP Trap Receiver Configuration for v1 and v2c				
Any number of trap receivers can be configured. A trap receiver that has been set up is always active; the data set must be completely deleted to deactivate it.				
IP address of a trap receiver	read	get_snmp_data v1-v2c-trap-receiver-address <Nummer>	Specifies the IP address of the trap receiver that the controller is to send the v1 or v2 traps to. The <number> parameter enables consecutive reading of related data from the individually configured trap receiver for a short period of time (without interim changing of the data). This is a consecutive number that is not connected to the data. If the number is not included, the data of the first receiver are read.	Right away
Community Name	read	get_snmp_data v1-v2c-trap-receiver-community-name <Nummer>	Specifies the community name that the SNMP agent of the controller sends in the Trap Header. Parameter <number> see section “IP Address of a Trap Receiver”.	Right away
Trap version	read	get_snmp_data v1-v2c-trap-receiver-version <Nummer>	Specifies the SNMP version (“v1” or “v2c”) via which the SNMP agent sends the traps to the associated trap receiver address. Parameter <number> see section “IP Address of a Trap Receiver”.	Right away
Creating/ deleting a trap receiver	write	config_snmp v1-v2c-trap-receiver-edit=<Value1> v1-v2c-trap-receiver-address=<Value2> v1-v2c-trap-receiver-community-name=<Value3> v1-v2c-trap-receiver-version=<Value4>	Create a new trap receiver (value1=add) or delete an already configured trap receiver (value1=delete). Other parameters: <Value2> = IP address (number.number.number.number) that the controller is to send the traps to. <Value3>: Community string (string), which the controller enters in the trap header. <Value4>: SNMP version, via which the traps are sent (v1 or v2c). Note: All parameters must also be entered when deleting a trap receiver, as this is the only means to uniquely identify the data set.	After restart

Table 200: Description of configuration scripts for “SNMP”

Parameters	Status	Call-Up	Output/Input	Valid
Configuration of SNMP v3				
Any number of SNMP v3 users can be created. A user that has been set up is always active; the complete data set must be deleted to deactivate a user.				
Authentication Name	read	get_snmp_data v3-auth-name <Number>	Specifies the user name for the v3 user. The <number> parameter enables consecutive reading of the related data from the individually configured trap receiver for a short period of time (without interim changing of the data). This is a consecutive number that is not connected to the data. If the number is not included, the data of the first user are read.	Right away
Authentication encryption type	read	get_snmp_data v3-auth-type <Number>	Specifies the type of encryption that the v3 user uses (none, MD5, or SHA). Parameter <number> see “Authentication Name”.	Right away
Authentication key	read	get_snmp_data v3-auth-key <Number>	Specifies the key string for authentication. Parameter <number> see “Authentication Name”.	Right away
Privacy encryption type	read	get_snmp_data v3-privacy <number>	Specifies the type of privacy encryption for the v3 user (none, DES, or AES). Parameter <number> see “Authentication Name”.	Right away
Privacy key	read	get_snmp_data v3-privacy-key <number>	Specifies the key string for privacy. If nothing is entered, the SNMP agent uses the “Authentication Key”. Parameter <number> see “Authentication Name”.	Right away
Trap receiver address	read	get_snmp_data v3-notification-receiver <number>	IP address of an SNMP manager that the agent traps for this v3 user are sent to. If nothing is entered here, no traps are sent for this user. Parameter <number> see “Authentication Name”.	Right away

Table 200: Description of configuration scripts for “SNMP”

Parameters	Status	Call-Up	Output/Input	Valid
Add new v3-User	write	<pre> config_snmp v3-edit=add v3-auth-name=<Value1> v3-auth-type=<Value2> v3-auth-key=<Value3> v3-privacy=<Value4> v3-privacy-key=<Value5> v3-notification-receiver=<Value6> </pre>	<p>Creating a new v3 user. v3-auth-name: User name, string without spaces, maximum of 32 characters. This must be a new, unique user name.</p> <p>Parameters: User name (<Value1> = string) Encryption method. (<Value2> = none, MD5 or SHA). Key string for authentication, (<Value3> = String with at least eight and a maximum of 32 characters) Privacy encryption method (<Value4> = none, DES or AES). Privacy key string (<Value5> = String with at least eight and a maximum of 32 characters), can also be blank; in this case the authentication key will be used. The IP address of a trap receiver is transmitted as the notification receiver (<Value6> = number.number.number.number) . This parameter is not required if no v3 traps are to be sent.</p>	After restart
Delete v3 user	write	<pre> config_snmp v3-edit=delete v3-auth-name=<Value> </pre>	<p>Deleting a v3 user that has been set up. Because the doubled allocation of the same user name is prevented when creating a user, the name is sufficient to uniquely identify a data set (<Value> = string).</p>	After restart

14.2.1.10 WagoLibCpuUsage.lib

The controller 750-8204 supports the following function blocks of the “WagoLibCpuUsage.lib” library:

- CPU_Usage

The document containing the description of the library and the function block it includes is available for download on the Internet at www.wago.com.

14.2.1.11 WagoLibDiagnosticIDs.lib

The controller 750-8204 supports the following function blocks of the “WagoLibDiagnosticIDs.lib” library:

- DIAGNOSTIC_SEND_ID
- DIAGNOSTIC_SET_TEXT_FOR_ID

The document containing the description of the library and the function block it includes is available for download on the Internet at www.wago.com.

14.2.1.12 WagoLibLed.lib

The controller 750-8204 supports the following function blocks of the “WagoLibLed.lib” library:

- LED_SET_STATIC
- LED_SET_BLINK
- LED_SET_FLASH
- LED_SET_ERROR
- LED_RESET_ERROR
- LED_RESET_ALL_ERRORS
- LED_GET_STATE
- LED_GET_STATE_ASYNC

The document containing a description of this library and the function blocks it includes is available for download on the Internet at www.wago.com.

14.2.1.13 WagoLibNetSnmp.lib

The controller 750-8204 supports the following function blocks of the “WagoLibNetSnmp.lib” library:

- snmpGetValueCustomOID_INT32
- snmpGetValueCustomOID_STRING
- snmpGetValueCustomOID_UINT32
- snmpRegisterCustomOID_INT32
- snmpRegisterCustomOID_STRING
- snmpRegisterCustomOID_UINT32
- snmpSetValueCustomOID_INT32
- snmpSetValueCustomOID_STRING
- snmpSetValueCustomOID_UINT32

The document containing the description of the library and the function block it includes is available for download on the Internet at www.wago.com.

14.2.1.14 WagoLibNetSnmpManager.lib

The controller 750-8204 supports the following function blocks of the “WagoLibNetSnmpManager.lib” libraries:

- SNMPM_DINT_TO_TLV
- SNMPM_UDINT_TO_TLV
- SNMPM_STRING_TO_TLV
- SNMPM_TLV_TO_DINT
- SNMPM_TLV_TO_UDINT
- SNMPM_TLV_TO_STRING
- SNMPM_GET
- SNMPM_GET_V3

- SNMPM_SET
- SNMPM_SET_V3

The document containing a description of this library and the function blocks it includes is available for download on the Internet at www.wago.com.

14.2.1.15 WagoLibSSL.lib

The controller 750-8204 supports the following function blocks of the “WagoLibSSL.lib” library:

- SSL_CTX
- SSL_CTX_load_verify_locations
- SSL_CTX_sess_set_cache_size
- SSL_CTX_set_client_CA_list
- SSL_CTX_set_method
- SSL_CTX_use_certificate_file
- SSL_CTX_use_PrivateKey_file
- SSL_free
- SSL_get_error
- SSL_Hndshk_Accept
- SSL_Hndshk_Connect
- SSL_load_client_CA_file
- SSL_read
- SSL_shutdown
- SSL_write

The document containing a description of this library and the function blocks it includes is available for download on the Internet at www.wago.com.

14.2.1.16 WagoLibTerminalDiag.lib

The controller 750-8204 supports the following function blocks of the “WagoLibTerminalDiag.lib” library:

- GET_TERMINALDIAG

The document containing a description of this library and the function blocks it includes is available for download on the Internet at www.wago.com.

14.2.2 Libraries for a CANopen and CANLayer2 Link

This section contains libraries supported by the controller 750-8204 for linking with CANopen and CANLayer2.

14.2.2.1 WagoCANLayer2_02.lib

The controller 750-8204 supports the following function blocks of the “WagoCANLayer2_02.lib” library:

- CAN_ERROR_INFO
- CAN_LAYER2_VERSION
- CAN_RX_11BIT_FRAME
- CAN_RX_29BIT_FRAME
- CAN_TX_11BIT_FRAME
- CAN_TX_29BIT_FRAME
- CAN_OPEN
- CAN_CLOSE
- CAN_RESET
- CAN_SET_LED

The document containing a description of this library and the function blocks it includes is available for download on the Internet at www.wago.com.

14.2.2.2 WagoCANopen_02.lib

The controller 750-8204 supports the following functions blocks of the “WagoCANopen_02.lib” library:

- CIA405_GET_KERNEL_STATE
- CIA405_GET_LOCAL_NODE_ID
- CIA405_RECV_EMCY
- CIA405_RECV_EMCY_DEV
- CIA405_GET_STATE
- CIA405_RECV_EMCY_DEV
- CIA405_NMT
- CANOPEN_VERSION
- NMT_GUARD_ERROR
- NMT_GUARD_ERROR_DEV
- CIA405_SDO_WRITE4
- CIA405_SDO_READ4
- CIA405_SDO_WRITEXX
- CIA405_SDO_READXX

The document containing a description of this library and the function blocks it includes is available for download on the Internet at www.wago.com.

List of Figures

Figure 1: View of device	24
Figure 2: Data contacts	26
Figure 3: Power Jumper Contacts	27
Figure 4: CAGE CLAMP® connections	28
Figure 5: Service interface, (closed and open flap)	29
Figure 6: Network connections – X1, X2	30
Figure 7: RS-232/RS-485 – X3 communication connection	31
Figure 8: Termination with DTE-DCE connection (1:1)	32
Figure 9: Termination with DTE-DTE connection (cross-over)	32
Figure 10: RS-485 bus termination	33
Figure 11: CANopen – X4 fieldbus connection	34
Figure 12: CANopen standard bus termination	35
Figure 13: Power supply indicating elements	36
Figure 14: Indicating elements for fieldbus/system	37
Figure 15: Indicating elements, memory card slot	38
Figure 16: Indicating elements, RJ-45 jacks	39
Figure 17: Mode selector switch	40
Figure 18: Reset button	41
Figure 19: Memory card slot	42
Figure 20: Schematic diagram	43
Figure 21: Spacing	53
Figure 22: Release Tab of Controller	55
Figure 23: Insert I/O Module (Example)	56
Figure 24: Snap the I/O Module into Place (Example)	56
Figure 25: Connecting a Conductor to a CAGE CLAMP®	57
Figure 26: Power Supply Concept	58
Figure 27: “Open DHCP”, example figure	63
Figure 28: CBM starting screen	64
Figure 29: CBM – Selecting “Networking”	64
Figure 30: CBM – Selecting “TCP/IP”	65
Figure 31: CBM – Selecting “IP address”	65
Figure 32: CBM – Selecting the IP address	66
Figure 33: CBM – Entering a new IP address	66
Figure 34: “WAGO Ethernet Settings” – Starting screen	67
Figure 35: “WAGO Ethernet Settings” – “Network” tab	68
Figure 36: Example of a function test	69
Figure 37: Entering authentication	77
Figure 38: Password reminder	77
Figure 39: WBM browser window (example)	79
Figure 40: WBM status information (example)	79
Figure 41: “WAGO ETHERNET Settings” – Start screen	113
Figure 42: “WAGO ETHERNET Settings” – Communication link	114
Figure 43: “WAGO ETHERNET Settings” – Identification tab (example)	115
Figure 44: “WAGO ETHERNET Settings” – Network tab	116
Figure 45: “WAGO ETHERNET Settings” – Protocol tab	118
Figure 46: “WAGO ETHERNET Settings” – Status tab	119
Figure 47: Target system settings (1)	121
Figure 48: Target system settings (2)	121

Figure 49: Creating a new function block	122
Figure 50: Programming interface with the PLC_PRG program module	122
Figure 51: “Resources” tab	123
Figure 52: Control configuration – Edit	124
Figure 53: “Start WAGO-I/O-CHECK and scan” button	124
Figure 54: WAGO-I/O-CHECK – Starting screen	125
Figure 55: I/O Configurator empty	126
Figure 56: “Add I/O modules” button	126
Figure 57: “Module selection” window	127
Figure 58: I/O Configurator with defined I/O modules	127
Figure 59: Variable declaration	128
Figure 60: Control configuration: I/O modules with their associated addresses	128
Figure 61: Program function block	129
Figure 62: Input assistant for selecting variables	129
Figure 63: Example of an allocation	130
Figure 64: Creating a communication link – Step 1	131
Figure 65: Creating a communication link – Step 2	132
Figure 66: Creating a communication link – Step 3	132
Figure 67: Task configuration	134
Figure 68: Changing task names 1	135
Figure 69: Call-up to add to the program module	136
Figure 70: Cyclic task	137
Figure 71: Freewheeling task	138
Figure 72: CODESYS – System events	139
Figure 73: CODESYS program provokes division by “0”	141
Figure 74: CODESYS – Creating and activating an event handler	141
Figure 75: CODESYS – New module has been generated	142
Figure 76: CODESYS – Enter the event in a global variable	142
Figure 77: CODESYS – Variable contents prior to division by “0”	143
Figure 78: CODESYS – Variable contents after division by “0” and call-up of the event handler	143
Figure 79: Process image	144
Figure 80: Flag area	145
Figure 81: Internal data bus synchronization 01	149
Figure 82: I/O module synchronization 02	151
Figure 83: I/O module synchronization 03	152
Figure 84: Internal data bus synchronization 04	153
Figure 85: Internal data bus settings	154
Figure 86: Program memory	157
Figure 87: Data memory and function block limitation	158
Figure 88: Remanent main memory	158
Figure 89: Flag and retain memory	159
Figure 90: Selecting the visualization technique in the target system settings ...	160
Figure 91: Creating the PLC_VISU starting visualization	161
Figure 92: CODESYS control system configuration - MODBUS settings	168
Figure 93: MODBUS process image	174
Figure 94: Flag area	175
Figure 95: Correlation between “IEC 61131-3” variables and PFC variables ...	202
Figure 96: Adding the CANopen master	205
Figure 97: Master basic parameters tab	206

Figure 98: Master CAN Parameters tab	207
Figure 99: Adding a CANopen slave	208
Figure 100: Basic parameters tab	209
Figure 101: CAN parameters tab.....	210
Figure 102: CAN module selection tab.....	213
Figure 103: PDO mapping tab.....	214
Figure 104: PDO properties window.....	215
Figure 105: Service data objects tab.....	217
Figure 106: Adapting SDOs	218
Figure 107: “Module parameters” tab	219
Figure 108: Attaching a CANopen slave	220
Figure 109: Configuring a CANopen slave.....	220
Figure 110: Configuration of the CANopen slave variables.....	221
Figure 111: Configuration of CANopen slave parameters.....	222
Figure 112: “Resources” tab.....	224
Figure 113: “Open” dialog window	225
Figure 114: Module symbol in the menu bar; FUP programming language.....	225
Figure 115: Entity for the function block DiagGetBusState() in FUP	225
Figure 116: Function block DiagGetState() in FUP.....	226
Figure 117: Offline view of the variable window in CODESYS.....	226
Figure 118: Online view of the variable window (top window) in FUP.....	228
Figure 119: Example of diagnostics	228
Figure 120: DiagGetState() diagnostic call	230
Figure 121: Online view of the EXTENDEDINFO array in the binary representation	231
Figure 122: Attaching the CANopen master	233
Figure 123: Setting the baud rate	233
Figure 124: EDS file “Generic CAN Device”	234
Figure 125: “Module parameters” tab	234
Figure 126: “CAN parameters“ tab	235
Figure 127: Attaching the CAN Layer2 device.....	235
Figure 128: Power supply indicating elements	236
Figure 129: Indicating elements for fieldbus/system	237
Figure 130: Flashing sequence process diagram.....	242
Figure 131: Inserting the memory card	250
Figure 132: Release Tab of Controller	252
Figure 133: Removing the I/O Module (Example)	253
Figure 134: Graphical Representation of the “ConfigToolFB” Function Block.	288

List of Tables

Table 1: Variants	12
Table 2: Number Notation.....	15
Table 3: Font Conventions	15
Table 4: Legend for figure “Device view”	24
Table 5: Legend for Figure “Power Jumper Contacts”	27
Table 6: Legend for figure “CAGE CLAMP [®] connections”	28
Table 7: Service interface.....	29
Table 8: Legend for Figure "Network Connections – X1, X2"	30
Table 9: Key for the “RS-232/RS-485 – X3 communication connection” figure.	31
Table 10: Function of RS-232 signals for DTE/DCE	32
Table 11: Legend for Figure “CANopen – X4 Fieldbus Connection”	34
Table 12: Legend for Figure “Power Supply Indicating Elements”	36
Table 13: Legend for figure “Fieldbus/System Indicating Elements”	37
Table 14: Legend for figure “Indicating Elements, memory card slot”	38
Table 15: Legend for figure “Indicating elements, RJ-45 jacks”	39
Table 16: Mode selector switch.....	40
Table 17: Technical data, device data	44
Table 18: Technical Data – System Data	44
Table 19: Technical Data – Power Supply	44
Table 20: Technical data – Clock.....	44
Table 21: Technical Data – Programming	45
Table 22: Technical Data – Internal Data Bus	45
Table 23: Technical Data – ETHERNET	45
Table 24: Technical Data – CANopen	45
Table 25: Technical Data – Serial Interface	46
Table 26: Technical Data – Field Wiring.....	47
Table 27: Technical Data – Power Jumper Contacts	47
Table 28: Technical Data – Data Contacts	47
Table 29: Technical Data – Climatic Environmental Conditions	47
Table 30: WAGO DIN Rail.....	53
Table 31: Filter Modules for 24 V Supply	58
Table 32: Default IP Addresses for ETHERNET Interfaces.....	62
Table 33: Network Mask 255.255.255.0	62
Table 34: WBM Users.....	74
Table 35: Linux [®] Users	74
Table 36: User Settings in the Initial State.....	77
Table 37: Access Rights for WBM Pages	78
Table 38: WBM “Status Information” page – “Controller Details” group	81
Table 39: WBM “Status Information” page – “Network Details (Xn)” group(s).	81
Table 40: WBM “CODESYS Configuration” page – “General Configuration” group	82
Table 41: WBM “CODESYS – Information” page – “CODESYS” group	83
Table 42: WBM “CODESYS Information” page – “Project Details” group.....	83
Table 43: WBM “CODESYS Information” page – “Task n” group(s)	84
Table 44: WBM “CODESYS WebVisu” page – “Webserver Configuration” group	85
Table 45: WBM “Configuration of Network Parameters” page – “Hostname” group	86

Table 46: WBM “Configuration of Network Parameters” page – “Domain Name” group	86
Table 47: WBM “TCP/IP Configuration” page – “Switch Configuration” group	87
Table 48: WBM “TCP/IP Configuration” page – “IP Address (Xn)” group(s)....	87
Table 49: WBM “TCP/IP Configuration” page – “Default Gateway” group	88
Table 50: WBM “TCP/IP Configuration” page – “DNS Server” group	88
Table 51: WBM “Configuration of ETHERNET Parameters” page – “Interface Xn” groups	89
Table 52: WBM “Configuration of Time and Date” page – “Date on Device” group	90
Table 53: WBM “Configuration of time and date” page – “Time on Device” group	90
Table 54: WBM “Configuration of time and date” page – “Time Zone” group...	91
Table 55: WBM “Configuration of time and date” page – “TZ String” group.....	91
Table 56: WBM “Configuration of the users for the Web-based Management” page – “Change Password for selected user” group	92
Table 57: WBM “Create Bootable Image” page – “Create bootable image from active partition” group	93
Table 58: WBM “Configuration of Serial Interface RS232” page – “Assign Owner of serial Interface” group	94
Table 59: WBM “Mass Storage” page – “<Device Name>” group.....	99
Table 60: WBM “Mass Storage” page – “<Device Name>” group.....	99
Table 61: WBM “Software Uploads” page – “Upload New Software” group ...	100
Table 62: WBM “Software Uploads” page – “Activate New Software” group .	100
Table 63: WBM “Configuration of Network Services” page – “Telnet” group .	101
Table 64: WBM “Configuration of Network Services” page – “FTP” group.....	101
Table 65: WBM “Configuration of Network Services” page – “FTPS” group ..	101
Table 66: WBM “Configuration of Network Services” page – “HTTP” group .	101
Table 67: WBM “Configuration of Network Services” page – “HTTPS” group	101
Table 68: WBM “Configuration of NTP Client” page – “NTP Client” group ...	102
Table 69: WBM “Configuration of the CODESYS Services” page – “CODESYS Webserver” group	103
Table 70: WBM “Configuration of the CODESYS Services” page – “Communication” group.....	103
Table 71: WBM “Configuration of the CODESYS Services” page – “Port Authentication” group.....	103
Table 72: WBM “Configuration of the CODESYS Services” page – “Port Authentication Password” group	103
Table 73: WBM “SSH Client Settings” page – “SSH Client” group.....	104
Table 74: WBM “TFTP Server” page – “TFTP Server” group	105
Table 75: WBM “Configuration of SNMP parameter” page – “General SNMP Configuration” group	106
Table 76: WBM “Configuration of SNMP parameter” page – “SNMP v1/v2c Manager Configuration” group.....	107
Table 77: WBM “Configuration of SNMP parameter” page – “Actually Configured Trap Receivers” group.....	107
Table 78: WBM “Configuration of SNMP parameter” page – “Trap Receiver n” group	108
Table 79: WBM “Configuration of SNMP parameter” page – “Add new Trap Receiver” group	108

Table 80: WBM “Configuration of SNMP v3” page – “Actually Configured v3 Users” group	109
Table 81: WBM “Configuration of SNMP v3 Users” page – “v3 User n” group(s)	109
Table 82: WBM “Configuration of SNMP v3 Users” page – “Add new v3 User” group	110
Table 83: WBM “Diagnostic Information” page	111
Table 84: Syntax of logical addresses	133
Table 85: Events	140
Table 86: Access to the Process Images of the Input and Output Data – Internal Data Bus	146
Table 87: Access to the Process Images of the Input and Output Data – MODBUS	147
Table 88: Access to the Process Images of the Input and Output Data – CANopen	147
Table 89: Access to the Process Images of the Input and Output Data – Flags..	147
Table 90: Arrangement of the I/O modules for the addressing example	148
Table 91: Internal Data Bus Settings	155
Table 92: Errors and remedies	164
Table 93: MODBUS Settings	169
Table 94: MODBUS TCP Settings	170
Table 95: MODBUS UDP Settings	170
Table 96: MODBUS RTU Settings	171
Table 97: MODBUS Mapping for Read Bit Services FC1, FC2	176
Table 98: MODBUS mapping for write bit services FC5, FC15	177
Table 99: MODBUS Mapping for Read Register Services FC3, FC4, FC23	178
Table 100: MODBUS mapping for write register services FC6, FC16, FC22, FC23	180
Table 101: WAGO MODBUS Registers	182
Table 102: Watchdog Commands	186
Table 103: Watchdog Status	187
Table 104: Watchdog Configuration	188
Table 105: Diagnostics for the Error Server	190
Table 106: Overview of addresses in the object directory	193
Table 107: Indexing of “IEC 61131-3” Variable Data in the Object Directory..	200
Table 108: Fieldbus access to PFC output data	201
Table 109: Examples for CODESYS access to PFC variables	203
Table 110: Maximum indices and sub-indices for “IEC 61131-3” variables	204
Table 111: Example of “IEC 61131-3” output variables	204
Table 112: Description of Basic Parameters	206
Table 113: Description of the CAN parameters	207
Table 114: Description of Basic Parameters	209
Table 115: Description of the CAN parameters	211
Table 116: Receiving and Sending Description for PDO Mapping	215
Table 117: Description of the PDO Properties window	216
Table 118: Description of the module parameters (slave)	219
Table 119: Description of the CANopen Slave Variables Window	221
Table 120: Description of CANopen Slave Settings	222
Table 121: Diagnostics Information Bits	229
Table 122: Legend for Figure “Power Supply Indicating Elements”	236

Table 123: Field-Side Supply Diagnostics	236
Table 124: System Power Supply Diagnostics	236
Table 125: Diagnostics SYS LED	237
Table 126: Diagnostics RUN LED	238
Table 127: Diagnostics I/O LED	239
Table 128: Diagnostics CAN LED	240
Table 129: Overview of Error Codes	244
Table 130: Error Code 1, Explanation of Blink Codes and Procedures for Troubleshooting	245
Table 131: Error Code 3, Explanation of Blink Codes and Procedures for Troubleshooting	247
Table 132: Error Code 4, Explanation of Blink Codes and Procedures for Troubleshooting	248
Table 133: Error Code 5, Explanation of Blink Codes and Procedures for Troubleshooting	248
Table 134: Error Code 6, Explanation of Blink Codes and Procedures for Troubleshooting	248
Table 135: Error Code 9, Explanation of Blink Codes and Procedures for Troubleshooting	249
Table 136: 1 Channel Digital Input Module with Diagnostics	255
Table 137: 2 Channel Digital Input Modules	255
Table 138: 2 Channel Digital Input Module with Diagnostics	255
Table 139: 2 Channel Digital Input Module with Diagnostics and Output Process Data	256
Table 140: 4 Channel Digital Input Modules	256
Table 141: 8 Channel Digital Input Modules	256
Table 142: 8 Channel Digital Input Module PTC with Diagnostics and Output Process Data	257
Table 143: 16 Channel Digital Input Modules	257
Table 144: 1 Channel Digital Output Module with Input Process Data	258
Table 145: 2 Channel Digital Output Modules	258
Table 146: 2 Channel Digital Input Modules with Diagnostics and Input Process Data	259
Table 147: 2 Channel Digital Input Modules with Diagnostics and Input Process Data 75x-506	259
Table 148: 4 Channel Digital Output Modules	260
Table 149: 4 Channel Digital Output Modules with Diagnostics and Input Process Data	260
Table 150: 8 Channel Digital Output Module	260
Table 151: 8 Channel Digital Output Modules with Diagnostics and Input Process Data	261
Table 152: 16 Channel Digital Output Modules	261
Table 153: 8 Channel Digital Input/Output Modules	262
Table 154: 1 Channel Analog Input Modules	263
Table 155: 2 Channel Analog Input Modules	263
Table 156: 4 Channel Analog Input Modules	264
Table 157: 3-Phase Power Measurement Module	265
Table 158: 8 Channel Analog Input Modules	265
Table 159: 2 Channel Analog Output Modules	266
Table 160: 4 Channel Analog Output Modules	266

Table 161: Counter Modules 750-404, (and all variations except of /000-005), 753-404, (and variation /000-003)	267
Table 162: Counter Modules 750-404/000-005	268
Table 163: Counter Modules 750-638, 753-638	268
Table 164: Pulse Width Modules 750-511, /xxx-xxx	269
Table 165: Serial Interface Modules with alternative Data Format	269
Table 166: Serial Interface Modules with Standard Data Format	270
Table 167: Data Exchange Module	270
Table 168: SSI Transmitter Interface Modules	271
Table 169: Incremental Encoder Interface Modules 750-631/000-004, --010, -011	271
Table 170: Incremental Encoder Interface Modules 750-634	272
Table 171: Incremental Encoder Interface Modules 750-637	272
Table 172: Digital Pulse Interface Modules 750-635	273
Table 173: DC-Drive Controller 750-636	273
Table 174: Stepper Controller RS 422 / 24 V / 20 mA 750-670	274
Table 175: RTC Module 750-640	275
Table 176: DALI/DSI Master Module 750-641	275
Table 177: Overview of Input Process Image in the "Easy" Mode	277
Table 178: Overview of the Output Process Image in the "Easy" Mode“	277
Table 179: EnOcean Radio Receiver 750-642	278
Table 180: MP Bus Master Module 750-643	279
Table 181: Bluetooth [®] RF-Transceiver 750-644	279
Table 182: Vibration Velocity/Bearing Condition Monitoring VIB I/O 750-645	280
Table 183: KNX/EIB/TP1 Module 753-646	281
Table 184: AS-interface Master Module 750-655	282
Table 185: System Modules with Diagnostics 750-610, -611	283
Table 186: Binary Space Module 750-622 (with Behavior Like 2 Channel Digital Input)	283
Table 187: CODESYS System Libraries	284
Table 188: Input Variable “DEVICE NUMBER”	287
Table 189: Description of the Configuration Scripts for “Information”	288
Table 190: Description of the Configuration Scripts for “CODESYS”	289
Table 191: Description of the Configuration Scripts for “Networking - Host- /Domain-Name”	289
Table 192: Description of the Configuration Scripts for “Networking - TCP/IP”	290
Table 193: Description of the Configuration Scripts for “Networking - ETHERNET”	292
Table 194: Description of the Configuration Scripts for “CODESYS”	293
Table 195: Description of the Configuration Scripts for “NTP”	294
Table 196: Description of the Configuration Scripts for “Clock”	295
Table 197: Description of the Configuration Scripts for “Administration”	295
Table 198: Description of Configuration Scripts for “Package Server”	296
Table 199: Description of Configuration Scripts for “Ports and Services”	296
Table 200: Description of configuration scripts for “SNMP”	300

WAGO Kontakttechnik GmbH & Co. KG
Postfach 2880 • D-32385 Minden
Hansastraße 27 • D-32423 Minden
Phone: +49/5 71/8 87 – 0
Fax: +49/5 71/8 87 – 1 69
E-Mail: info@wago.com
Internet: <http://www.wago.com>

