

## Data sheet | Item number: 210-842

Push-button marker; for frames, to be snapped in or glued in place; 27 x 12.5 mm; silver-colored

[www.wago.com/210-842](http://www.wago.com/210-842)



### Data

#### Technical data

Suitable	for Siemens push-button frame
Marking method	Thermal transfer
Marking	plain
Delivery form configuration	350 markers/reel; 1 line
Printing device	Smart Printer (Thermal Transfer Printer)

#### Physical data

Height	27 mm
Width	12.5 mm
Depth	0.65 mm
Marking surface	27 x 12.5 mm

#### Mechanical data

Mounting type	Snap-in or adhesive mounting
---------------	------------------------------

Subject to changes. Please also observe the further product documentation!

WAGO Corporation  
Germantown, WI 53022  
Phone: 1-800-DIN-RAIL (346-7245) | Fax: (262) 255-6222  
Email: [info.us@wago.com](mailto:info.us@wago.com) | Web: [www.wago.us](http://www.wago.us)

Do you have any questions about our products?  
We are always happy to take your call at +49 (571) 887-44222.

Smear resistance	in conjunction with 258-5005 Ink Ribbon
------------------	---

## Material data

Color	silver-colored
Material	Polyester
UV resistance	EN 60068-2-5:2010 Procedure B
Adhesive information	Acrylic; permanent; foamed
Halogen-free	Yes
Weight	85 g


## Environmental requirements

Surrounding air temperature (storage)	≥+22 °C
Relative humidity	40 ... 50 %

## Commercial data

PU (SPU)	1 Stück
Packaging type	bag
Country of origin VKOrg Germany	DK
GTIN	4055143965156
Customs tariff number VKOrg Germany	3926909985

## Required accessories

Cover	
Cover	
	<p><b>Item no.: 210-843</b> Cover; for frames, snap-in type, 27 x 12.5 mm; halogen-free; transparent</p>
	<a href="http://www.wago.com/210-843">www.wago.com/210-843</a>

## Downloads

### Documentation

#### Operating Instructions

210-852 Information on handling print material	1	pdf	Download
	2020 Aug 28	1.0 MB	

## Environmental Product Compliance

### Compliance Search

Subject to changes. Please also observe the further product documentation!

Environmental Product Compliance 210-842

Push-button marker; for frames, to be snapped in or glued in place; 27 x 12.5 mm; silver-colored

[URL](#)

[Download](#)

## Installation Notes


### Stick on frame



Remove the push-button label from the carrier film.



Stick the push-button label onto the push-button frame.



WAGO's push-button label is attached to the push-button frame. A cover cannot be applied.

### Snap into frame



Remove the push-button label from the carrier film. Press and hold the pre-punched carrier film to do this.



Snap the push-button label, with the carrier film on the back, on to the push-button frame. Only the area of the push-button label outside the remaining carrier film is adhesive.



Optional: A cover may also be installed on a push-button frame equipped with latches.

Subject to changes. Please also observe the further product documentation!



Push-button label and cover are snapped on to the push-button frame.

Subject to changes. Please also observe the further product documentation!