



## Data sheet | Item number: 221-523

Mounting carrier; for 3-conductor terminal blocks; 221 Series - 4 mm<sup>2</sup>; with snap-in mounting foot for vertical mounting; white



[www.wago.com/221-523](http://www.wago.com/221-523)



RoHS  Compliant

BOMcheck.net

Color:

### Data

#### Geometrical Data

Width	23,7 mm / 0.933 inch
Height	57,3 mm / 2.256 inch
Height from the surface	52,8 mm / 2.079 inch
Depth	16,9 mm / 0.665 inch

#### Material Data

Color	white
Insulating material	Polyamide 66 (PA 66)
Flammability class per UL94	V0
Weight	3.8 g

Subject to changes. Please also observe the further product documentation!

WAGO Kontakttechnik GmbH & Co. KG  
Hansastr. 27  
32423 Minden  
Phone: +49571 887-0 | Fax: +49571 887-169  
Email: [info.de@wago.com](mailto:info.de@wago.com) | Web: [www.wago.com](http://www.wago.com)

Do you have any questions about our products?  
We are always happy to take your call at +49 (571) 887-44222.



## Commercial data

Packaging type	BOX
Country of origin	CN
GTIN	4055143640930
Customs Tariff No.	39269097900

## Counterpart

### Downloads

#### Documentation

##### Bid Text

221-523 GAEB X81 - Datei	Feb 19, 2019	xml 2.8 kB	Download
221-523 doc - Datei	Jan 4, 2018	doc 24.6 kB	Download
Additional Information Technical explanations	Apr 3, 2019	pdf 2.1 MB	Download

## CAD/CAE-Data

### CAD data


2D/3D Models 221-523	URL	Download
----------------------	-----	----------

## Installation Notes


Subject to changes. Please also observe the further product documentation!

WAGO Kontakttechnik GmbH & Co. KG  
Hansastr. 27  
32423 Minden  
Phone: +49571 887-0 | Fax: +49571 887-169  
Email: [info.de@wago.com](mailto:info.de@wago.com) | Web: [www.wago.com](http://www.wago.com)

Do you have any questions about our products?  
We are always happy to take your call at +49 (571) 887-44222.




Inserting a connector into the mounting carrier.



Removing a connector from the mounting carrier.

#### Inserting a conductor




Inserting a conductor.



Horizontal screw mounting



Vertical screw mounting



Horizontal mounting via snap-in foot

Subject to changes. Please also observe the further product documentation!



Vertical mounting via snap-in foot

### Strain Relief




Use a cable tie to secure the conductors to the strain relief plate.



The strain relief plate can be removed.

### Testing



Testing a connector mounted on the carrier via test slot.


### Application

Subject to changes. Please also observe the further product documentation!



Connecting a light to the mains.

#### Marking



#### Labeling

Subject to changes. Please also observe the further product documentation!